

Asus Laptop Batteries (Replacement | Genuine)

[AU Laptop battery](#) >> [Au Laptop Computer Batteries](#) >> [ASUS Batteries](#)

By Brand: << [Prevpage](#) | [ASI](#) | [ASI AMATA](#) | [ASM](#) | [AST](#) | [ASUS](#) | [ATOM](#) | [AUPS](#) | [AV](#) | [Nextpage](#) >>

All the Asus Laptop Batteries

1. [AU Genuine Asus C41N1838 Battery Rechargeable Li-ion 15.32v 4090mah 4 Cells](#)
2. [AU Genuine Asus C31N1841 Battery Rechargeable Li-ion 50Wh 3ICP5/70/81](#)
3. [AU Genuine Asus C41N1837 Battery Rechargeable Li-ion For ROG Zephyrus Series](#)
4. [AU Genuine Asus C41N1825 Battery Rechargeable Li-ion For X403FA Series](#)
5. [AU Genuine Asus C31N1845 Battery Rechargeable Li-ion 11.55v 42Wh](#)
6. [AU Genuine Asus C31N1843 Battery 3ICP5/58/78 Rechargeable Li-ion 11.55v 42Wh](#)
7. [AU Genuine Asus C31N1836-1 Battery Rechargeable Li-ion 3ICP5/58/78 42Wh](#)
8. [AU Genuine Asus C21N1818-1 Battery Rechargeable 2ICP7/54/83 Li-ion 37Wh](#)
9. [AU Genuine Asus C21N1818 Battery 2ICP7/60/80 Li-ion 7.7V Rechargeable 4850mah](#)
10. [AU Genuine Asus C31N1724 Batteries Rechargeable Li-Polymer 11.55v 50Wh](#)
11. [AU Genuine Asus C41N1828 Battery Rechargeable Li-Polymer 60Wh 15.44v](#)
12. [AU Genuine Asus B41N1827 Battery Rechargeable Li-Polymer For UX562FA Series](#)
13. [AU Genuine Asus C41N1809 Battery Rechargeable Li-Polymer 15.4v 3640mah](#)
14. [AU Genuine Asus C21N1808 Battery Rechargeable Li-Polymer For Chromebook C423NA C523NA](#)
15. [AU Genuine Asus C31N1821 Battery Rechargeable Li-Polymer For UX392FA UX392FN](#)
16. [AU Genuine Asus B31N1822 Battery Rechargeable Li-Polymer 42Wh 3653mah](#)
17. [AU Genuine Asus C31N1824 Battery Rechargeable For Chromebook Flip C434TA](#)
18. [AU Genuine Asus C31N1831 Battery Rechargeable Li-Polymer For P3340 P3540](#)
19. [AU Genuine Asus C42N1839 Battery For UX534F UX563 Series Li-ion 71Wh](#)
20. [AU Genuine Asus C21N1819 Battery For VivoBook 14 X420UA Series Li-Polymer 38Wh](#)
21. [AU Genuine Asus C21N1833 Battery For Zenbook 14 UX431FA Series Laptop 47Wh](#)
22. [AU Genuine Asus C41N1802 Battery For GX701GX Series Li-ion 15.4V 76Wh](#)
23. [AU ASUS C21N1807 Battery For Vivobook E203NA Series Laptop Li-Polymer](#)
24. [AU C32N1810 Battery For Asus ZenBook Flip 15 UX562 Series Li-Polymer 86Wh](#)
25. [AU C12P1602 Battery For ASUS ZENPAD 3S 10 Z500K Series 30Wh Li-Polymer](#)
26. [AU ASUS B21N1818 Battery For VivoBook 15 X512DA X512UB Li-Polymer 32Wh](#)
27. [AU Li-Polymer 3.85v C11P1514 Battery For ASUS ZenPad 3 8.0 ZT581KL](#)
28. [AU C21N1717 Battery For Asus VivoBook Flip 12 TP202NA Li-Polymer 36Wh](#)
29. [AU C31N1815 Battery For Asus ZenBook UX333FA RX333FN Series Li-Polymer](#)
30. [AU C41N1832 Battery C41P0J1 For Asus Laptop Li-Polymer 15.4V 70Wh](#)
31. [AU B31N1732 Battery Asus B31Bi9H Li-Polymer Laptop Batteries 11.52V](#)
32. [AU Genuine C41PPEH Battery C41N1814 For Asus ZenBook 15 UX533FD Series 15.4v 73Wh](#)
33. [AU Asus C41N1804 Battery For UX450FDX UX480 Laptop Li-Polymer 15.4v](#)
34. [AU C11-ME571K Battery C11ME571K Asus Li-Polymer 3.8v 17Wh](#)
35. [AU Asus B31N1637 Battery B31Bi9H B31Bi2H Li-Polymer 11.52v](#)

36. [AU C31N1816 Battery Li-Polymer Asus 11.55v 50Wh Rechargeable](#)
37. [AU B31N1723 Battery Asus Li-Polymer 11.4v 4210mAh](#)
38. [AU C31N1721 Asus Battery Li-Polymer 11.4V 59Wh](#)
39. [AU C11P1426 Battery Li-Polymer Asus 3.8V 3948mAh 15.2Wh](#)
40. [AU C31N1806 Battery Asus Li-Polymer 3ICP5/58/78 42Wh 11.55v](#)
41. [AU C11P1509 Battery Li-Polymer ASUS 1ICP4/70/133 16Wh](#)
42. [AU C21N1434 Battery Li-Polymer Asus 7.6V 5000mAh 38Wh](#)
43. [AU C31N1803 Battery Asus Li-Polymer 3ICP6/60/72 11.55v 52Wh](#)
44. [AU A42N1713 Battery ASUS Li-ion A42L85H 74Wh 14.4V](#)
45. [AU A43N1605 Battery Li-ion ASUS A43LK41 125Wh 14.4v](#)
46. [AU ASUS B21N1628 Battery Li-Polymer 32Wh 7.6V](#)
47. [AU B31N1705-1 Battery B31N1705 Asus Li-Polymer 42Wh 11.52V](#)
48. [AU C41N1715 Battery Asus 4ICP4/72/75 Li-Polymer 15.4V 50Wh](#)
49. [AU B31N1708 Battery Li-Polymer Asus 42wh 11.52v](#)
50. [AU B31N1726 Battery Li-Polymer Asus 48Wh 11.4V](#)
51. [AU Genuine B31N1729 Asus Battery 11.52V 42Wh Li-Polymer](#)
52. [AU C11P1615 Battery Li-Polymer Asus 18Wh 3.85V](#)
53. [AU C12N1607 Battery Li-Polymer For Asus Transformer Mini T102HA](#)
54. [AU C21N1613 Battery ASUS Li-Polymer For Chromebook Flip C302CA](#)
55. [AU C21N1629 Battery Asus Li-Polymer 38Wh 7.6V](#)
56. [AU C21N1638 Battery Li-Polymer For Asus F442U A480U](#)
57. [AU C21N1714 Battery Asus Li-Polymer For TP401 TP401NA](#)
58. [AU Battery C21N1701 Asus Li-Polymer 39Wh 7.7V 5070mAh](#)
59. [AU ASUS C22N1720 C22PYJH Battery Li-Polymer 50Wh 7.7V](#)
60. [AU C31N15WZ Battery For Asus UX490 Series Laptop Li-Polymer 57Wh](#)
61. [AU C31N1636 Battery Asus Li-Polymer 11.49v 4165mAh](#)
62. [AU C31N1637 Asus Battery Li-Polymer 42Wh 11.55V](#)
63. [AU C31N1703 Battery Li-Polymer Asus 11.55V 52Wh 4550mah](#)
64. [AU ASUS C31N1704 Battery Li-Polymer 11.55V 52Wh 4550mAh](#)
65. [AU C31N1733 Battery Asus Li-Polymer 3ICP5/58/78 42Wh 11.55V](#)
66. [AU C41N1619 Battery Asus Li-Polymer 48Wh 15.4V 3120mAh](#)
67. [AU C41N1621 Battery Asus Li-Polymer 50Wh 15.4V](#)
68. [AU C41N1718 Battery Asus Li-Polymer 52wh 15.4v 3300mAh](#)
69. [AU Asus ROG Zephyrus M GM501 Laptop Battery C41N1727](#)
70. [AU Genuine C42N1728 Battery Asus Li-Polymer 15.4V 71Wh 4480mAh](#)
71. [AU MBP-01 Battery Li-Polymer For Asus PadFone A66 7.4V 24.4Wh](#)
72. [AU C22-UX52 Battery For ASUS ZenBook UX52A UX52V UX52S](#)
73. [AU C11P1425 C11P1429 Battery For ASUS Zenpad 7.0 Z370CG Z370KL](#)
74. [AU C31N1529 Battery For Asus B8230 B8230U Laptop](#)
75. [AU C31N1303 Battery For ASUS PU401 PU401L PU401LA Laptop](#)
76. [AU C31N1622 Battery For ASUS Zenbook UX530UX UX3430UA UX433 Series](#)
77. [AU C21N1612 Battery For Asus Transformer 3 T305CA Series](#)
78. [AU C12-TF400C Battery For ASUS Transformer Pad TF502T TF600T](#)
79. [AU A31N1537 Battery For Asus F441U X441UA R414 A441U](#)
80. [AU Asus A21P1518 Battery pack 3200mah 24.1wh](#)
81. [AU ASUS A21-SI Battery A21-SI A21-S1 A21LM2H 7.5v 22Wh](#)

82. [AU ASUS A31N1730 Battery 36Wh 10.8V Li-ion](#)
83. [AU ASUS A31N1719 Battery For X407 X507 Series](#)
84. [AU ASUS A42N1608 Battery For GX800V G800VI-XB78K Series](#)
85. [AU 10Wh A3101316 A31O1316 Battery For Asus M70AD](#)
86. [AU B11P1406 Battery For ASUS Phone PF450 PadFone X Mini 4.5](#)
87. [AU B32-M6 B32M6 Battery For ASUS Z70 Series](#)
88. [AU Genuine C21N1418 Battery For Asus Transformer T300Chi](#)
89. [AU C11P1323 Battery For Asus PadFone S P92L P93L PF500KL PF500K](#)
90. [AU Asus C22N1626 Battery 46Wh 2ICP5/40/115-2](#)
91. [AU C11P1309 Battery For Asus FonePad ME560CG,Note 6](#)
92. [AU Viknight A41-X550A Battery For Asus X450 X550 Series Laptop](#)
93. [AU Genuine 37Wh Asus A41-X500E Battery 14.4v](#)
94. [AU 19Wh C11-TF500CD Battery For Asus Transformer Pad TF500T](#)
95. [AU Genuine C41N1524 Battery Pack For Asus UX501 N501VW2B UX501JW Series](#)
96. [AU C11-ME570T Battery For Asus Google Nexus 7 Pad](#)
97. [AU 19Wh C11-P05 Battery For Asus PadFone Infinity A80](#)
98. [AU 19Wh C11-P1801 Battery For Asus P1801 B037K Pad](#)
99. [AU Asus C21N1634 Battery 38Wh 7.6V 5000mah](#)
100. [AU Asus C31N1522 Battery For Q553U 0b200-01880000 Series](#)
101. [AU Genuine C31N1525 Battery For Asus T302 LG-POLY T302CHI-2C Series](#)
102. [AU Genuine C31N1539 Battery For Asus UX305UAB Series](#)
103. [AU 57Wh Genuine C31N1602 Battery For Asus ZENBOOK UX330UA Series](#)
104. [AU Genuine C31N1620 Battery For Asus ZenBook UX430UQ Series](#)
105. [AU Genuine Asus C32N1516 Battery Pack 11.4V 93Wh](#)
106. [AU Genuine Asus C41N1716 Battery Pack 76Wh 15.4V](#)
107. [AU C11P1510 Battery For Asus ZenPad S 8.0 Z580CA 15.2Wh](#)
108. [AU Genuine C22N1307 Battery For Asus T300LA Series Laptop](#)
109. [AU C12N1406 Battery For Asus Pad Transformer Book T100TAL Series](#)
110. [AU C12N1604 Battery For Asus Transformer Book T100HA Series](#)
111. [AU C12P1301 Battery For Asus TRANSFORMER PAD SERIES](#)
112. [AU C12P1302 Battery For Asus Pad MeMO Pad ME302KL Series](#)
113. [AU C12P1305 Battery For Asus Transformer TF701T Series](#)
114. [AU 31Wh C12P1305 Battery For Asus Transformer TF701T TF501T](#)
115. [AU C21P095 C21N1313 Battery For Asus Transformer Book TX201LA Series](#)
116. [AU C21N1521 Battery For Asus VivoBook E200HA Series Laptop](#)
117. [AU Genuine ASUS C21N1625 Battery Pack Rechargeable 38Wh 7.7v](#)
118. [AU Asus C21-TF810CD Battery C21TF810CD 25Wh 3380mah Li-ion](#)
119. [AU 46Wh Genuine Asus C22N1623 Battery Li-ion For UX490 UX490U Series](#)
120. [AU Genuine Asus B31N1536 Battery For Transformer Book Flip TP201 Series](#)
121. [AU Genuine Asus B31N1625 Battery Packs 42Wh 11.52V](#)
122. [AU Genuine Asus B31N1631 Battery 42Wh 11.55V](#)
123. [AU Genuine Asus B31N1632 Battery 42Wh 11.55V](#)
124. [AU Genuine B31N1635 Asus Battery Packs 42wh 11.52V](#)
125. [AU Genuine Asus B41N1327 Battery For Pro B551L B551LA1A Series Laptop](#)
126. [AU Genuine Asus B41N1711 Battery Pack Rechargeable 64wh 15.2v](#)
127. [AU Genuine Asus C11N1303 Battery For Transformer Book T300LA](#)

128. [AU Genuine C11P1308 Battery For Asus TF501T TF502T](#)
129. [AU Genuine C11P1311 Battery For Asus ME715 ME175KG K00S Series](#)
130. [AU Genuine Asus C11P1329 Battery For MeMO Pad 8 Series](#)
131. [AU Genuine Asus C11P1331 Battery For Fonepad 8 FE380CG](#)
132. [AU Genuine Asus C11P1411 Battery For MeMO Pad 10 ME0310K](#)
133. [AU C11P1429 Battery 3.8V 13Wh 3450mah For Asus ZenPad 7.0 Series](#)
134. [AU Asus C11P1502 Battery 4750mah 18wh 3.8V Li-ion](#)
135. [AU Genuine ASUS A32-X51 Battery For X52S X53 X51L series Laptop 46Wh](#)
136. [AU Genuine Asus B21N1344 Battery Pack Li-ion 7.6V 32wh](#)
137. [AU 4 Cells A41N1424 Battery Pack For Asus GL552 GL552J Series](#)
138. [AU Genuine B21N1505 Battery For Asus EeeBook E402MA E402NA Series](#)
139. [AU Genuine ASUS A31-P2B A31P2B Battery Rechargeable Li-ion 33wh 11.3V](#)
140. [AU Genuine Asus A41N1702 Battery Pack Li-ion 44.4wh](#)
141. [AU Genuine C21N1423 Battery Packs For Asus X302LA X302LJ SERIES Laptop](#)
142. [AU Genuine ASUS A42N1710 Battery pack Li-ion 88wh](#)
143. [AU Genuine Asus B21N1506 Battery Packs For EeeBook E502MA series](#)
144. [AU Genuine B31N1427 Battery For Asus E502M E502S Laptop](#)
145. [AU Genuine ASUS B31N1534 Battery Pack For ZenBook UX510UX 48wh 11.4V Li-ion](#)
146. [AU Genuine ASUS C41N1541 Battery rechargeable Li-ion 15.2v 76wh](#)
147. [AU 4 cells A41-K56, A32-K56 Battery For Asus A46C S56 S46 Laptop](#)
148. [AU Genuine Asus A32-K56 A41-K56 Battery 15v 2950mah](#)
149. [AU 8 Cells 4400mah A31-K56 A41-K56 Battery For Asus K56C K56CA K56CM K46CA K46CM](#)
150. [AU Genuine Asus A41N1421 Battery Rechargeable 37wh 14.4v Li-ion](#)
151. [AU Genuine Asus A32N1511 Battery For ROG G752VL G752VT G752VM](#)
152. [AU Genuine B11P1405 Battery For Asus MeMO Pad 7 ME70CX](#)
153. [AU Asus C11P1326 Battery For MeMO Pad 7 ME176CX Series](#)
154. [AU Genuine B31N1425 Battery For Asus EeeBook E402MA](#)
155. [AU Genuine B41N1304 Battery pack For Asus VivoBook V451LA Laptop](#)
156. [AU Genuine Asus B41N1526 Battery li-ion rechargeable For ROG FX502VM series](#)
157. [AU Genuine C11P1402 Battery Pack For ASUS Fone Pad 7 ME375C FE375 FE375CXG](#)
158. [AU 31Wh ASUS C12N1432 Battery For Chromebook Flip C100PA Series](#)
159. [AU Genuine ASUS C41N1337 Battery Pack For Portable AiO PT2001](#)
160. [AU Genuine C41N1533 Battery Pack For ASUS UX560UQ UX560UX](#)
161. [AU 40Wh Genuine C23N1606 Battery For Asus ZENBOOK UX390UA SERIES](#)
162. [AU 90wh Genuine Asus A42N1520 Battery Packs For ROG SERIES Laptop](#)
163. [AU Genuine B31N1429 Battery For Asus K501U K501LB K501LX Series Laptop](#)
164. [AU 38wh Genuine C21N1334 Battery For Asus Transformer Book T200TA](#)
165. [AU Genuine C21N1603 Battery For Asus Transformer 3 Pro T303UA Laptop](#)
166. [AU Genuine ASUS C21N1627 Battery packs rechargeable Li-ion 7.7v 38wh](#)
167. [AU Genuine C31N1330 Battery For Asus ZENBOOK UX32LN UX32LA Series Laptop](#)
168. [AU Genuine ASUS C31N1538 Battery For ZENBOOK FLIP UX360UA Series Laptop](#)
169. [AU 6 cells Asus A31-x101 Battery packs for Eee Pc X101 X101 X101C series](#)
170. [AU ASUS A41-X550E battery For K550DP X550DP Series Laptop 2200mah 14.4V](#)
171. [AU Genuine Asus A41N1611 Battery For ROG GL553VW series Laptop](#)
172. [AU Genuine Asus B41N1514 battery packs for Q503 Series Laptop 64Wh](#)

173. [AU Genuine rechargeable B41N1532 Battery For Asus Zenbook Flip UX560](#)
174. [AU C11P1505 battery For Asus Z380KL Z380C P022 P024](#)
175. [AU Genuine Asus B31N1707 battery packs For VivoBook S410UQ-NH74](#)
176. [AU Genuine ASUS C31N1714 Battery packs, rechargeable UX461UA-1A batteries](#)
177. [AU Genuine ASUS B31N1345 Battery For TP500LA TP500LB TP500LN Series 48wh](#)
178. [AU Genuine Asus B31N1346 Battery For CHROMEBOOK C300MA Series 48Wh](#)
179. [AU Genuine ASUS B31N1424 Battery For K401U Series Laptop](#)
180. [AU Genuine ASUS B31N1535 Battery For Zenbook UX310 UX410UA Series](#)
181. [AU Genuine ASUS C21N1508 Battery For X456 Laptop 38wh](#)
182. [AU Genuine ASUS C21N1530 Battery For Chromebook C202 C202SA Series](#)
183. [AU Genuine C31N1428 Battery For Asus Zenbook UX305LA Series](#)
184. [AU Genuine C31N1528 Battery For Asus UX360CA Series Laptop 54Wh](#)
185. [AU Genuine C31N1610 Battery For Asus ZenBook UX330CA Laptop](#)
186. [AU 96Wh Genuine Asus C32N1340 Battery For ZenBook NX500JK Series](#)
187. [AU Genuine C41N1531 Battery For Asus ROG GL502 Series Laptop](#)
188. [AU Genuine Asus C32N1523 Battery For UX501VW Series 96Wh 11.4V](#)
189. [AU Genuine Asus VivoBook X441UA X441uv X441SC A31N1537 Battery](#)
190. [AU Genuine C21N1518 Battery For Asus TP501 TP501UA Series](#)
191. [AU Genuine ASUS A32N1331 A32N1332 Battery For PU450 PU550 Series Laptop](#)
192. [AU Genuine ASUS B21N1404 Battery For BU201 Series Laptop](#)
193. [AU Genuine ASUS B31N1503 Battery For E202SA Series Laptop 48wh](#)
194. [AU ASUS C12N1419 Battery For Transformer Book T100 CHI](#)
195. [AU ASUS C21N1335 Battery For VivoBook S451 S451LA S451LB Series](#)
196. [AU Genuine ASUS C21N1618 Battery 7.7V 36Wh](#)
197. [AU Genuine ASUS C31N1411 Battery For Zenbook UX305 Series](#)
198. [AU ASUS B31N1402 Battery For Q551 Q551L Series Laptop 48wh 11.4V](#)
199. [AU ASUS C11P1414 Battery Pack 3.7V 4170mAh 16Wh](#)
200. [AU ASUS C12P1601 Battery 3.8V 5900mah Li-ion](#)
201. [AU A41N1424 Battery For ASUS ZX50V ZX50VW FX-Plus G552VX Series](#)
202. [AU C31N1517 Battery For ASUS TP301 TP301UA Series Laptop](#)
203. [AU ASUS C11P1330 C11P1330 Li-ion Battery For AST21 MeMO Pad 8 Tablet](#)
204. [AU ASUS C21N1413 battery For Transformer Book T300 T300A 7.6V](#)
205. [AU ASUS C21N1504 Battery For TP200SA Series Laptop 38Wh 7.6V](#)
206. [AU ASUS C21N1408 Battery 37Wh 4840mah 7.5V](#)
207. [AU ASUS C21N1409 Battery 37Wh 4800Mah For Notebook X Series X455](#)
208. [AU Genuine ASUS C21-TX300P Battery For Transformer Book TX300](#)
209. [AU Genuine C21N1414 Battery for Asus EeeBook X205 Series Laptop](#)
210. [AU Genuine ASUS B31N1342 Battery For Chromebook C200 C200MA Laptop](#)
211. [AU ASUS B31N1407 Battery For B451 B451JA B451JA-1A Laptop](#)
212. [AU ASUS C11N1312 Battery Rating 3.75V 4920mAh 19Wh](#)
213. [AU ASUS C11P1328 Battery Rating 3.7V 5135mAh 19Wh](#)
214. [AU ASUS C12N1343 Battery 3.85V 31Wh](#)
215. [AU ASUS C21N1326 Battery 7.5V 38Wh For computer](#)
216. [AU ASUS C21N1421 Battery 0B200-01520000 38Wh 7.6V](#)
217. [AU ASUS C21N1515 Battery 7.6V 38Wh For R753 X756 Series](#)
218. [AU ASUS C21-P1801 Battery For Transformer AIO P1801 Series](#)

219. [AU ASUS C31N1318 Battery For ROG PU301 Series 44Wh](#)
220. [AU ASUS C31N1324 C31N1324 Battery For Laptop 11.1v 44wh](#)
221. [AU ASUS C31N1512 Battery Rating 11.55V 3790mAh](#)
222. [AU ASUS C32N1415 Battery For UX501JW Laptop](#)
223. [AU ASUS C41N1416 Battery For ZenBook Pro UX501 N501 Series](#)
224. [AU ASUS C21O1412 C21O1412 Battery 33Wh 7.54V](#)
225. [AU ASUS C31N1431 Laptop Battery for EeeBook E403SA Tablet](#)
226. [AU Genuine C41-TAICHI31 Battery for Asus TAICHI 31 Laptop](#)
227. [AU New Asus T100H T100HA Tablet Battery C12N1435 3.8V 30Wh](#)
228. [AU Genuine ASUS C21N1430 ChromeBook C201P C201PA Laptop Battery](#)
229. [AU Genuine Asus C21-TX300D TransformerBook TX300CA Laptop Battery](#)
230. [AU ASUS A41N1501 Battery For GL752 N552VX Series Laptop 48wh](#)
231. [AU ASUS C21N1509 Battery For X556 Series Laptop](#)
232. [AU ASUS B31N1507 Laptop Battery 11.4V 48WH](#)
233. [AU New Asus A46C S56 S46 K46 K56 S405 OEM PC Battery A41-K56 4Cells](#)
234. [AU ASUS A32-N55 N45 N45E N55 N55E N55S N75 Laptop Battery](#)
235. [AU ASUS C31N1339 ZenBook U303L UX303 UX303LN UX303L Q302L Battery](#)
236. [AU C21N1401 Battery For ASUS X455 F455L X455LA Laptop Battery](#)
237. [AU ASUS A31N1519 X540S X540L X540LA-SI302 X540S Laptop Battery](#)
238. [AU New A42-UL30 A42-UL50 Replacement Battery for ASUS UL30 UL50 UL80 Series Laptop 8Cells](#)
239. [AU New Asus P31 P31F Replace Laptop Battery A32-U31 A42-U31 8cells](#)
240. [AU Genuine 2600mah Battery For Asus A43 A54 A83 K43 X43 K53 X53E P54 x54 x84 A32-K53 A42-K53](#)
241. [AU ASUS B31N1336 R553L R553LN S551LN-1A Laptop Battery 11.4V 48Wh](#)
242. [AU battery for 0mAh ASUS UX32K, U13S881, U33X,](#)
243. [AU A32-F5 Replacement Battery For ASUS F5 F5N F5R X50R X50 Laptop](#)
244. [AU Genuine ASUS A42-G55 Battery For G55V, G55VM, G55VW Series Laptop](#)
245. [AU Original Asus A34-W90 battery for asus W90 W90V W90VN Series Laptop](#)
246. [AU New Asus A32-K55 K55 K45 A45 K45VG K45VM Replacement Laptop Battery](#)
247. [AU New A32-K55 A41-K55 Replacement Battery For Asus K45 K55A-SX071 K55DE K75 Laptop](#)
248. [AU New A32-K72 Replacement Battery For Asus Asus K72 K72D A72 K73 Laptop](#)
249. [AU New A32-1015 Replacement Battery For Asus Eee PC 1011P Laptop](#)
250. [AU New A32-A8 Replacement Battery For Asus A8E A8F X80 Series Laptop](#)
251. [AU New Asus K52JB K42D A32-K52 A42-K52 Replace Laptop Battery](#)
252. [AU A41-U46 A42-U46 Replacement Battery for Asus U46JC U46JC U46S Series Laptop](#)
253. [AU New A41-X550A Asus X550A X550B X550V Laptop Replace Battery](#)
254. [AU battery for 5400mAh ASUS GS70-2PE781, gs70 2pu 009au,](#)
255. [AU Genuine C32-TAICHI21 35Wh Battery For Asus TAICHI 21 Ultrabook](#)
256. [AU New Genuine C41-N541 N54PNC3 8cell Battery for ASUS Q501L Q501LA Q501LA-BBI5T03 Series Laptop](#)
257. [AU New A42-G73 G73-52 8cells Replacement Battery For Asus G73 G73G G73GW G73S Series](#)
258. [AU New A42-G75 Battery For Asus G75 G75V G75V 3D G75VM Laptop](#)
259. [AU Genuine C11P1303 Battery For ASUS GOOGLE NEXUS 7 2RD II ME571 ME571K](#)

ME571KL Tablet

- 260. [AU New Genuine A32N1331 A33N1332 87Wh Battery For Asus E451 E551 PRO450 PU551JH Series Laptop](#)
- 261. [AU New Genuine A42N1403 A42LM93 Battery For Asus ROG G751J GFX71J Laptop](#)
- 262. [AU Genuine C22-EP121 C22EP121 Battery for Asus Eee Pad Slate EP121 B121 B121-1A001 Tablet](#)
- 263. [AU New Genuine A32-K55 Laptop Battery For Asus K55A-SX071 Series](#)
- 264. [AU New A32-U47 A41-U47 Battery For ASUS U47 U47A U47C U47V U47VC Laptop](#)
- 265. [AU New ASUS A42-G750 A42G750 Battery For Asus G750 G750JH G750JM Laptop](#)
- 266. [AU New A42-G55 Battery For Asus G55 G55V G55VM G55VW Series Laptop](#)
- 267. [AU New Asus AL21-B204 Battery for Asus Eee Box B204 Laptop](#)
- 268. [AU New Asus U47A U47C U47V U47VC A32-U47 Replacement PC Battery](#)
- 269. [AU New Genuine A32-N1405 For ASUS N551J N751 G771 GL551 LG771 Laptop](#)
- 270. [AU New A32-M50 A33-M50 Replacement Battery for Asus M50Q M50Sa G50VT Laptop](#)
- 271. [AU New A32-F80 A32-F80A Replacement Battery for Asus F50 F50Gx F50Q F50sv-x1 Laptop](#)
- 272. [AU New A42-K53 A32-K53 Replacement Battery For Asus K53B K53BY K53E K53F Laptop](#)
- 273. [AU A31-U24 A32-U24 battery for asus U24 U24A U24E Series Laptop](#)
- 274. [AU New A33-M50 A32-N61 Replacement Battery for Asus M50 M50Sr M50Sv M51E Laptop](#)
- 275. [AU New A32-F80 A32-F80A Replacement Battery For Asus F80 F80A F80Q F50 F50S Series Laptop](#)
- 276. [AU New C23-UX31 C22-UX31 Replacement Battery For Asus ZENBOOK UX31 UX31E UX31E-DH72 Laptop](#)
- 277. [AU Replacement A32-F80 A32-F80A Laptop Battery For ASUS X61 X80 X82 X85 series](#)
- 278. [AU ASUS A31-U1 Battery for A32-U1 A32-U2 A32-U3 U1 series](#)
- 279. [AU Replacement C23-UX21 Battery for ASUS Zenbook UX21 UX21E Series 35Wh](#)
- 280. [AU Brand New Replace Battery A31-N56 A32-N56 For Asus N46 N46V N56 N56D N76 N76V Series Laptop](#)
- 281. [AU Genuine Asus C11O1314 Table battery for Memo Pad Me102 19Wh 5000mah](#)
- 282. [AU Genuine A31N1319 A41N1308 Battery For ASUS X451C, X451CA, X551C, X551CA](#)
- 283. [AU New Genuine Battery A31-U1 A32-U1 for Asus U1 U1F U1E U2 U2E N10 U3 U3S Series Laptop 3-Cell](#)
- 284. [AU New Genuine Battery for Asus UL30VT-X1K UL50Vt-A1 UL80Vt A42-UL30 A42-UL50 A42-UL80 14.8V 5200mah](#)
- 285. [AU Genuine A31N1319 Battery For Asus X451C X451CA X551C X551CA Laptop 10.8V 33WH](#)
- 286. [AU battery for 2200mAh ASUS SQU-908.](#)
- 287. [AU Asus A42-UL50 UL30 UL50 UL80 Replacement Laptop Battery 14.4V](#)
- 288. [AU Genuine C11P1327 battery for ASUS ASUS FONEPAD 7 K012 WiFi+3G Tablets PC](#)
- 289. [AU C21N1333 laptop battery for ASUS X454 series 7.6V 38Wh](#)
- 290. [AU battery for ASUS laptop C32N1305 C32N1305 11.1V 50Wh](#)
- 291. [AU Genuine C41-UX52 battery for ASUS ZenBook UX52 UX52A UX52V UX52VS 14.8V 53Wh](#)
- 292. [AU Genuine ASUS Eee Top ET16-BT1 ET1603 7.4V 1400mah battery](#)
- 293. [AU Genuine A31N1311 A31N1311 battery for ASUS X102B F102BA X102BA laptop 11.25V 33Wh](#)
- 294. [AU Replacement A31-JN101 battery for ASUS laptop 10.8V 2600mah,28Wh](#)

295. [AU Genuine C11-ME301T battery for Asus MeMo Pad 10 Smart ME301T tablet PC](#)
296. [AU Genuine C12-P1801 battery for Asus Transformer AiO P1801](#)
297. [AU Genuine ASUS C21-TF600TD TF600TD battery 7.4V 2980mAh 22WH](#)
298. [AU Genuine Asus VivoTab TF810C Tablet PC C12-TF810C 30Wh Battery](#)
299. [AU Genuine C42-UX51 battery Asus Zenbook UX51 UX51VZ U500VZ laptop 14.8V 70Wh](#)
300. [AU C31-UX30 battery for ASUS UX30 UX30-A1 UX30-QX005C UX30-QX015C UX30-QX011E UX30-QX007E UX30S series](#)
301. [AU Genuine A41-K56 battery for ASUS K46 S56 S46CM S505 S505C E46CA laptop 15V](#)
302. [AU B21N1329 laptop battery for ASUS X553M X553MA X453](#)
303. [AU Genuine C21N1347 battery for ASUS X555 X555LA X555LD X555LN Laptop 7.6V 38WH](#)
304. [AU Genuine C11P1304 battery for Asus MemoPad Memo Pad ME173X](#)
305. [AU C12N1320 battery for ASUS Transformer Book T100T T101TA Tablet 3.8V 31WH](#)
306. [AU Genuine ASUS N750JV N750JK N750Y47JV-SL C32-N750 Laptop Battery](#)
307. [AU Genuine A42-G75 battery for ASUS G75 G75V G75VM G75VW 3D G75VX Series 14.4V](#)
308. [AU Genuine ASUS A42-G750 G750JH G750JS G750JZ battery 15V 88Wh](#)
309. [AU Laptop Battery for ASUS C31-S551 S551 11.1v 50Wh](#)
310. [AU C21N1309 Battery for ASUS Q301L Laptop 38WH](#)
311. [AU Genuine C31-X502 X502 Battery for ASUS V500C 11.1V 44WH 4000mAh B200-00320200M](#)
312. [AU Genuine C22-UX42 UX42 Battery for ASUS ULTRABOOK UX42E3517VS-SL 45WH](#)
313. [AU C22-B400A B400A Battery for ASUS PRO BU400 BU400V BU400A i5-3317u ULTRABOOK](#)
314. [AU C12-TF600T Tablet Replacement Battery for ASUS VIVO TAB TF600T WINDOWS PACK](#)
315. [AU C12-P05 Battery for ASUS Laptop 3.8V 6320MAH 24WH](#)
316. [AU ASUS Li-Polymer Battery Pack C11-P03 3.8V 19WH Battery](#)
317. [AU C21-TF301 Battery For ASUS Transformer Pad TF700T TF700 Series 7.4V 3380mAh 25Wh](#)
318. [AU Genuine C21-TF201XD TF201XD Battery for ASUS Notebook 16Wh](#)
319. [AU Genuine C32-G46 Battery For ASUS G46 G46V G46VW G46E G46EI363VM G46EI361VW 69Wh](#)
320. [AU New Replacement Battery A32-K93 A42-K93 for ASUS K93 K93S K93SM K93SV Series laptop 5200mah](#)
321. [AU Genuine A42-U36 battery for ASUS U40S U40SD U44 U82U U32U U36J series laptop 14.4V 44WH](#)
322. [AU Genuine A41-X550A X550A Battery for ASUS X550B F550C X550D X550 X450C X450 X550V 15V](#)
323. [AU Genuine C21-X502 X502 battery for ASUS X502 X502C X502CA series laptop 38wh](#)
324. [AU Genuine C23-UX32 Battery for ASUS VivoBook U38N Zenbook UX32 UX32VD UX32A](#)
325. [AU Genuine Asus A41N1308 A31LJ91 Battery For X451C X451CA X551C X551CA Series 37WH](#)
326. [AU Genuine A41-X550E 15V 44Wh Battery For ASUS K550E X450 X450J A450 Series](#)
327. [AU Genuine ASUS Google NEXUS 7 tablet Battery ME370TG C11-ME370TG](#)
328. [AU Genuine ASUS Eee Pad TF201 TF300 C21-TF201X TF201-1B002A TF201-1I076A TF201-1B04 TF201-B1-CG battery](#)
329. [AU White ASUS A32-A8 70-NF51B1000 90-NF51B1000 A8 A8000 F8 X80 Z99 Series Battery](#)
330. [AU Genuine A31N1302 A3INI302 A3INI302 battery for ASUS R202CA F200CA X200CA X200MA Laptop](#)

331. [AU A31-K53 A32-K53 A42-K53 Battery For ASUS K43JC K53U K43S K43S X43BY Series 7800mAh](#)
332. [AU A31-X401 A32-X401 A42-X401 Replacement Battery for ASUS X301 X401 X401A X401U X501A X501U](#)
333. [AU New Genuine Asus A31-N56 A32-N56 Battery for ASUS N46 N46V N46VJ N46VM N46VZ N56 N56D N56DP N56V N56VJ N76VZ Series Laptop](#)
334. [AU A31-U24 A32-U24 battery for ASUS U24 U24A U24E Series](#)
335. [AU Genuine ASUS X550 A41-X550 A41-X550A battery for ASUS X550C X550B X550V X550D X450C X450 X452 Battery 14.4V 37WH](#)
336. [AU Genuine C41-N550 Battery for ASUS N550J N550X47JV N550X47JV-S NJ550JV Laptop](#)
337. [AU ASUS EA-800/EA-800L Battery F103400024 For EA-800 Eee Note](#)
338. [AU Genuine ASUS X402 C31-X402 battery for ASUS VivoBook S300 S300C S300E S300CA S400 S400C S400E S400CA 44WH](#)
339. [AU Genuine A32-U47 A41-U47 A42-U47 Battery for ASUS U47 Series U47A U47C U47V U47VC Series 10.8V 56Wh 5200mah](#)
340. [AU X202 C21-X202 C21X202 S200L987E Battery for ASUS VivoBook S200E X201E X202E](#)
341. [AU Genuine ASUS C22-UX31 C23-UX31 UX31 battery for ASUS Zenbook UX31 UX31A UX31E 50Wh](#)
342. [AU Genuine ASUS Zenbook C23-UX21 UX21 battery for ASUS Zenbook UX21 UX21E Series 35Wh](#)
343. [AU Brand New AP22-T101MT Battery For Asus EEE PC T101 T101MT Series Laptop 4900mah](#)
344. [AU ASUS C21-X402 battery for VivoBook series, 38Wh](#)
345. [AU Genuine C11-ME172V 5559 Battery For ASUS MEMO PAD 7 inch ME371MG ME371](#)
346. [AU Genuine ASUS C11-EP71 3.7V 16wh battery For Eee Pad MeMo EP71 N71PNG3](#)
347. [AU Original ASUS C11-TF400CD battery 3.75V 5070mah 19WH](#)
348. [AU Genuine C11-TF500TD TF500TD battery for ASUS Transformer Pad TF500](#)
349. [AU ASUS A42-U32,A32-U31 Laptop Battery,10.8V, 4400ma, 6cellsh](#)
350. [AU New A32-U31 A42-U31 Battery For ASUS U31E U31F U31J U31JC U31JG Series Laptop](#)
351. [AU Replacement ASUS G74 laptop battery for asus G74J G74S G74SX G74SW G74JH Series, 5200mah, 8cells](#)
352. [AU ASUS A32-1025,A31-1025 for 1025C Series laptop battery, 5200mah, 6cells](#)
353. [AU Genuine C11-ME370T ME370T Battery for ASUS GOOGLE NEXUS 7 Tablet 3.7V 4325mAh](#)
354. [AU Genuine C21-TF201D Battery For ASUS Eee Pad TF201 Series Laptop 2940mAh](#)
355. [AU Genuine A32-C90 Battery For Asus C90a C90A C90P C90S Series Laptop 4800MAH](#)
356. [AU A32-K72 A32-N71 Battery for ASUS A72 A73 X73S K72 K73 N71 N73 Series laptop 6600mah](#)
357. [AU AP22-100, Asus 870AAQ159571, A22-901 for Asus Eee Pc 1000 Series laptop battery, Black, 6600mah, 7.4v](#)
358. [AU Asus W1 A42-W190-N901B1000 for Asus W1000 Series laptop battery, Black, 14.8V 4400mah](#)
359. [AU Genuine A32-F80 A32-F80A F80A Battery For Asus F50 F80 F80S F81 X61 X80 X82 Series laptop White](#)
360. [AU Genuine EP102 C31-EP102 Battery For ASUS Eee Pad Slider EP102 Laptop 2260mah 11.1V 3cells](#)
361. [AU Genuine ASUS A42-U46 4INR18/65-2 For U46 Series Laptop Battery Black 15V 2950mah 4](#)

Cells

- 362. [AU ASUS AP22-1000,AP23-901,Asus Eee PC 901 Series Laptop Battery 6 Cell](#)
- 363. [AU ASUS A42-M70 L0690LC M70 Series Laptop Battery 6 Cells](#)
- 364. [AU ASUS A42-A2,90-N7V1B1200,A254OH series,A2000 series Laptop Battery 2400MAH](#)
- 365. [AU ASUS C21-EP101 Eee Pad Transformer TF101 Series Laptop Battery Black](#)
- 366. [AU ASUS AP31-1008HA,AP32-1008HA,EEE PC 1008HA Series Laptop Battery](#)
- 367. [AU battery for 3260mAh ASUS BT.00307.034, AP11B7H, AP11B3F, BT.00303.024,](#)
- 368. [AU ASUS A33-U6,A32-U6,Asus U6S,Asus N20 Series Laptop Battery 4 Cell](#)
- 369. [AU Laptop Battery AP21-1002HA For ASUS Eee PC S101H, S101H-BLK042X, S101H-BRN043X White](#)
- 370. [AU ASUS A32-U5,70-NE62B3000,U5 Series Laptop Battery 4800MAH](#)
- 371. [AU A33-Z97 A32-Z84 A32-Z62 Battery for ASUS S62 S62EP S62H Z62 Z62E Z62H Z84 Z84F Z94L Z96 Z96S Z97](#)
- 372. [AU ASUS A32-N82,A42-N82,ASUS A40J Series, ASUS A42 Series Laptop Battery](#)
- 373. [AU A31-1015 ASUS A32-1015 AL31-1015 Battery for ASUS Eee PC 1015P 1015PE 1016 1016P 1215 1016](#)
- 374. [AU ASUS PL32-1015 A32-1015 EEE PC 1015PED N4551015 1015PN Series Replacement Laptop Battery](#)
- 375. [AU 2400mAh ASUS S5NBTB1A, 0-N8V1B3100, 70-NHA2B3000, M5200A laptop battery, sliver](#)
- 376. [AU A32-K93 A42-K93 Laptop battery for ASUS K93 Series 4700mAh](#)
- 377. [AU Genuine A42-G74 battery for ASUS G74J G74S-XR1 G74SW G74SX-TY151V G74SX G74 Laptop LC42SD128](#)
- 378. [AU ASUS A42-K53 A32-K53 ASUS A43 A53 Series Laptop Battery 6 Cell](#)
- 379. [AU ASUS A31-1025,A32-1025,1025 Series,1025C Series Laptop Battery 2600MAH](#)
- 380. [AU A31-1025 A32-1025 Battery for ASUS EEE PC 1025 1025C 1025CE 1025](#)
- 381. [AU ASUS S8-PW-BP001,16NG027237,S8 Series Laptop Battery Grey](#)
- 382. [AU 7200mah A32-N50 A33-N50 Battery for Asus N50 N51 N51S N51TP N51V Series laptop](#)
- 383. [AU A32-F9 A31-F9 Battery For Asus F6 F6A F6E F6H F6K F9 Series Laptop 9cells Black](#)
- 384. [AU ASUS A31-B53 A41-B53 Battery for ASUS B53 B53S B53F B53f-a1b B53f-so042x B53J B53j-a1b B53j-b1b B53j-so042x Series](#)
- 385. [AU ASUS N45 N45E N45F N45J N45S N45S A32-N55 N55 Genuine Battery](#)
- 386. [AU ASUS A31-B43 For B43E,B43 series,11.1V 4400MAH Laptop Battery](#)
- 387. [AU ASUS A31-X101 A32-X101 battery for Asus Eee Pc X101 X101 X101C X101CH X101H Series](#)
- 388. [AU A32-X101 A31-X101 Battery for ASUS Eee PC X101 Series laptop white](#)
- 389. [AU ASUS N45 N45E N55 N55E N55S N75 A32-N55 Replace Laptop Battery](#)
- 390. [AU ASUS A42-L5,90-N7P1B1100,Asus L5 Series,Asus L55 Series Laptop Battery 4400AH 14.8V](#)
- 391. [AU ASUS A42-L5,90-N7P1B1100,Asus L5 Series,Asus L55 Series Laptop Battery 4400AH 14.8V](#)
- 392. [AU ASUS A32-S5,A32-W5F,M5 Series,Laptop Battery 4400AH 11.1V Black](#)
- 393. [AU ASUS A32-S5 A32-W5F M5 Series Laptop Battery 4400AH 11.1V Silver](#)
- 394. [AU Asus C22-R2, R2HP9A6 laptop battery for asus R2 Series, R2E, R2H, R2Hv laptop](#)
- 395. [AU New A32-U6 OEM battery For Asus U6 Laptop](#)
- 396. [AU New A42-U46 Battery for Asus U56E U56J U56JC U56S U56SV Laptop](#)

397. [AU ASUS A32-Z96 10.8V 5200mah Laptop Battery](#)
398. [AU Asus A42-U53, U43 U52 U53 Series Battery 4-Cell](#)
399. [AU Original A32-N82 A42-N82 Battery for asus N82E N82EI N82J N82JQ series laptop](#)
400. [AU Asus A32-F70 L0690LC Battery 10.8V 6-Cell](#)
401. [AU Asus A32-U80 U50 U30 U80 Replacement Battery 11.1V](#)
402. [AU Genuine A42-U53 A41-U53 A32-U53 Battery For Asus U43 U52 U53 Series Laptop 8-Cell](#)
403. [AU C22-1018 Battery For Asus Eee PC 1018 1018PB 1018PED Series](#)
404. [AU Genuine A32-N70 A32-F70 A32-M70 A42-M70 Battery For ASUS F70 G71 M70 N70 Series Laptop](#)
405. [AU battery for 7200mAh ASUS L072056, A33-H17, A32-H17,](#)
406. [AU New Asus F82 F82Q F52 A32-F52 A32-F82 Replace Laptop Battery](#)
407. [AU A32-M9 A33-M9 A32-W7 A33-W7 Battery For Asus M9 M9F W7 W7FJ Series Laptop 6600mAh 9-Cell](#)
408. [AU Asus A32-P30 L0790C6 P30 P30A P30G P30AG Series Laptop Battery 6-Cell](#)
409. [AU Genuine A42-G70 G70L821 Battery for ASUS G70 G70s G70SG Series Laptop](#)
410. [AU Replacement Asus A32-N50 N50VN N50 Series Battery 11.1V 6-Cell](#)
411. [AU ASUS C41-UX50 POAC001 battery for Asus UX50 UX50v UX50V-RX05 ux50v-xx004c](#)
412. [AU Asus A42-G73, G73JH, G73JH-A1, G73JH-A2, G73JH-X1, G73 Series Laptop Battery](#)
413. [AU Original ASUS A32-K72 Battery for X73 X73S N73J K72JK K72JR K72DR K72F K72J K72JA K72JB 70-NZYB1000Z Laptop](#)
414. [AU A33-M50 A32-M50 Battery for ASUS N53S G50V G50 G50VT-X5 G51 G51J-A1 M60J N53JF-a1 Series](#)
415. [AU Asus A42-UL50, A42-UL30, A42-UL80, UL30, UL50, UL80 Replacement Laptop Battery 12-Cell](#)
416. [AU Asus AP31-1008P, AP32-1008P, Eee PC 1008P Replacement Laptop Battery](#)
417. [AU Asus A31-1015, A32-1015, EEE PC 1015, EEE PC 1016, EEE PC 1215 Replacement Laptop Battery](#)
418. [AU Asus A32-1015 Genuine Battery for ASUS EEE PC 1015 EEE PC 1015P EEE PC 1016 EEE PC 1215 Laptop](#)
419. [AU Asus A33-U6 A32-U6 U6S U6Sg U6Vc Replacement Laptop Battery](#)
420. [AU Asus A42-A2, A2, A2D, A2G, A2H, A2000, A2000H, 90-N7V1B1000, 90-N7V1B1200 Replacement Laptop Battery 4400mAh 8 Cell](#)
421. [AU Asus A32-Z94, Z53 Z94 Z96 Series Battery 12-Cell](#)
422. [AU Asus AL32-1005 Eee PC 1005HA Replacement Laptop Battery 9 Cell](#)
423. [AU Asus AL32-1005 Eee PC 1005 Eee PC 1005H Eee PC 1005HA Replacement Laptop Battery 9 Cell White](#)
424. [AU Asus A32-N61, N61J, N61Ja, N61Vn, N61w, N61Vg, N61Jv, N61 Series Battery](#)
425. [AU ASUS N82 N82E N82EI N82J N82JQ A42-N82 A32-N82 Battery 14.4V](#)
426. [AU Asus A32-M9 A32-W7 battery for M9A M9F M9J M9V W7S W7Sg W7 Series Laptop](#)
427. [AU Asus A32-M9 M9A M9F M9J M9V W7S W7Sg W7 Series Laptop Battery](#)
428. [AU New ASUS A32-U6 Battery For U6S U6Sg U6Vc Series Laptop 4400Mah 11.1V](#)
429. [AU Asus A42-A6, 70-NA51B1100, 90-NA51B2200, 90-NA52B2000, A42-A3, A3 A6 A7 G1 Z9100 Series Replacement Laptop Battery](#)
430. [AU Asus C22-R2, R2HP9A6, 70-NGV1B3000M-00A2B-707-0347, R2H R2 Series Battery 7.4V](#)
431. [AU Asus A32-T14, Haier A32-T14 T68 Replacement Laptop Battery](#)
432. [AU Asus A42-A4, 70-N9X1B1000, 90-N9X1B1000, A4G, A4K, A4S, A4000 Replacement](#)

Laptop Battery

- 433. [AU New Asus A31-K52 A32-K52 A41-K52 Series Battery for Asus K52JB K52JC K52JE K52JK Laptop 10.8V 6 Cells](#)
- 434. [AU Asus A42-V6, 70-NAA1B1000, 90-NAA1B1000 Laptop Battery](#)
- 435. [AU Genuine A32-UL20 A31-UL20 A33-UL20 Battery For Asus Eee PC 1201HA 1201N 1201PN 1201T Series](#)
- 436. [AU Asus A33-Z96, Z96, A9 Series Battery](#)
- 437. [AU New Asus A42-UL50, UL30A, UL80VT Laptop Battery 15V 5600mAh](#)
- 438. [AU Asus A32-UL20, UL20A, UL20G, UL20VT, Eee PC 1201N Battery 63WH 11.25V](#)
- 439. [AU Asus A32-Z37, A33-Z37, Z37, Z37K, Z37E, Z37S Series Battery](#)
- 440. [AU A32-F80 A32-F80A Battery For ASUS F80 F80A F80S F80H X61 X85 Series Laptop 49WH Li-ion](#)
- 441. [AU battery for 4800mAh ASUS SQU-605, SQU-503, SQU-528, SQU-424,](#)
- 442. [AU Genuine New A32-F82 A32-F52 Battery for ASUS A32 F82 F52 k50IJ k50 K51 k50ab k40in k50id k50ij K40 K42 k42j k50in k60 K60I k61 k70](#)
- 443. [AU battery for 3920mAh ASUS TravelMate 636XC, TravelMate 636LV, TravelMate 636XVi, TravelMate 636LC,](#)
- 444. [AU Asus A32-F3 Battery A32-Z96 SQU-528 For S96 Z94 series 4400mah 6cells](#)
- 445. [AU Asus BATEL80L9, A9, F3 F2 A9T Z53 Series Replacement Laptop Battery 9-Cell](#)
- 446. [AU AP21-1002HA Battery For ASUS EEE PC 1002 1002HA Series Laptop](#)
- 447. [AU Asus A32-F9 F9 F9Dc F9E F9F F9J F9S series Battery 11.1V 6-Cell](#)
- 448. [AU Asus A42-M70 M70V X71 G71 X72 N70SV Series Battery](#)
- 449. [AU ASUS A31-1005 A32-1005 AL31-1005 Replacement Battery For ASUS Eee PC 1001HA 1101HA 1001 1005 1005H 1005P Series](#)
- 450. [AU Asus Eee PC 1005HA Laptop Battery AL32-1005 AL31-1005 PL32-1005 White](#)
- 451. [AU Asus A42-V6, 70-NAA1B1000, 70-NFB1B1000, 90-NAA1B1000, 90-NFB1B1000, V6, V6V, V6000, V6000V Series Battery](#)
- 452. [AU Asus A32-U6, U6S, U6Sg, U6Vc Replacement Laptop Battery 4400mAh](#)
- 453. [AU Asus A32-M50 90-NED1B2100Y M50 M50Sa M51Se N53SV M51Va M70Sa Battery 4800mAh](#)
- 454. [AU 70-NLF1B2000 70-NLF1B2000Y 70-NLF1B2000Z A32-F5 Battery For ASUS F5 F5N F5R X50R X50 Series Laptop](#)
- 455. [AU Asus Eee PC 901 PC 904 PC 1000 Series AL23-901 Replacement Laptop Battery 6600mAh](#)
- 456. [AU A22-700 A22-P701 A22-P701H Battery for ASUS Eee PC 700 701 Eee PC 900 Series 2G 4G 8G Replacement Laptop Battery 4400mAh](#)
- 457. [AU Asus 90-OA001B1100, Eee PC 700, Eee PC 900 Series Eee PC 2G, Eee PC 4G Surf Replacement Laptop Battery 6600mAh](#)
- 458. [AU Asus A32-A8 70-NF51B1000 90-NF51B1000 A8 A8000 X80 Z99 Series Battery](#)
- 459. [AU Asus A32-F3 Replacement Laptop Battery 90-NI11B1000 90-NIA1B1000 for Asus F2 F3 M50 M51 Z53 Series](#)
- 460. [AU Asus A32-X51 A32-T12 90-NQK1B1000Y, T12 T12C X51H X51L Replacement Laptop Battery](#)

ASUS Notebook Batteries List By Battery Model

[#5559](#), [0-N8V1B3100](#), [07G016000520](#), [07G016003555](#), [07G016005462](#), [07G016031866](#),
[07G0160U1875](#), [07G016121875](#), [07G016131875](#), [07G0161K1875](#), [07G016201866](#), [07G016211866](#),
[07G016231866](#), [07G0162B1875](#), [07G016301875](#), [07G0163S1875](#), [07G016421875](#), [07G016441875](#),
[07G016451875](#), [07G0164F1875](#), [07G0164J1875](#), [07G0164P1875](#), [07G0164U1875](#), [07G0164V1875](#),
[07G0164W1875](#), [07G016501875](#), [07G0165A1875](#), [07G0165U1875](#), [07G0166M1875](#), [07G016761875](#),
[07G0167D1875](#), [07G0167Q1875](#), [07G0168S1875](#), [07G016921875](#), [07G016951875](#), [07G016971875](#),
[07G016971875-BTI](#), [07G016971875BTI](#), [07G016981875](#), [07G0169F1875](#), [07G0169K1875](#),
[07G016AB1875](#), [07G016AB1875-BTI](#), [07G016AP1875](#), [07G016AQ1875](#), [07G016B11866](#),
[07G016B21866](#), [07G016BE1875](#), [07G016BF1875](#), [07G016BH1875](#), [07G016BJ1875](#), [07G016BK1875](#),
[07G016BL1875](#), [07G016BN1875](#), [07G016BP1875](#), [07G016BQ1875](#), [07G016BR1875](#), [07G016BS1875](#),
[07G016BT1875](#), [07G016BV1875](#), [07G016BW1875](#), [07G016BZ1875](#), [07G016C11875](#), [07G016C21875](#),
[07G016C51875](#), [07G016CD1875](#), [07G016CF1875](#), [07G016CL1875](#), [07G016CM1875](#), [07G016CN1875](#),
[07G016CS1875](#), [07G016CX1875](#), [07G016D01875](#), [07G016DH1875](#), [07G016DQ1875](#), [07G016DU1875](#),
[07G016E61875](#), [07G016EG1875](#), [07G016EH1875](#), [07G016EJ1875](#), [07G016EK1875](#), [07G016EM1875](#),
[07G016ES1875](#), [07G016ET1875](#), [07G016EU1875](#), [07G016F01875](#), [07G016F11875](#), [07G016F21875](#),
[07G016F61875](#), [07G016FM1875](#), [07G016FN1875](#), [07G016FP1875](#), [07G016FQ1875](#), [07G016FS1875](#),
[07G016FT1875](#), [07G016FW1875](#), [07G016FY1875](#), [07G016G01875](#), [07G016G11875](#), [07G016G31875](#),
[07G016G41875](#), [07G016G41875-RFB](#), [07G016G41875RFB](#), [07G016G51875](#), [07G016G91875](#),
[07G016GC1875](#), [07G016GE1875](#), [07G016GN1875](#), [07G016GQ1875M](#), [07G016H31875](#),
[07G016H71875M](#), [07G016HE1875](#), [07G016HF1875](#), [07G016HG1875](#), [07G016HK1875](#),
[07G016HN1875](#), [07G016HY1875](#), [07G016J01875](#), [07G016J71875](#), [07G016J91875](#), [07G016JD1875](#),
[07G016JE1875](#), [07G016JG1875](#), [07G016LQ1865](#), [07G016NI1865](#), [07G016QG1865](#), [07G016R11865](#),
[07G016R9186A](#), [07G016RR1865](#), [07G016WQ1865](#), [07G016X11865](#), [07G016X51865](#), [07G016X91865](#),
[07G016XW1865](#), [07G016Y0186A](#), [07G016Y2186A](#), [07G016YF1865](#), [07G031002000](#), [07G031002101](#),
[07G031002700](#), [07G031002901](#), [07G031002902](#), [07G031002903](#), [07G016003555M](#), [0B110-00050400](#),
[0B110-00050500](#), [0B110-00050600](#), [0B110-00050700](#), [0B110-00050800](#), [0B110-00050900](#),
[0B110-00051000](#), [0B110-00051100](#), [0B110-00060000](#), [0B110-00060200](#), [0B110-00070000](#),
[0B110-00100000](#), [0B110-00130000](#), [0B110-00140000](#), [0B110-00180000](#), [0B110-00180100](#),
[0B110-00180200](#), [0B110-00190300](#), [0B110-00250100](#), [0B110-00250100M](#), [0B110-00250600](#),
[0B110-00250600M](#), [0B110-00250700M](#), [0B110-00250800](#), [0B110-00270000](#), [0B110-00280000](#),
[0B110-00280100](#), [0B110-00280200](#), [0B110-00280300](#), [0B110-00300000](#), [0B110-00320000](#),
[0B110-00320100](#), [0B110-00320200](#), [0B110-00320300](#), [0B110-00320600](#), [0B110-00320700](#),
[0B110-00350000](#), [0B110-00350100](#), [0B110-00360000](#), [0B110-00360100](#), [0B110-00370000](#),
[0B110-00390000](#), [0B110-00390100](#), [0B110-00390200](#), [0B110-00390300](#), [0B110-00420300](#),
[0B110-00440000](#), [0B110-00440100](#), [0B110-00460000](#), [0B110-00470000](#), [0B110-00470100](#),
[0B110-00500000](#), [0B11000050400](#), [0B11000050500](#), [0B11000050600](#), [0B11000050700](#),
[0B11000050800](#), [0B11000050900](#), [0B11000051000](#), [0B11000051100](#), [0B11000060000](#), [0B11000060200](#),
[0B11000070000](#), [0B11000100000](#), [0B11000130000](#), [0B11000180000](#), [0B11000180100](#),
[0B11000180200](#), [0B11000190300](#), [0B11000250600](#), [0B11000250600M](#), [0B11000250700M](#),
[0B11000250800](#), [0B11000270000](#), [0B11000320100](#), [0B11000350000](#), [0B11000350100](#), [0B11000370000](#),
[0B11000420300](#), [0B11000440000](#), [0B11000460000](#), [0B11000470000](#), [0B20-00RL0AS](#),
[0B200-00070200](#), [0B200-00300200M](#), [0B200-00310200](#), [0B200-00420000](#), [0B200-00430100M](#),
[0B200-00470000](#), [0B200-00530100](#), [0B200-00580000](#), [0B200-00600000](#), [0B200-00600100](#),
[0B200-00600200](#), [0B200-00600300M](#), [0B200-00610000](#), [0B200-00620000](#), [0B200-00700000](#),
[0B200-00730200](#), [0B200-00790100](#), [0B200-00810000](#), [0B200-00860300](#), [0B200-00930000](#),
[0B200-00930100](#), [0B200-00930200](#), [0B200-00930300](#), [0B200-00990100](#), [0B200-01000000](#),

[0B200-01000100](#), [0B200-01000200](#), [0B200-01000300](#), [0B200-01000400](#), [0B200-01000500](#),
[0B200-01000700](#), [0B200-01050000](#), [0B200-01050000M](#), [0B200-01060000](#), [0B200-01110000](#),
[0B200-01120100](#), [0B200-01180200](#), [0B200-01200000](#), [0B200-01200100](#), [0B200-01200200](#),
[0B200-01200300](#), [0B200-01200400](#), [0B200-01290000](#), [0B200-01360100](#), [0B200-01400100](#),
[0B200-01400200](#), [0B200-01400700](#), [0B200-01430000](#), [0B200-01430600](#), [0B200-01440000](#),
[0B200-01450100](#), [0B200-01460100](#), [0B200-01490000](#), [0B200-01510100](#), [0B200-01520000](#),
[0B200-01540000](#), [0B200-01550000](#), [0B200-01580000](#), [0B200-01600000](#), [0B200-01740000](#),
[0B200-01750000](#), [0B200-01780000](#), [0B200-01800100](#), [0B200-01880000](#), [0B200-01930000](#),
[0B200-01940100](#), [0B200-01990000](#), [0B200-02010100](#), [0B200-02010200](#), [0B200-02010300](#),
[0B200-02020000](#), [0B200-02030000](#), [0B200-02040000](#), [0B200-02070000](#), [0B200-02070200](#),
[0B200-02070300](#), [0B200-02070400](#), [0B200-02080000](#), [0B200-02090000](#), [0B200-02090100](#),
[0B200-02100100](#), [0B200-02110100](#), [0B200-02110200](#), [0B200-02150000](#), [0B200-02210000](#),
[0B200-02230100](#), [0B200-02280000](#), [0B200-02370000](#), [0B200-02370100](#), [0B200-02370200](#),
[0B200-02380000](#), [0B200-02380100](#), [0B200-02420200](#), [0B200-02460000](#), [0B200-02510200](#),
[0B200-02520000](#), [0B200-02520100](#), [0B200-02710000](#), [0B200-02730100](#), [0B200-02740000](#),
[0B200-02760400](#), [0B200-02770000](#), [0B200-02780000](#), [0B200-02810000](#), [0B200-02830100](#),
[0B200-02850000](#), [0B200-02900000](#), [0B200-02910000](#), [0B200-02960000](#), [0B200-02960400](#),
[0B200-02970000](#), [0B200-02980100](#), [0B200-03020000](#), [0B200-03020200](#), [0B200-03040000](#),
[0B200-03060000](#), [0B200-03070000](#), [0B200-03070100](#), [0B200-03070200](#), [0B200-03080000](#),
[0B200-03120100](#), [0B200-03130000](#), [0B200-03140100](#), [0B200-03150000](#), [0B200-03160000](#),
[0B200-03200000](#), [0B200-03210100](#), [0B200-03220000](#), [0B200-03250000](#), [0B200-03290000](#),
[0B200-03330](#), [0B200-03330100](#), [0B200-03330200](#), [0B200-03340000](#), [0B200-03380100](#),
[0B200-03420200](#), [0B200-03430000](#), [0B200-03470000](#), [0B200-9300000](#), [0B200-9300000M](#),
[0B20000070200](#), [0B20000470000](#), [0B20000530100](#), [0B20000600000](#), [0B20000610000](#), [0B20000620000](#),
[0B20000730200](#), [0B20000790100](#), [0B20000810000](#), [0B20000990100](#), [0B20001110000](#),
[0B20001180200](#), [0B20001360100](#), [0B20001400100](#), [0B20001400200](#), [0B20001430000](#), [0B20001430600](#),
[0B20001450100](#), [0B20001460100](#), [0B20001490000](#), [0B20001510100](#), [0B20001540000](#),
[0B20001550000](#), [0B20001580000](#), [0B20001600000](#), [0B20001740000](#), [0B20001780000](#), [0B20001880000](#),
[0B20001930000](#), [0B20001940100](#), [0B20001990000](#), [0B20002010100](#), [0B20002010200](#),
[0B20002020000](#), [0B20002030000](#), [0B20002040000](#), [0B20002070000](#), [0B20002080000](#), [0B20002090000](#),
[0B20002090100](#), [0B20002100100](#), [0B20002210000](#), [0B20002230100](#), [0B20002460000](#),
[0B20002730100](#), [0B20002830100](#), [0B20002900000](#), [0B20002980100](#), [0B20003020000](#), [0B20003120100](#),
[0B2000RL0AS](#), [0B23-00290J4](#), [0B2300290J4](#), [1001PX-MU20-BK](#), [1001PXMU20BK](#), [1015PX-](#)
[PU17-WT](#), [110-AS002-10-0](#), [110-AS009-10-0](#), [15-100340000](#), [15-100360301](#), [15-10N318300](#),
[15-10N318310](#), [15-10N318320](#), [15-10N318330](#), [150A108](#), [15G10N3475A0](#), [15G10N365100](#),
[15G10N372500P8](#), [15G10N372500PB](#), [15G10N3737B0P8](#), [15G10N373800](#), [15G10N375522](#),
[15G10N3792T0](#), [15G10N3792YO](#), [15G10N381200](#), [16NG027237](#), [1ICP399100](#), [1ICP470133](#),
[21CP4/63/134](#), [21CP4/91/91](#), [21CP49191](#), [261750](#), [261751](#), [2C.201S0.001](#), [2C200ES031](#), [2ICP4/59/134](#),
[2ICP4/63/134](#), [2ICP4/73/110](#), [2ICP5/40/115-2](#), [2ICP7/49/91](#), [2ICP7/54/83](#), [2ICP7/60/80](#), [2ICP7/61/81](#),
[2ICP74991](#), [31CP3/58/137](#), [31CP4/91/91](#), [31CP5/70/81](#), [31CP57081](#), [3869087](#), [3ICP3/96/103](#),
[3ICP3/97/103](#), [3ICP4/74/84](#), [3ICP4/91/91](#), [3ICP5/57/81](#), [3ICP5/58/78](#), [3ICP5/70/81](#), [3ICP5/79/73](#),
[3ICP55878](#), [3ICP66072](#), [3ICP7/60/80](#), [3UR18650F-2-QC-11](#), [405231-001](#), [407672-001](#), [4566195](#),
[4732424](#), [4ICP363115](#), [4ICP4/59/134](#), [4ICP4/72/77](#), [4ICP47275](#), [4ICP5/70/81](#), [4ICP74870](#), [4ICR/1966](#),
[4ICR19/66-2](#), [4ICR19/662](#), [4INR18/65](#), [4INR18/65-2](#), [6-87-M6E6S-454](#), [70-M951B1004](#),
[70-N0N1B2000Z](#), [70-N451B1300](#), [70-N5F1B1000Z](#), [70-N5V1B0101P](#), [70-N651B1001](#), [70-N651B1010](#),
[70-N651B8001](#), [70-N651B8200](#), [70-N6A1B1000](#), [70-N6A1B1100](#), [70-N6B3B1001](#), [70-N6B3B1100](#),

[70-N761B1100](#), [70-N8V1B1100](#), [70-N8V1B2000](#), [70-N8V1B2100](#), [70-N8V1B3100](#), [70-N8V2B2000](#),
[70-N95181005](#), [70-N967B2100M](#), [70-N9Q1B1100](#), [70-N9X1B1000](#), [70-NA12B1000](#), [70-NA12B2000](#),
[70-NA12B3000](#), [70-NA51B1100](#), [70-NA51B2100](#), [70-NAA1B1000](#), [70-NC61B2000](#), [70-NC61B2100](#),
[70-NCB1B1001M](#), [70-NDQ1B2000](#), [70-NE51B2000](#), [70-NE61B2000](#), [70-NE62B3000](#),
[70-NEA1B2000M](#), [70-NEH1B1000Z](#), [70-NEM2B1400Z](#), [70-NEZ1B1000Z](#), [70-NF51B1000](#),
[70-NFA1B100](#), [70-NFB1B1000](#), [70-NFH5B2000M](#), [70-NFH5B2200](#), [70-NFU1B1000Z](#),
[70-NFU1B1100Z](#), [70-NFU1B1300Z](#), [70-NFX2B3000](#), [70-NGA1B1001M](#), [70-NGN3B1000Z](#),
[70-NGN3B1200Z](#), [70-NGV1B3000M-00A2B-707-0347](#), [70-NGV1B4000M](#), [70-NH01B2000](#),
[70-NHA2B1000](#), [70-NHA2B2000](#), [70-NHA2B3000](#), [70-NHM1B1100M](#), [70-NHQ2B1000M](#),
[70-NI51B2000](#), [70-NIQ3B1300](#), [70-NJ01B1100](#), [70-NJ01B2000](#), [70-NJ51B1000Z](#), [70-NK3BB1000Z](#),
[70-NK3BB1200Z](#), [70-NK3BB1300Z](#), [70-NKT1B1000](#), [70-NKT1B1100](#), [70-NL51B1000M](#),
[70-NLF1B2000](#), [70-NLF1B2000Y](#), [70-NLF1B2000Z](#), [70-NLV1B2000](#), [70-NLV1B2000M](#),
[70-NM81B1000PZ](#), [70-NM81B1000Z](#), [70-NM81B1100PZ](#), [70-NM81B1100Z](#), [70-NM81B1200PZ](#),
[70-NM81B1200Z](#), [70-NM81B1300PZ](#), [70-NM81B1300Z](#), [70-NM81B1400PZ](#), [70-NM81B1400Z](#),
[70-NM81B1500PZ](#), [70-NM81B1500Z](#), [70-NM81B1600Z](#), [70-NMF1B1100Z](#), [70-NMF1B2100PZ](#),
[70-NMF1B2100Z](#), [70-NNAA1B1000](#), [70-NNN2B1100PZ](#), [70-NNN2B1100Z](#), [70-NQ91B1000PZ](#),
[70-NQ91B1000Z](#), [70-NQK1B1000Z](#), [70-NQK1B2000PZ](#), [70-NQK1B2000Z](#), [70-NRH1B1000PZ](#),
[70-NRH1B1100Z](#), [70-NRL2B1000Z](#), [70-NS61B2000Z](#), [70-NSQ1B1100PZ](#), [70-NSQ1B1100Z](#),
[70-NSQ1B1200PZ](#), [70-NSQ1B1200Z](#), [70-NT41B1200PZ](#), [70-NTV1B1000PZ](#), [70-NTV1B1000Z](#),
[70-NU51B1000Z](#), [70-NU51B2100PZ](#), [70-NU51B2100Z](#), [70-NUC1B2000PZ](#), [70-NUC1B2000Z](#),
[70-NUP1B2100Z](#), [70-NV41B1100Z](#), [70-NV61B1000Z](#), [70-NV61B1100Z](#), [70-NVA1B1000Z](#),
[70-NVA1B1200Z](#), [70-NVJ1B1000PZ](#), [70-NVJ1B1000Z](#), [70-NVJ1B1100Z](#), [70-NVJ1B1200Z](#),
[70-NVK1B1000PZ](#), [70-NVK1B1000Z](#), [70-NVK1B1100Z](#), [70-NVK1B1200Z](#), [70-NVK1B1400Z](#),
[70-NVK1B1500Z](#), [70-NVM1B1000PZ](#), [70-NVP1B1000PZ](#), [70-NVP1B1000Z](#), [70-NVP1B1200Z](#),
[70-NW91B1000Z](#), [70-NWP1B1000Z](#), [70-NWU1B1000Z](#), [70-NWU1B1100Z](#), [70-NWU1B2000Z](#),
[70-NWU1B2100Z](#), [70-NWU1B3000Z](#), [70-NWU1B3100Z](#), [70-NWU1B4000](#), [70-NX01B1000Z](#),
[70-NX31B1000Z](#), [70-NX31B1100Z](#), [70-NX81B2000Z](#), [70-NX81B3000Z](#), [70-NX81B3100Z](#),
[70-NXH1B1000Z](#), [70-NXI1B1000Z](#), [70-NXJ1B1000Z](#), [70-NXM1B2200Z](#), [70-NXZ1B1000Z](#),
[70-NY81B1000Z](#), [70-NZA5B1000ZA](#), [70-NZA5B6000Z](#), [70-NZC5B5000Z](#), [70-NZL1B3000Z](#),
[70-NZY1B1000Z](#), [70-NZYB1000Z](#), [70-OA011B1000](#), [70-OA011B1000P](#), [70-OA011B1000PZ](#),
[70-OA011B1100P](#), [70-OA011B1100PZ](#), [70-OA011B1200P](#), [70-OA011B1200PZ](#), [70-OA011B1300P](#),
[70-OA011B1400](#), [70-OA011B1400P](#), [70-OA011B1500](#), [70-OA011B1500P](#), [70-OA011B1600](#),
[70-OA011B1600P](#), [70-OA012B1000](#), [70-OA021B1100](#), [70-OA091B1000](#), [70-OA091B2100P](#),
[70-OA091B2200P](#), [70-OA091B2300](#), [70-OA091B2300P](#), [70-OA0A1B1000](#), [70-OA0B1B3000](#),
[70-OA0B1B3100](#), [70-OA0B2B1000](#), [70-OA0B2B1100](#), [70-OA0B2B1100P](#), [70-OA0B2B1200](#),
[70-OA0B2B1300](#), [70-OA0B2B1300P](#), [70-OA0B2B2000](#), [70-OA0B2B3000](#), [70-OA0B2B3000P](#),
[70-OA0B2B3100](#), [70-OA0B2B4000](#), [70-OA0I2B2000](#), [70-OA0I2B3000](#), [70-OA0J1B1000](#),
[70-OA0J2B1000](#), [70-OA111B1000](#), [70-OA1B1B3000](#), [70-OA1B1B3000P](#), [70-OA1B1B3100](#),
[70-OA1B1B3100P](#), [70-OA1B1B3200](#), [70-OA1B1B3200P](#), [70-OA1B1B3300](#), [70-OA1B1B3300P](#),
[70-OA1B1B3400](#), [70-OA1B1B3400P](#), [70-OA1B1B3500](#), [70-OA1B1B3500P](#), [70-OA1B1B4100](#),
[70-OA1B2B1100](#), [70-OA1B2B2100](#), [70-OA1B2B4100](#), [70-OA1G1B1000](#), [70-OA1G1B1100](#),
[70-OA1J1B2000P](#), [70-OA1J1B2100](#), [70-OA1J1B2100P](#), [70-OA1J1B2200](#), [70-OA1J1B2200P](#),
[70-OA1J1B2300](#), [70-OA1J1B2300P](#), [70-OA1L4B2000](#), [70-OA1L4B2000P](#), [70-OA1L4B2100](#),
[70-OA1L4B2100P](#), [70-OA1L4B2200](#), [70-OA1L4B2200P](#), [70-OA282B1000](#), [70-OA282B1200](#),
[70-OA291B1000](#), [70-OA291B1200](#), [70-OA292B1000](#), [70-OA292B1100](#), [70-OA292B1200](#),
[70-OA292B3000](#), [70-OA292B3100](#), [70-OA2B2B2000](#), [70-OA2B2B2100](#), [70-OA2H1B1000](#),

[70-OA2H1B1100](#), [70-OA2H1B1200](#), [70-OA2R2B1000](#), [70N0N1B2000Z](#), [70N967B2100M](#),
[70NC61B2000](#), [70NC61B2100](#), [70NE51B2000](#), [70NE61B2000](#), [70NEH1B1000Z](#), [70NEM2B1400Z](#),
[70NEZ1B1000Z](#), [70NF51B1000](#), [70NGN3B1000Z](#), [70NGN3B1200Z](#), [70NIQ3B1300](#), [70NJ51B1000Z](#),
[70NKT1B1000](#), [70NKT1B1100](#), [70NLV1B2000](#), [70NLV1B2000M](#), [70NM81B1000PZ](#),
[70NM81B1000Z](#), [70NM81B1100PZ](#), [70NM81B1100Z](#), [70NM81B1200PZ](#), [70NM81B1200Z](#),
[70NM81B1300PZ](#), [70NM81B1300Z](#), [70NM81B1400PZ](#), [70NM81B1400Z](#), [70NM81B1500PZ](#),
[70NM81B1500Z](#), [70NM81B1600Z](#), [70NNN2B1100PZ](#), [70NNN2B1100Z](#), [70NQK1B1000Z](#),
[70NQK1B2000PZ](#), [70NQK1B2000Z](#), [70NRH1B1000PZ](#), [70NRH1B1100Z](#), [70NRL2B1000Z](#),
[70NS61B2000Z](#), [70NTV1B1000PZ](#), [70NTV1B1000Z](#), [70NUP1B2100Z](#), [70NV61B1000Z](#),
[70NV61B1100Z](#), [70NVA1B1000Z](#), [70NVA1B1200Z](#), [70NXM1B2200Z](#), [70NZL1B3000Z](#),
[70OA011B1000](#), [70OA011B1000P](#), [70OA011B1000PZ](#), [70OA011B1100P](#), [70OA011B1100PZ](#),
[70OA011B1200P](#), [70OA011B1200PZ](#), [70OA011B1300P](#), [70OA011B1400](#), [70OA011B1400P](#),
[70OA011B1500](#), [70OA011B1500P](#), [70OA011B1600](#), [70OA011B1600P](#), [70OA012B1000](#),
[70OA021B1100](#), [70OA091B1000](#), [70OA091B2100P](#), [70OA091B2200P](#), [70OA091B2300](#),
[70OA091B2300P](#), [70OA0A1B1000](#), [70OA0B1B3000](#), [70OA0B1B3100](#), [70OA0B2B1000](#),
[70OA0B2B1100](#), [70OA0B2B1100P](#), [70OA0B2B1200](#), [70OA0B2B1300](#), [70OA0B2B1300P](#),
[70OA0B2B2000](#), [70OA0B2B3000](#), [70OA0B2B3000P](#), [70OA0B2B3100](#), [70OA0B2B4000](#),
[70OA0I2B3000](#), [70OA0J1B1000](#), [70OA0J2B1000](#), [70OA1B1B3000](#), [70OA1B1B3000P](#),
[70OA1B1B3100](#), [70OA1B1B3100P](#), [70OA1B1B3200](#), [70OA1B1B3200P](#), [70OA1B1B3300](#),
[70OA1B1B3300P](#), [70OA1B1B3400](#), [70OA1B1B3400P](#), [70OA1B1B3500](#), [70OA1B1B3500P](#),
[70OA1B1B4100](#), [70OA1B2B1100](#), [70OA1B2B2100](#), [70OA1B2B4100](#), [70OA1J1B2000P](#),
[70OA1J1B2100](#), [70OA1J1B2100P](#), [70OA1J1B2200](#), [70OA1J1B2200P](#), [70OA1J1B2300](#),
[70OA1J1B2300P](#), [70OA1L4B2000](#), [70OA1L4B2000P](#), [70OA1L4B2100](#), [70OA1L4B2100P](#),
[70OA1L4B2200](#), [70OA1L4B2200P](#), [70OA282B1000](#), [70OA282B1200](#), [70OA291B1000](#),
[70OA291B1200](#), [70OA292B1000](#), [70OA292B1100](#), [70OA292B1200](#), [70OA292B3000](#), [70OA292B3100](#),
[70OA2B2B2000](#), [70OA2B2B2100](#), [70OA2H1B1000](#), [70OA2H1B1100](#), [70OA2H1B1200](#),
[70OA2R2B1000](#), [70R-N5V1B0300](#), [70R-NI11B1000Y](#), [70R-NQK1B1000Y](#), [70RNQK1B1000Y](#),
[7436800000](#), [7441520000](#), [7BOAAQ040493](#), [870AAQ159571](#), [890AAQ566970](#), [9-N181B1000Y](#), [90-NG51B1000](#),
[90-0A1Q2B1000Q](#), [90-441B3100P](#), [90-n011b3000y](#), [90-N10BT1220](#), [90-N181B1000Y](#),
[90-N181B4000Y](#), [90-N1L1B2000Y](#), [90-N2V1B1000Y](#), [90-N3V3B1000Y](#), [90-N40BT1220](#),
[90-N651B1010](#), [90-N7M1B1100](#), [90-N7P1B1100](#), [90-N7V1B1000](#), [90-N7V1B1200](#), [90-N801B1000](#),
[90-N851B1100](#), [90-N851B1210](#), [90-N8A1B2010](#), [90-N8V1B3000](#), [90-N8V1B3100](#), [90-N8V1B4100](#),
[90-N8V1B4200](#), [90-N8V1B5100](#), [90-N901B1000](#), [90-N951B1000](#), [90-N951B1100](#), [90-N951B1200](#),
[90-N998B1200](#), [90-N9Q1B1100](#), [90-N9X1B1000](#), [90-NA11B1000](#), [90-NA11B2000](#), [90-NA11B3000](#),
[90-NA12B1000](#), [90-NA12B2000](#), [90-NA12B3000](#), [90-NA51B1000](#), [90-NA51B2000](#), [90-NA51B2100](#),
[90-NA51B2200](#), [90-NA52B2000](#), [90-NA71B1100](#), [90-NAA1B1000](#), [90-NBR1B1000](#), [90-NBR1B2000](#),
[90-NBR1B3000](#), [90-NBR2B1000](#), [90-NBR2B2000](#), [90-NBR2B3000](#), [90-NC61B2000](#), [90-NC61B2100](#),
[90-NCA1B2000](#), [90-NCA1B3000](#), [90-NCB1B2000](#), [90-NCB1B3000](#), [90-NCG1B1000](#), [90-NCG1B1010](#),
[90-ND01B1000](#), [90-ND81B1000T](#), [90-ND81B2000T](#), [90-ND81B3000T](#), [90-NDK1B1000](#),
[90-NDM1B1000](#), [90-NDQ1B1000](#), [90-NDQ1B2000](#), [90-NDT1B1000Z](#), [90-NDT1B2000Z](#),
[90-NE51B2000](#), [90-NE51B3000](#), [90-NE52B2000](#), [90-NE52B3000](#), [90-NE61B1000](#), [90-NE61B2000](#),
[90-NE61B3000](#), [90-NE62B1000](#), [90-NE62B2000](#), [90-NE62B3000](#), [90-NEA1B1000](#), [90-NEA1B2000](#),
[90-NEA1B3000](#), [90-NED1B2100Y](#), [90-NER1B1000Y](#), [90-NER1B2000Y](#), [90-NF51B1000](#),
[90-NF51B1000Y](#), [90-NFB1B1000](#), [90-NFD2B1000T](#), [90-NFD2B2000T](#), [90-NFD2B3000T](#),
[90-NFJ1B1000](#), [90-NFPCB1001](#), [90-NFPCB2001](#), [90-NFU1B1000Y](#), [90-NFV6B1000Z](#), [90-NFY6B1000](#),
[90-NFY6B1000Z](#), [90-NG31B1000](#), [90-NG51B1000](#), [90-NGA1B3000](#), [90-NGC1B1000Y](#),

[90-NGF1B1100](#), [90-NGV1B1000T](#), [90-NGV1B2000T](#), [90-NH01B1000](#), [90-NH01B2000](#),
[90-NH01B3000](#), [90-NH73B1000Z](#), [90-NHA1B1000](#), [90-NHA1B2000](#), [90-NHA1B3000](#),
[90-NHA2B1000](#), [90-NHA2B2000](#), [90-NHA2B3000](#), [90-NHJ9B1000Z](#), [90-NHQ2B1000](#),
[90-NHQ2B2000](#), [90-NI11B1000](#), [90-NIA1B1000](#), [90-NIL1B2000](#), [90-NJ91B1010Z](#), [90-NL51B1000](#),
[90-NLF1B2000Y](#), [90-NLV1B1000T](#), [90-NLV1B2000T](#), [90-NM81B1000Y](#), [90-NNN1B1000Y](#),
[90-NNN2B1000Y](#), [90-NQ91B1000Y](#), [90-NQF1B1000T](#), [90-NQF1B2000T](#), [90-NQK1B1000Y](#),
[90-NQY1B1000Y](#), [90-NQY1B2000Y](#), [90-NS62B2000Y](#), [90-NVA1B2000Y](#), [90-NVD1B1000Y](#),
[90-NWF1B2000Y](#), [90-NWT3B3000](#), [90-NWT3B3000Y](#), [90-NX62B2000Y](#), [90-NY81B1000Y](#),
[90-nyx1b1000y](#), [90-NZ51B2000Y](#), [90-OA001B1000](#), [90-OA001B1100](#), [90-OA001B2200](#),
[90-OA001B2300Q](#), [90-OA001B2400Q](#), [90-OA001B2500Q](#), [90-OA001B2600Q](#), [90-OA001B2700Q](#),
[90-OA001B2800Q](#), [90-OA001B9000](#), [90-OA001B9100](#), [90-OA1Q2B1000Q](#), [90-OA281B1000Q](#),
[90-XB0NOABT000000Q](#), [90-XB0ROABT000000Q](#), [90-XB0ROABT000100Q](#), [90-XB16OABT000000Q](#),
[90-XB29OABT000000Q](#), [90-XB29OABT000100Q](#), [90-XB2BOABT000000Q](#), [90-XB2COABT000000Q](#),
[90-XB2KN0BT000000Y](#), [906C5040F](#), [906C5050F](#), [906T2021F](#), [908C3500F](#), [90n011b3000y](#),
[90N1L1B2000Y](#), [90N2V1B1000Y](#), [90NC61B2000](#), [90NC61B2100](#), [90NE51B2000](#), [90NE51B3000](#),
[90NE61B2000](#), [90NF51B1000Y](#), [90NITLILD4SU1](#), [90NITLILG2SU1](#), [90NJ91B1010Z](#),
[90NLV1B1000T](#), [90NLV1B2000T](#), [90NM81B1000Y](#), [90NNN1B1000Y](#), [90NNN2B1000Y](#),
[90NQF1B1000T](#), [90NQF1B2000T](#), [90NQK1B1000Y](#), [90NQY1B1000Y](#), [90NQY1B2000Y](#),
[90NVA1B2000Y](#), [90nyx1b1000y](#), [90NZ51B2000Y](#), [90OA001B2200](#), [90OA001B2300Q](#),
[90OA001B2400Q](#), [90OA001B2500Q](#), [90OA001B2600Q](#), [90OA001B2700Q](#), [90OA001B2800Q](#),
[90OA001B9000](#), [90OA001B9100](#), [90OA281B1000Q](#), [90R-NE61B2000T](#), [90R-NJ51B1000Y](#), [90R-
NM85B1000Y](#), [90R-NNX2B1000Y](#), [90R-NQL1B1000Y](#), [90R-NQM1B1000Ya](#), [90R-NS62B2000Y](#), [90R-
NTC2B1000Y](#), [90R-NUP1B2000Y](#), [90R-NV61B2000Y](#), [90R-NWU1B3100Y](#), [90RNJ51B1000Y](#),
[90RNM85B1000Y](#), [90RNNX2B1000Y](#), [90RNQL1B1000Y](#), [90RNQM1B1000Ya](#), [90RNS62B2000Y](#),
[90RNUP1B2000Y](#), [90RNV61B2000Y](#), [90XB0NOABT000000Q](#), [90XB0ROABT000000Q](#),
[90XB0ROABT000100Q](#), [90XB16OABT000000Q](#), [90XB29OABT000100Q](#), [90XB2BOABT000000Q](#),
[90XB2COABT000000Q](#), [916C-4230F](#), [916C4230F](#), [916C4540F](#), [916C5080F](#), [916C5110F](#), [916C5180F](#),
[916C5190F](#), [916C5220F](#), [916C5280F](#), [920100150](#), [925C2290F](#), [990-OA001B9000](#), [990OA001B9000](#),
[9COAAS031219](#), [A05L623](#), [A1B/F](#), [A21-R2](#), [A21-S1](#), [A21-SI](#), [A21LM2H](#), [A21P1518](#), [A22-700](#),
[A22-901](#), [A22-P701](#), [A22-P701H](#), [A22-R2](#), [A22901](#), [A23-P701](#), [A2I-SI](#), [A31-1005](#), [A31-1015](#), [A31-1025](#)
, [A31-1025b](#), [A31-1025c](#), [A31-B43](#), [A31-B53](#), [A31-F9](#), [A31-JN101](#), [A31-K52](#), [A31-K53](#), [A31-K56](#),
[A31-N56](#), [A31-P2B](#), [A31-S5](#), [A31-S6](#), [A31-T12](#), [A31-U1](#), [A31-U20](#), [A31-U24](#), [A31-U53](#), [A31-U6](#),
[A31-U80](#), [A31-UL20](#), [A31-UL30](#), [A31-UL50](#), [A31-UL80](#), [A31-W5F](#), [A31-X101](#), [A31-X401](#), [A31-X51](#),
[A31-X58](#), [A3101316](#), [A311015](#), [A311025](#), [A311025b](#), [A311025c](#), [A31B53](#), [A31K53](#), [A31K56](#), [A31LJ21](#)
, [A31LJ91](#), [A31LO4G](#), [A31LP4Q](#), [A31N1302](#), [A31N1311](#), [A31N1319](#), [A31N1519](#), [A31N1519-1](#),
[A31N1519-2](#), [A31N1537](#), [A31N1601](#), [A31N1719](#), [A31N1730](#), [A31N56](#), [A31O1316](#), [A31P2B](#), [A31T12](#),
[A31U24](#), [A31U53](#), [A31U80](#), [A31X101](#), [A31X51](#), [A31X58](#), [A32-1005](#), [A32-1015](#), [A32-1025](#), [A32-1025b](#)
, [A32-1025c](#), [A32-A](#), [A32-A3](#), [A32-A6](#), [A32-A8](#), [A32-A93](#), [A32-B43](#), [A32-B50](#), [A32-B53](#), [A32-C90](#),
[A32-F2](#), [A32-F3](#), [A32-F5](#), [A32-F52](#), [A32-F70](#), [A32-F80H](#), [A32-F82](#), [A32-F9](#), [A32-G752](#), [A32-H15](#),
[A32-H17](#), [A32-K52](#), [A32-K53](#), [A32-K55](#), [A32-K55e](#), [A32-K55X](#), [A32-K56](#), [A32-K72](#), [A32-K93](#),
[A32-M50](#), [A32-M70](#), [A32-M9](#), [A32-N1405](#), [A32-N46](#), [A32-N50](#), [A32-N50](#) [A32N50](#), [A32-N55](#),
[A32-N56](#), [A32-N61](#), [A32-N70](#), [A32-N71](#), [A32-N82](#), [A32-NX90](#), [A32-P30](#), [A32-R1](#), [A32-S37](#), [A32-S5](#),
[A32-S6](#), [A32-T12](#), [A32-T12J](#), [A32-T13](#), [A32-T14](#), [A32-T31](#), [A32-T32](#), [A32-U1](#), [A32-U2](#), [A32-U20](#),
[A32-U24](#), [A32-U24](#) [A32U24](#), [A32-U3](#), [A32-U31](#), [A32-U46](#), [A32-U47](#), [A32-U5](#), [A32-U50](#), [A32-U53](#),
[A32-U6](#), [A32-U80](#), [A32-UL20](#), [A32-UL30](#), [A32-UL5](#), [A32-UL50](#), [A32-UL80](#), [A32-V2](#), [A32-W5F](#),
[A32-W7](#), [A32-X101](#), [A32-X401](#), [A32-X50](#), [A32-X51](#), [A32-X51H](#), [A32-X51L](#), [A32-X64](#), [A32-XT12](#),

[A32-Z37](#), [A32-Z62](#), [A32-Z84](#), [A32-Z94](#), [A32-Z96](#), [A32-Z97](#), [A321015](#), [A321025](#), [A321025b](#), [A321025c](#), [A32A](#), [A32A8](#), [A32B53](#), [A32F52](#), [A32F82](#), [A32G752](#), [A32K53](#), [A32K55](#), [A32K55X](#), [A32K56](#), [A32LI9H](#), [A32N1331](#), [A32N1332](#), [A32N1405](#), [A32N1405](#), [A32N1511](#), [A32N46](#), [A32N56](#), [A32NI405](#), [A32RG50](#), [A32T12](#), [A32T12J](#), [A32U31](#), [A32U53](#), [A32U80](#), [A32X101](#), [A32X51](#), [A32X51H](#), [A32X51L](#), [A32XT12](#), [A33-F3](#), [A33-H17](#), [A33-K55](#), [A33-M50](#), [A33-M9](#), [A33-N5](#), [A33-N50](#), [A33-N56](#), [A33-S37](#), [A33-S6](#), [A33-U5](#), [A33-U50](#), [A33-U5F](#), [A33-U6](#), [A33-UL20](#), [A33-W5F](#), [A33-W7](#), [A33-W770-NDQ1B2000](#), [A33-Z37](#), [A33-Z9](#), [A33-Z94](#), [A33-Z96](#), [A33-Z97](#), [A33K55](#), [A33N1332](#), [A33N50](#), [A33N56](#), [A33U50](#), [A34-W90](#), [A3INI302](#), [A3INI3II](#), [A3INI302](#), [A3INI3II](#), [A41-550A](#), [A41-A3](#), [A41-A6](#), [A41-B53](#), [A41-K52](#), [A41-K53](#), [A41-K55](#), [A41-K56](#), [A41-K93](#), [A41-M70](#), [A41-T32](#), [A41-U36](#), [A41-U46](#), [A41-U47](#), [A41-U53](#), [A41-UL30](#), [A41-UL50](#), [A41-UL80](#), [A41-W3](#), [A41-X401](#), [A41-X550A](#), [A41-X550E](#), [A411424](#), [A41B53](#), [A41K53](#), [A41K55](#), [A41K56](#), [A41Lk9H](#), [A41LP4Q](#), [A41N1308](#), [A41N1421](#), [A41N1424](#), [A41N1501](#), [A41N1611](#), [A41N1702](#), [A41U53](#), [A41X500E](#), [A41X550A](#), [A41X550E](#), [A42-A2](#), [A42-A3](#), [A42-A4](#), [A42-A5](#), [A42-A6](#), [A42-A6J](#), [A42-B50](#), [A42-B53](#), [A42-G55](#), [A42-G70](#), [A42-G70](#), [A42G70](#), [A42-G73](#), [A42-G74](#), [A42-G75](#), [A42-G75](#), [A42G75](#), [A42-G750](#), [A42-K52](#), [A42-K53](#), [A42-K55](#), [A42-K56](#), [A42-K93](#), [A42-L5](#), [A42-M2](#), [A42-M3N](#), [A42-M6](#), [A42-M7](#), [A42-M70](#), [A42-N82](#), [A42-N82\(U2\)](#), [A42-U31](#), [A42-U36](#), [A42-U46](#), [A42-U47](#), [A42-U53](#), [A42-UL30](#), [A42-UL50](#), [A42-UL80](#), [A42-V1](#), [A42-V6](#), [A42-W1](#), [A42-W2](#), [A42-W3](#), [A42-X401](#), [A42B53](#), [A42G750](#), [A42K53](#), [A42K55](#), [A42K56](#), [A42I5](#), [A42L85H](#), [A42LM93](#), [A42N1403](#), [A42N1520](#), [A42N1608](#), [A42N1710](#), [A42N1713](#), [A42NI520](#), [A42U31](#), [A42U53](#), [A43EI241SV-SL](#), [A43EI241SVSL](#), [A43LK41](#), [A43N1605](#), [A65](#), [A8000](#), [A8000 Series](#), [A8000F](#), [A8000J](#), [A8000Ja](#), [A8000Jc](#), [A8000Jm](#), [A8A](#), [A8Dc](#), [A8E](#), [A8F](#), [A8Fm](#), [A8H](#), [A8He](#), [A8J](#), [A8Ja](#), [A8Jc](#), [A8Je](#), [A8Jm](#), [A8Jn](#), [A8Jp](#), [A8Jr](#), [A8Js](#), [A8Jv](#), [A8Le](#), [A8M](#), [A8Sc](#), [A8Sr](#), [A8Tc](#), [A8Tm](#), [AASS10](#), [ACGACCBATTA1300](#), [ACGACCBATTF7400](#), [ACGACCBATTL8400](#), [ACGACCBATTS8200](#), [AEEPC900A-WFBB01](#), [AL21-B204](#), [AL21B204](#), [AL22-703](#), [AL22-901](#), [AL23-703](#), [AL23-901](#), [AL23-901H](#), [AL23901](#), [AL23901H](#), [AL24-1000](#), [AL241000](#), [AL31-1005](#), [AL31-1015](#), [AL311005](#), [AL311015](#), [AL32-1005](#), [AL32-1005HA](#), [AL321005](#), [AP11B3F](#), [AP11B7H](#), [AP21-1002HA](#), [AP21-MK90](#), [AP21-T91](#), [AP22-1000](#), [AP22-T101MT](#), [AP22-U100](#), [AP22-U1001](#), [AP22T101MT](#), [AP23-901](#), [AP23-T91](#), [AP23901](#), [AP31-1008HA](#), [AP31-1008P](#), [AP31-H53](#), [AP32-1008HA](#), [AP32-1008P](#), [AS-K50](#), [AS-M2000NL](#), [ASUS-S1BTY](#), [B076M4NXWF](#), [B07JHJNWMF](#), [B07L6GL8KL](#), [B110-00100000](#), [B11P1405](#), [B11P1406](#), [B200-00320200M](#), [B21Bn9H](#), [B21BnEH](#), [B21N1329](#), [B21N1344](#), [B21N1404](#), [B21N1504](#), [B21N1505](#), [B21N1506](#), [B21N1628](#), [B21N1818](#), [B31Bi2H](#), [B31Bi9H](#), [B31Bn9H](#), [B31N1336](#), [B31N1342](#), [B31N1345](#), [B31N1346](#), [B31N1402](#), [B31N1407](#), [B31N1424](#), [B31N1425](#), [B31N1427](#), [B31N1429](#), [B31N14WZ](#), [B31N1503](#), [B31N1507](#), [B31N1534](#), [B31N1535](#), [B31N1536](#), [B31N1625](#), [B31N1631](#), [B31N1632](#), [B31N1635](#), [B31N1637](#), [B31N1705](#), [B31N1705-1](#), [B31N1707](#), [B31N1707-1](#), [B31N1708](#), [B31N1723](#), [B31N1726](#), [B31N1729](#), [B31N1732](#), [B31N1822](#), [B32-M6](#), [B32-S1](#), [B32M6](#), [B400A](#), [B41BK4G](#), [B41Bn95](#), [B41N1304](#), [B41N1327](#), [B41N1341](#), [B41N1514](#), [B41N1526](#), [B41N1532](#), [B41N1711](#), [B41N1827](#), [B53F](#), [B53J](#), [B70KAS184793](#), [B991205](#), [BA-04](#), [BA-05-LMA1](#), [BATA42U53](#), [BATAS2000](#), [BATEL80L6](#), [BATEL80L9](#), [BATSQU511](#), [BATTA1300](#), [BATTF7400](#), [BATTGL702](#), [BATTL8400](#), [BNE010027](#), [BPA0B](#), [BPM3N](#), [BS2-S1](#), [BT.00303.024](#), [BT.00307.034](#), [BU45](#), [BU46](#), [BX310U](#), [C11 EP71](#), [C11-EP71](#), [C11-ME 172V](#), [C11-ME172V](#), [C11-ME301T](#), [C11-ME370T](#), [C11-ME370TG](#), [C11-ME570T](#), [C11-ME571K](#), [C11-ME5PNC1](#), [C11-P03](#), [C11-P05](#), [C11-P1801](#), [C11-TF400CD](#), [C11-TF500CD](#), [C11-TF500TD](#), [C11EP71](#), [C11ME570T](#), [C11N1303](#), [C11N1312](#), [C11O1314](#), [C11P05](#), [C11P1303](#), [C11P1304](#), [C11P1308](#), [C11P1309](#), [C11P1310](#), [C11P1311](#), [C11P1314](#), [C11P1323](#), [C11P1326](#), [C11P1327](#), [C11P1328](#), [C11P1329](#), [C11P1330](#), [C11P1331](#), [C11P1402](#), [C11P1411](#), [C11P1414](#), [C11P1417](#), [C11P1425](#), [C11P1426](#), [C11P1429](#), [C11P1502](#), [C11P1505](#), [C11P1509](#), [C11P1510](#), [C11P1514](#), [C11P1615](#), [C11P1801](#), [C11PI326](#), [C11PQ95](#), [C11TF400CD](#), [C11TF500CD](#), [C11TF500TD](#), [C12-P05](#), [C12-P1801](#), [C12-TF400C](#), [C12-TF600T](#),

[C12-TF810C](#), [C12N1320](#), [C12N1343](#), [C12N1406](#), [C12N1419](#), [C12N1432](#), [C12N1435](#), [C12N1604](#),
[C12N1607](#), [C12P1301](#), [C12P1302](#), [C12P1305](#), [C12P1601](#), [C12P1602](#), [C12PMCH](#), [C12TF400C](#), [C201PA](#),
[C21-TX300D](#), [C21-EP101](#), [C21-N1309](#), [C21-P1801](#), [C21-R2](#), [C21-R50](#), [C21-TF201D](#), [C21-TF201P](#),
[C21-TF201X](#), [C21-TF201XD](#), [C21-TF301](#), [C21-TF500T](#), [C21-TF600TD](#), [C21-TF810CD](#), [C21-TX300D](#),
[C21-TX300P](#), [C21-X202](#), [C21-X402](#), [C21-X502](#), [C2101412](#), [C21IN401](#), [C21INI401](#), [C21N1309](#),
[C21N1313](#), [C21N1318](#), [C21N1326](#), [C21N1333](#), [C21N1334](#), [C21N1335](#), [C21N1347](#), [C21N1401](#),
[C21N1408](#), [C21N1409](#), [C21N1413](#), [C21N1414](#), [C21N1418](#), [C21N1421](#), [C21N1423](#), [C21N1430](#),
[C21N1434](#), [C21N1504](#), [C21N1508](#), [C21N1509](#), [C21N1515](#), [C21N1518](#), [C21N1521](#), [C21N1530](#),
[C21N1603](#), [C21N1612](#), [C21N1613](#), [C21N1618](#), [C21N1624](#), [C21N1625](#), [C21N1627](#), [C21N1629](#),
[C21N1634](#), [C21N1638](#), [C21N1701](#), [C21N1706](#), [C21N1714](#), [C21N1717](#), [C21N1807](#), [C21N1808](#),
[C21N1818](#), [C21N1818-1](#), [C21N1819](#), [C21N1819 1](#), [C21N1833](#), [C21NI333](#), [C21O1412](#), [C21P095](#),
[C21Po95](#), [C21PQ2H](#), [C21PQ91](#), [C21Pq9H](#), [C21PqCH](#), [C21TF500T](#), [C21TF810CD](#), [C21X202](#),
[C21X402](#), [C22-1018](#), [C22-1018P](#), [C22-B400A](#), [C22-EP121](#), [C22-R2](#), [C22-UX31](#), [C22-UX42](#), [C22-UX52](#),
[C221018](#), [C221018P](#), [C22N1307](#), [C22N1623](#), [C22N1626](#), [C22N1720](#), [C22PKC3](#), [C22PYJH](#), [C22UX31](#),
[C22UX52](#), [C23-UX21](#), [C23-UX31](#), [C23-UX32](#), [C23N1606](#), [C23PqCH](#), [C23UX21](#), [C23UX31](#), [C2IN1430](#),
[C2IN1521](#), [C2INI347](#), [C31-EP102](#), [C31-S551](#), [C31-UX30](#), [C31-V551](#), [C31-X402](#), [C31-X502](#),
[C31N1303](#), [C31N1306](#), [C31N1318](#), [C31N1324](#), [C31N1328](#), [C31N1330](#), [C31N1339](#), [C31N1411](#),
[C31N1428](#), [C31N1431](#), [C31N1512](#), [C31N1517](#), [C31N1522](#), [C31N1525](#), [C31N1528](#), [C31N1529](#),
[C31N1538](#), [C31N1539](#), [C31N15WZ](#), [C31N1602](#), [C31N1610](#), [C31N1620](#), [C31N1622](#), [C31N1636](#),
[C31N1637](#), [C31N1703](#), [C31N1704](#), [C31N1714](#), [C31N1721](#), [C31N1724](#), [C31N1733](#), [C31N1803](#),
[C31N1806](#), [C31N1811](#), [C31N1815](#), [C31N1816](#), [C31N1821](#), [C31N1824](#), [C31N1831](#), [C31N1836](#),
[C31N1836-1](#), [C31N1841](#), [C31N1843](#), [C31N1845](#), [C31NI318](#), [C31P0C1](#), [C31PIJ1](#), [C31PMC5](#), [C31PO95](#),
[C31POC1](#), [C31PQ9H](#), [C31X402](#), [C32-G46](#), [C32-N1301](#), [C32-N750](#), [C32-TAICH121](#), [C32-TAICH121](#),
[C32N-1305](#), [C32N1301](#), [C32N1305](#), [C32N1340](#), [C32N1415](#), [C32N1516](#), [C32N1523](#), [C32N1810](#),
[C32NI305](#), [C32PhJ3](#), [C3INI324](#), [C3INI3I8](#), [C3INI4I1](#), [C3INI324](#), [C41-N541](#), [C41-N550](#), [C41-TAICH131](#),
[C41-TAICH131](#), [C41-UX50](#), [C41-UX52](#), [C41N1337](#), [C41N1416](#), [C41N1524](#), [C41N1531](#), [C41N1533](#),
[C41N1541](#), [C41N1619](#), [C41N1621](#), [C41N1709](#), [C41N1712](#), [C41N1714](#), [C41N1715](#), [C41N1716](#),
[C41N1718](#), [C41N1727](#), [C41N1731](#), [C41N1731-1](#), [C41N1731-2](#), [C41N1802](#), [C41N1804](#), [C41N1805](#),
[C41N1809](#), [C41N1814](#), [C41N1825](#), [C41N1828](#), [C41N1832](#), [C41N1837](#), [C41N1838](#), [C41N550](#), [C41P0J1](#),
[C41PKC5](#), [C41PoJ1](#), [C41PPEH](#), [C41PQCH](#), [C41PqPH](#), [C41PSJH](#), [C41TAICH131](#), [C41TAICH131](#),
[C41UX52](#), [C42-UX51](#), [C42N1630](#), [C42N1728](#), [C42N1839](#), [C42PHCH](#), [C4IN1416](#), [CBI0771A](#), [CBPIL44](#),
[CBPIL48](#), [CBPIL72](#), [CII-ME370TG](#), [CII-ME37OT](#), [CII-P03](#), [CIIP1330](#), [CKSA332C1](#), [CKSE14122](#),
[CKSE321D1](#), [CII-EP71](#), [CII-ME37OT](#), [CII-TF400CD](#), [CII-TF500TD](#), [CIIME37OT](#), [CIIP1314](#), [CIIP1330](#),
[CIITF500TD](#), [EA-800](#), [EA-800L](#), [Eee Top ET16-BT1](#), [Eee Top ET16BT1](#), [EEPC900A-WFBB01](#),
[EP121-1A010M](#), [EPCS101-BPN003X](#), [ET16-BT1](#), [ET1603](#), [F501A](#), [F80Q-a1](#), [G46EI361VW](#),
[G46EI363VM](#), [G50 Series](#), [G50-vt](#), [G50V](#), [G50VT Series](#), [G50vt-x2](#), [G50vt-x5](#), [G51J](#), [G51J-A1](#),
[G51J1-X1](#), [G51vx](#), [G70L821](#), [G73-52](#), [GC020009Y00](#), [GC020009Z00](#), [GC02000A000](#), [GC02000AK00](#),
[GC02000AM00](#), [GC02000AN00](#), [GC02000AU00](#), [GC02000AV00](#), [GU501GM](#), [H15L72](#), [H15L726](#),
[HSTNN-CB25](#), [ICR18650-26F](#), [ID6](#), [ID9](#), [L062061](#), [L062066](#), [L0690L6](#), [L0690LC](#), [L072051](#), [L072056](#),
[L0790C1](#), [L0790C6](#), [L082031](#), [L082036](#), [L0890D1](#), [L0A2011](#), [L0A2016](#), [L3TP](#), [L41LK2H](#), [L41LK9H](#),
[LBASL7000L](#), [LC32SD122](#), [LC42SD128](#), [LL22-900A](#), [LO62061](#), [LOA2011](#), [M2A/E-1A](#), [M3N4S2P](#),
[M50 Series](#), [M50Q](#), [M50Q Series](#), [M50Sa](#), [M50Sa Series](#), [M50Sr](#), [M50Sr Series](#), [M50Sv](#), [M50Sv Series](#),
[M50VM](#), [M51E](#), [M70Sa Series](#), [M70Sr Series](#), [MBP-01](#), [MBP-01 TBD PP21](#), [MBP01](#), [ME172V](#),
[ME5PNC1](#), [ML31-1005](#), [ML311005](#), [ML32-1005](#), [ML321005](#), [N501JW-1A](#), [N501JW-1B](#), [N501JW-2A](#),
[N501JW-2B](#), [N501JW1A](#), [N501JW1B](#), [N501JW2A](#), [N501JW2B](#), [N54PNC3](#), [N55SE](#), [N55SF Series](#),
[N55SF-1284V Series](#), [N55SL Series](#), [N55XI243SF-SL](#), [N55XI245SL-SL](#), [N55XI263SF-SL](#),

[N55XI267SF-SL](#), [N55XI267SL-SL](#), [N56I82h](#), [N591LB](#), [N75 Series](#), [N75E Series](#), [N75S Series](#), [N75SF Series](#), [N75SL Series](#), [N75SL-V2G-TZ033V](#), [N75YI267SL-SL](#), [N80 Series](#), [N80Vc](#), [N80VM](#), [N80VM-1A](#), [N80VM-1B](#), [N80VM-2B](#), [N80VM-X2](#), [N80VM1A](#), [N80VM1B](#), [N80VM2B](#), [N80VMX2](#), [N80Vn](#), [N80VR](#), [N81 Series](#), [N81Vg](#), [N81Vp](#), [NB-BAT-A8-NF51B1000](#), [NBBATA8NF51B1000](#), [NBP6A138](#), [NFY6B1000Z](#), [NX90](#), [OB110-00470000](#), [OB200-02770000M](#), [OB200-02770000P](#), [P0AC001](#), [P22-900](#), [P43](#), [P43E](#), [P43EB](#), [P43EI](#), [P43F](#), [P43J](#), [P43JC](#), [P43S](#), [P43SJ](#), [P43SL](#), [P53](#), [P53E](#), [P53E-SO127X](#), [P53E-XS51](#), [P53ESO127X](#), [P53EXS51](#), [P53F](#), [P53J](#), [P53JC](#), [P53S](#), [P53SJ](#), [P53XI](#), [PL31-1005](#), [PL311005](#), [PL32-1005](#), [PL32-1015](#), [PL321005](#), [PL321015](#), [POAC001](#), [PP11LG149Q](#), [PP21AT149Q-1](#), [PRO61XXX](#), [Pro80 Series](#), [Pro80E](#), [Pro80F](#), [Pro80Fm](#), [Pro80H](#), [Pro80Hm](#), [Pro80Jc](#), [Pro80Jn](#), [Pro80Jp](#), [Pro80Jr](#), [Pro80Js](#), [Pro80Jt](#), [Pro80Le](#), [Pro80N](#), [Pro80Sc](#), [Pro80Se](#), [Pro80Sr](#), [PRO86XXX](#), [PST-84000](#), [PWPB001/S1](#), [R2HP9A6](#), [S-L7000L](#), [S200L987E](#), [S2691061](#), [S401](#), [S551](#), [S5NBTB1A](#), [S5NBTW1B](#), [S8-PW-BP001](#), [S9N-0362210-CE1](#), [SL-S1AMO](#), [SL22-900A](#), [SN31NP025321](#), [SQU-424](#), [SQU-503](#), [SQU-511](#), [SQU-528](#), [SQU-529](#), [SQU-601](#), [SQU-605](#), [SQU-814](#), [TF201-1B002A](#), [TF201-1B04](#), [TF201-1I076A](#), [TF201-B1-CG](#), [TF201XD](#), [TF600T](#), [TF600TD](#), [TL31-1005](#), [TL311005](#), [TX300D](#), [U50](#), [U80](#), [UX42](#), [X301](#), [X401](#), [X401U](#), [X40PW91](#), [X45LI9C](#), [X501A](#), [X501U](#), [X502](#), [X502C](#), [X502CA](#), [X550A](#), [X80 Series](#), [X80A](#), [X80H](#), [X80Le](#), [X80N](#), [X80Z](#), [X83 Series](#), [X83V](#), [X83VB](#), [X83VB-X2](#), [X83VBX2](#), [X83VM-X1](#), [X83VMX1](#), [YS-1](#), [YU12008-13007D](#), [YU12125-13002](#),

ASUS Batteries List By ASUS Notebook Computer Model

07G016761875M, 0B110-00220000, 0B110-00220100, 0B110-00220200, 0B110-00230000, 0B110-00230200, 0B110-00230400, 0B110-00230900, 0B110-00231100, 0B200-00530100, 0B200-01300100, 0B200-01300100P, 0B200-01660000, 0B200-01690000, 0B200-01710100, 0B200-01790000, 0B200-02910000, 0B20001660000, 0B20001790000, 1000HD Series, 1001P, 1001PX, 1001PXD, 1002HA-BLK006X, ASUS [1002HA-BLK013K](#) Laptop Battery, 1025 Series, 1025C Series, 1025CE, ASUS [1025CE Series](#) Laptop Battery, 11201NB, 1201N, 1201NB, 200CA-CT161H, ASUS [3568A-BT183](#) Laptop Battery, ASUS [370 TP370QL](#) Laptop Battery, 441SA-WX034D, 441SC-3G, 450, 450C, ASUS [450CD](#) Laptop Battery, 450V, 450VB, 450VE, 46CM-WX124H, 48C, 48CA, 48CM, 5.6-inch MID R50A, 505CM-XX188H, 505CM-XX189P, 505CMXX189P, 550L, 552VX, 58, 58CA, 58CB, 66IC-JX076V, 7265NGW, 8200, 900HA, A1 Series, A1000 Series, A1000B Series, ASUS [A1000D Series](#) Laptop Battery, A1000F Series, A1200 Series, A1200-C700 Series, ASUS [A1300 Series](#) Laptop Battery, A1300-P700 Series, A1B Series, A1D Series, A1F Series, A2, A2000, A2000C, A2000D, A2000G, A2000H, A2000K, A2000L, A2000S, A2000T, A2508H, A2514H, A2534H, A254OH, A254OH series, A2C, A2D, A2G, A2H, A2K, A2L, ASUS [A2S](#) Laptop Battery, A2T, A3000, A3000 Series, A3000E, A3000G, A3000L, A3000N, A32, A32-H15 Series, A33-Z97V, A3500L, A38N, A3Ac, A3E, A3Fc, A3Fp, A3G, A3H, A3H Series, A3Hf, A3L, A3N, A3Vc, A3Vp, A4, A4000, A4000D, A4000G, A4000Ga, A4000K, A4000Ka, A4000L, A4000S, A4000S series, A40J, A40JA, A40JE, A40JP, A41, A411QA, A411QA-BV201T, A411QA-BV202T, A411UF, A412FA, ASUS [A412UA](#) Laptop Battery, A412UB, A420UA, A420UA-EK115T, A42QR, A43 Series, A43BR, A43E-VX0, A43EB815E-SL, A43EB815ESL, A43EB815SD-SL, A43EB815SDSL, A43EB94SD-SL, A43EB94SDSL, A43EB95SD-SL, A43EB95SDSL, A43EB96SD-SL, A43EB96SDSL, A43EI233SA-SL, A43EI233SASL, A43EI233SJ-SL, A43EI233SJSL, A43EI233SV-SL, A43EI233SVSL, A43EI235SD-SL, ASUS [A43EI235SDSL](#) Laptop Battery, A43EI243E-SL, A43EI243ESL, ASUS [A43EI243SA-SL](#) Laptop Battery, A43EI243SASL, A43EI243SJ-SL, A43EI243SJSL, A43EI243SV-SL,

A43EI243SVSL, A43EI245SD-SL, A43EI245SDSL, A43EI245SM-SL, A43EI245SMSL, A43EI267SD-SL, A43EI267SDSL, A43EI267SM-SL, A43EI267SMSL, A43JA, A43JB, A43JC, A43JE, A43JF, A43JG, A43JH, A43JN, A43JP, A43JQ, A43JR, A43JU, A43JV, A43S, A43SJ, A43SV, A43TA, ASUS [A45 Series](#) Laptop Battery, A450, A450C, A450CA-WX102D, A450CA-WX103D, A450CA-WX104D, A450CA-WX105D, A450CA-WX106D, A450CA-WX107D, A450CA-WX219D, A450CA-WX243D, A450CA-WX313D, A450CA-WX314D, A450CC-WX145D, A450CC-WX147D, A450CC-WX152D, A450CC-WX154D, ASUS [A450CC-WX155D](#) Laptop Battery, A450CC-WX247D, A450CC-WX249D, A450CC-WX250D, A450CC-WX261D, A450E, ASUS [A450E1007CC-SL](#) Laptop Battery, A450E1007CCSL, A450E3217CC-SL, A450E3217CCSL, A450E323VB-SL, A450E323VC-SL, A450E3337CC-SL, A450E3337CCSL, A450E42JF-SL, A450E42JFSL, A450E47JF-SL, A450EI323VB-SL, A450EI323VBSL, A450J, A450JF, A450JN, A450JN-WX009H, A450JN4700, A450LC-WX048D, A450LC-WX049D, A450LC-WX050D, A450LC-WX051D, A450LC-WX052D, A450LC-WX055D, ASUS [A450LC4200](#) Laptop Battery, A450LD4210, A450V, A455L, A45A, A45A Series, A45D Series, A45DE, A45DE Series, A45DR, A45DR Series, A45E1000VD-SL, A45E1000VDSL, A45EI321VD-SL, A45EI321VDSL, A45EI323VD-SL, ASUS [A45EI323VDSL](#) Laptop Battery, A45EI361VD-SL, A45EI361VDSL, A45EI361VM-SL, A45EI361VMSL, A45N, A45N Series, A45V, A45V Series, A45VD, A45VD Series, A45VD-VX026R, A45VD-VX027D, A45VDVX026R, A45VDVX027D, A45VG, A45VG Series, ASUS [A45VJ Series](#) Laptop Battery, A45VM, A45VM Series, A45VM-VX029V, A45VM-VX055D, A45VM-VX055V, A45VM-VX063V, A45VMVX029V, A45VMVX055D, A45VMVX055V, A45VMVX063V, A45VS, A45VS Series, A46, A46 Series, A46C, A46CA, A46CA-WX043D, A46CAWX043D, A46CM, A46CM-WX085V, A46CM-WX095D, A46CMWX085V, A46CMWX095D, A46E, A46E2365CM-SL, A46E2365CMSL, A46E3317CB-SL, A46E3317CBSL, A46EI3317CM-SL, A46EI3317CMSL, A46SV, A46SV-WX039D, A46SVWX039D, A480U, A4D, A4G, A4Ga, A4K, A4Ka, A4L, ASUS [A4S](#) Laptop Battery, A5, A5000, A5000E, A5000Eb, A5000Ec, A5000L, A501LB5200, ASUS [A505BA](#) Laptop Battery, A505BP, A505ZA, A52, A52 Series, A52F, A52J, A52JB, A52JC, A52JK, A52JR, A52JR-X1, A53, A53BY-SX089V, A53E, A53E-EH31, A53E-EH91, A53E-NH51, A53E-XA2, A53E-XE1, A53E-XE2, A53EEH31, A53EEH91, A53EI267SM-SL, A53EI267SMSL, A53ENH51, A53EXA2, A53EXE1, A53EXE2, A53F, A53JA, A53JB, A53JC, A53JE, A53JH, A53JQ, A53JR, A53JT, A53JU, A53SD, A53SJ, A53SK, A53SV, A53SV-EH71, A53SV-NH51, A53SV-NH71, ASUS [A53SV-TH71](#) Laptop Battery, A53SV-XC1, A53SV-XE2, A53SV-XT1, A53SVEH71, A53SVNH51, A53SVNH71, A53SVTH71, A53SVXC1, A53SVXE2, A53SVXT1, A53T, A53TA, A53TA-EH61, A53TA-XE2, A53TA-XN1, A53TAEH61, A53TAXE2, A53TAXN1, A53U-EH11, A53U-EH21, A53U-EH22, A53U-XA1, ASUS [A53U-XE1](#) Laptop Battery, A53U-XE2, A53U-XT2, A53UEH11, A53UEH21, A53UEH22, A53UXA1, A53UXE1, A53UXE2, A53UXT2, A53XI233SV-SL, A53XI233SVSL, A53XI235SD-SL, A53XI235SDSL, A53XI243SV-SL, A53XI243SVSL, ASUS [A53XI245SD-SL](#) Laptop Battery, A53XI245SDSL, A53XI245SM-SL, A53XI245SMSL, A53XI267SM-SL, A53XI267SMSL, A540SC-XX012T, A541UV, ASUS [A541UV-XX370T](#) Laptop Battery, A541UVXX370T, A54C, A54HO, A55, A55 Series, A550C, A550C-XX837H, A550CA-XO684H, A550CA-XX566H, A550CA-XX580H, A550CA-XX657V, A550CC Series, A550CC-XX307, A550CC-XX309, A550CC-XX470D, ASUS [A550CC-XX471D](#) Laptop Battery, A550CC-XX530H, A550CC-XX544H, A550DP5750, A550JK, A550JK-DM138H, ASUS [A550JK-XX142D](#) Laptop Battery, A550JK4200, A550JK4710, A550JK4710 Series, A550L Series, A550LA Series, A550LB Series, A550LC Series, A550LC-XX179H, A550LC-XX180H, A550LC-XX181H, A550LC4200, A550V Series, A550VB Series, A550VC Series, A550X1007CC-SL, A550X3217CC-SL, A550X3337CC-SL, ASUS [A550XI323VB-SL](#) Laptop Battery, A550XI323VC-SL, A551C, A551CA, A551LN, A552E, A552EA, A555, A555L, ASUS [A555LD4010](#) Laptop Battery, A555LD4030,

A555LD4210, A555LD5200, A555LF5200, A555LP5200, A556, A556U, A55A, A55A-SX060V, ASUS [A55D](#) Laptop Battery, A55DE, A55DR, A55E, A55N, A55VD, A55VD-SX043V, A55VD-SX050V, A55VD-SX054V, A55VD-SX087V, A55VM, A55VM-SX054V, A55vm-Sx068v, A55VM-SX096V, A55VS, A56, A56 Series, A56C, A56C Series, A56CA, A56CA Series, A56CB, ASUS [A56CB Series](#) Laptop Battery, A56CB-XX174H, A56CM, A56CM Series, A56CM-XX074H, A56CM-XX075H, A56CM-XX269H, A56CMXX074H, A56CMXX075H, A56E, A56V, A56XI3317CM, A56XI3317CM-SL, A56XI3317CMSL, A570ZD, ASUS [A570ZD-DM133T](#) Laptop Battery, A570ZD-DM334T, A5E, A5EB, A5EB-Q008H, A5EB-Q016H, A5EB-Q018H, A5EC, A5EP, A5L, ASUS [A6 SERIES](#) Laptop Battery, A6000 Series, A6000E, A6000G, A6000Ga, A6000J, A6000Ja, A6000K, A6000L, A6000N, A6000Ne, A6000R, A6000U, A6000V, A6000Va, A6000Vc, A6000Vm, ASUS [A62](#) Laptop Battery, A62 Series, ASUS [A6E](#) Laptop Battery, A6F, A6G, A6Ga, A6J, A6Ja, A6Jc, A6Je, A6Jm, A6K, A6Km, A6Kt, A6L, A6M, A6N, A6Ne, A6R, A6Rp, A6T, A6Tc, ASUS [A6U](#) Laptop Battery, A6V, A6Va, A6Vc, A6Vm, A7 Series, A72, A72 Series, A72D, A72DR, A72F, A72F-TY167D, A72F-X1, A72FR-XT1, A72J, A72JK, A72JR, A72JR-TY062V, A72JT-TY139V, A73 Series, A73B, A73BR, A73BY, ASUS [A73E](#) Laptop Battery, A73S Series, A73SD, A73SJ, A73SM, A73SV, A73SW, A73T, A73TA, A73TK, A75 Series, A750j, A750jx, A75A, A75DE, A75DE-TY026V, A75DE-TY043V, A75VD, ASUS [A75VM](#) Laptop Battery, A75VM-TY075V, A75VM-TY085V, A75VM-TY086V, A75VM-TY089V, A7C, ASUS [A7Cd](#) Laptop Battery, A7D, A7Db, A7Dc, A7F, A7G, A7Gb, A7Gc, A7J, A7Jb, A7Jc, A7K, A7M, A7Mb, A7Mc, A7S, A7Sv, A7T, A7Tb, A7Tc, ASUS [A7U](#) Laptop Battery, A7V, A7Vb, A7Vc, A8 Series, ASUS [A8000 Series](#) Laptop Battery, A8000F, A8000J, A8000Ja, A8000Jc, A8000Jm, A83B, A83SA, A83T, A83TK, A8A, A8Dc, A8E, A8F, A8Fm, A8H, A8He, A8J, A8Ja, A8Jc, A8Je, A8Jm, ASUS [A8Jn](#) Laptop Battery, A8Jp, A8Jr, A8Js, A8Jv, A8Le, A8M, A8Sc, A8Sr, A8Tc, A8TL751, A8Tm, A9, A9 Series, A93S, A93SM, A93SM-YZ023V, A93SM-YZ026V, A93SM-YZ095V, A93SV, A93SV-YZ128V, A93SV-YZ142V, A93SV-YZ187V, ASUS [A93SV-YZ222V](#) Laptop Battery, A93SV-YZ223V, A95 Series, A95A, A95V, A95VM, A95VM-YZ019V, A95VM-YZ030V, A95VM-YZ031V, A95VM-YZ033V, A95VM-YZ044V, ASUS [A9C](#) Laptop Battery, A9R, A9Rp, A9Rt, A9T, A9W, Adol 13, ADOL 13U, ADOL I403FA, ADOL13UN, ADOL14F, AE-800, AP21-1002HA, AR5B125, ar5b225, ASmobile S96Fm, ASP 45G, AST21 1B, AST21 1D, AST21 2C, Asus A8000, ASUS B43 Series, ASUS B43A Series, Asus Eee PC 1000HA, ASUS Eee Top ET16-BT1, ASUS EEEPC SERIES, Asus FE170CG, Asus Fonepad 7 K012, ASUS GFX72 SERIES, Asus K012, Asus K017, Asus ME170C, ASUS MeMo Pad 10 Smart ME301T tablet, ASUS MeMo Pad 10 Smart ME301T tablet PC, ASUS MEMO PAD 7, ASUS ROG SERIES, ASUS S6, Asus TP300L, ASUS TP300LD-DW002H, Asus Transformer AiO P1801, Asus UL50AG-A2, ASUS ULTRABOOK, ASUS UX SERIES, Asus Ux303l, ASUS VivoBook S15 S530UN Series, Asus VivoTab TF810C Tablet PC, Asus W90, ASUS X441SA-1A, Asus X502 Series, Asus X502C Series, Asus X502CA Series, ASUS X712FA-GC102T, ASUS ZENBOOK PRO SERIES, ASUS ZENBOOK UX SERIES, Asus-zenbook-ux303l, ASUSPRO B43AV Series, ASUSPRO B43E Series, ASUSPRO B43S Series, ASUSPRO B43V Series, ASUSPRO B9440, ATHEROS, Atheros AR5B22, ATHEROS/AR5B125, B121, B121-1A001, B121-1A001F, B121-1A031F, B121-A1, B31BN91, B31N17260, B43 series, B43AV Series, B43E, B43E Series, B43EI, ASUS [B43F Series](#) Laptop Battery, B43J, B43J Series, B43JB Series, B43JC Series, B43JE Series, B43JF Series, B43Jr, B43JR Series, B43S Series, B43V Series, B43VC Series, B451, B451JA, B451JA-1A, B53, B53 series, B53E, B53E-SO009X, B53E-SO011X, ASUS [B53E-SO039X](#) Laptop Battery, B53E-SO042X, B53E-SO045X, B53E-SX019X, B53E-SX021X, B53ESO009X, B53ESO011X, B53ESO039X, B53ESO042X, B53ESO045X, B53ESX019X, B53ESX021X, B53F, B53F SO054X, B53f-a1b, B53F-C1B, B53F-S0125X, B53F-S0126X, B53f-so042x, B53f-so043x, ASUS [B53F-SO044X](#) Laptop Battery, B53F-SO045X, B53F-SO046X, B53F-SO053X, B53F-SO054, B53F-

SO065X, B53F-SO075X, B53F-SO0762X, B53F-SO076X, B53F-SO079X, ASUS [B53F-SO081](#) Laptop Battery, B53F-SO084, B53F-SO085X, B53F-SO092X, B53F-SO101X, B53F-SO1244, B53F-SO134X, B53F-SO151X, B53F-SO152X, B53F-SO157WS, ASUS [B53F-SO160X](#) Laptop Battery, B53F-SO162X, B53F-SO198X, B53F-SO206X, B53F-SO219X, B53F-SO220X, B53F-SO224X, B53FA1B, B53FC1B, B53FS0125X, B53FS0126X, B53FSO042X, B53FSO043X, B53FSO044X, B53FSO045X, B53FSO046X, B53FSO053X, B53FSO054, B53FSO065X, B53FSO075X, B53FSO0762X, B53FSO076X, B53FSO079X, B53FSO081, B53FSO084, B53FSO085X, B53FSO092X, B53FSO101X, B53FSO1244, B53FSO134X, B53FSO151X, B53FSO152X, B53FSO157WS, B53FSO160X, B53FSO162X, B53FSO198X, B53FSO206X, B53FSO219X, B53FSO220X, B53FSO224X, B53J, B53j-a1b, B53j-b1b, B53J-C1B, B53J-D1B, ASUS [B53J-S0045X](#) Laptop Battery, B53J-S0138X, B53J-SO0335, B53j-so042x, B53JA1B, B53JB1B, B53JC, B53JC1B, B53JD1B, B53JS0045X, B53JS0138X, B53S, B551LA-1A, B551LA-CN018G, B551LA-CN026G, B551LA-CN032G, B551LA-CN039G, B551LA-CN101G, B551LA-CN110G, B551LA-CN169G, B551LA-CN243G, B551LA-CN266G, B551LA-CR015G, B551LA-CR026G, B551LA-XO053G, B551LA-XO082G, ASUS [B551LA-XO104G](#) Laptop Battery, B551LA-XO171G, B551LA-XO187G, B551LA-XO243G, B551LA-XO247G, B551LA-XO315X, B551LA1A, B551LG-1A, B551LG-CN015G, B551LG-CN018G, B551LG-CN031G, B551LG-CN047G, B551LG-CN063G, B551LG-CN126G, B551LG-XB51, B551LG-XO044G, B551LG1A, B8230, B8230U, B8230UA, B9440UA, B9440UA-0271A7500U, B9440UA-0451A8650U, B9440UA-0471A8350U, B9440UA-0511A8550U, B9440UA-0541A8550U, B9440UA-0561A8250U, B9440UA-0631A8250U, B9440UA-GV0005R, B9440UA-GV0006R, B9440UA-GV0028R, B9440UA-GV0046R, B9440UA-GV0048R, B9440UA-GV0050R, B9440UA-GV0056R, B9440UA-GV0076R, B9440UA-GV0081R, B9440UA-GV0094R, B9440UA-GV0100R, B9440UA-GV0100T, B9440UA-GV0101T, B9440UA-GV0128R, B9440UA-GV0132R, B9440UA-GV0143R, B9440UA-GV0144R, B9440UA-GV0177R, B9440UA-GV0188R, B9440UA-GV0210R, B9440UA-GV0211T, B9440UA-GV0215R, B9440UA-GV0218R, B9440UA-GV0230R, B9440UA-GV0274T, B9440UA-GV0279R, B9440UA-GV0303R, B9440UA-GV0342T, B9440UA-GV0361R, B9440UA-GV0389R, B9440UA-GV0407T, B9440UA-GV0409R, B9440UA-GV0432R, B9440UA-GV0433R, B9440UA-GV0443R, B9440UA-GV0450R, B9440UA-GV0474R, B9440UA-GV0475R, B9440UA-XS51, B9440UA-XS74, B9440UA-XS77, B9440UA0271A7500U, B9440UA0451A8650U, B9440UA0471A8350U, B9440UA0511A8550U, B9440UA0541A8550U, ASUS [B9440UA0561A8250U](#) Laptop Battery, B9440UA0631A8250U, B9440UA7200, B9440UA7500, B9440UAGV0005R, B9440UAGV0006R, B9440UAGV0028R, B9440UAGV0046R, B9440UAGV0048R, B9440UAGV0050R, B9440UAGV0056R, ASUS [B9440UAGV0076R](#) Laptop Battery, B9440UAGV0081R, B9440UAGV0094R, B9440UAGV0100R, B9440UAGV0100T, B9440UAGV0101T, B9440UAGV0128R, B9440UAGV0132R, B9440UAGV0143R, B9440UAGV0144R, B9440UAGV0177R, B9440UAGV0188R, B9440UAGV0210R, ASUS [B9440UAGV0211T](#) Laptop Battery, B9440UAGV0215R, B9440UAGV0218R, B9440UAGV0230R, B9440UAGV0274T, B9440UAGV0279R, B9440UAGV0303R, B9440UAGV0342T, B9440UAGV0361R, B9440UAGV0389R, B9440UAGV0407T, ASUS [B9440UAGV0409R](#) Laptop Battery, B9440UAGV0432R, B9440UAGV0433R, B9440UAGV0443R, B9440UAGV0450R, B9440UAGV0474R, B9440UAGV0475R, B9440UAXS51, B9440UAXS74, B9440UAXS77, BATTK56, BATTUX560-2, BB41-CB, BU201 Series, BU201L Series, BU201LA Series, BU201LA-1C, BU203UA, BU400, ASUS [BU400A](#) Laptop Battery, BU400V, BX333FN, BX430, BX430UA, BX430UQ, BX431FA, BX431FB, BX433FN, BX501UX-DM175R, BX51, BX510UW, BX510UW-DM097R, BX510UX, BX510UX-CN118R, BX510UX-CN258T, BX510UX-CN261R, BX510UX-CN261T, BX510UX-DM122R, BX510UX-DM198R, BX510UX-DM260R, BX51V, BX533FD,

C100PA-3J, C100PA-C-3J, C100PA-C3J, C100PA3J, C100PA_C-3J, C101PA, C101PA-3J, C12-TF600T, C200MA C-1A, C201PA, C201PA-2A, C201PA-2B, C201PA-2G, C201PA_C-2A, C201PA_C-2B, C204MA-1A, C204MA-BU0005, C204MA-BU0010, ASUS [C204MA-GJ0003](#) Laptop Battery, C204MA-GJ0023, C204MA-YS02-GR, C213NA, C214MA-BU0003, C214MA-BU0038, ASUS [C214MA-BW0024](#) Laptop Battery, C214MA-BW0077, C214MA-YS02T, C223NA, ASUS [C223NA-1A](#) Laptop Battery, C223NA-1B, C23, C23ux 32 a, c23ux21e, ASUS [C302CA](#) Laptop Battery, C31-S551, C32 TAICHI21, C403NA, C423, C423NA, C423NA-0031AN4200, C423NA-1A, C423NA-BV0001, C423NA-BV0017, C423NA-BV0028, C423NA-BV0044, C423NA-BV0051, C423NA-BV0054, C423NA-BV0078, C423NA-BZ0004, C423NA-BZ0027, C423NA-BZ0038, C423NA-BZ0057, C423NA-DH02, C423NA-EB0020, C423NA-EB0033, C423NA-EB0050, C423NA-EB0063, C423NA-EB0108, C423NA-RH91T-CB, C434TA, C434TA-AI0041, C434TA-AI0045, C434TA-AI0080, C434TA-AI0095, C434TA-AI0108, C434TA-DS384, C434TA-DS384T, C434TA-DS584, C434TA-DS588T, C434TA-DSM4T, C434TA-E10013, C523, C523NA, C523NA-0021AN4200, C523NA-1A, C523NA-A20007, C523NA-A20025, C523NA-A20026, C523NA-A20033, C523NA-A20045, C523NA-A20057, C523NA-A20093, C523NA-A20105, ASUS [C523NA-BR0035](#) Laptop Battery, C523NA-BR0043, C523NA-BR0067, C523NA-EJ0052, ASUS [C523NA-EJ0053](#) Laptop Battery, C523NA-EJ0054, C523NA-EJ0058, C90, C90a, C90P, C90s, Chi T300, Chrombook C201PA-BS01, CHROMEBOOK FLIP C213SA, Chromebook C100PA-DB01, Chromebook C100PA-DB02, Chromebook C100PA-DS03, Chromebook C100PA-RBRKT03, Chromebook C100PADB01, Chromebook C200, Chromebook C200MA, ChromeBook C201P 11.6 inch, Chromebook C201PA, Chromebook C201PA 2G, ASUS [Chromebook C201PA C-2A](#) Laptop Battery, Chromebook C201PA C-2B, Chromebook C201PA C-2B C201PA5, Chromebook C201PA-2G, Chromebook C201PA-DS01, Chromebook C201PA-DS02, Chromebook C201PA_C-2A, Chromebook C201PA_C-2B, Chromebook C202, Chromebook C202SA, Chromebook C202SA-2A, Chromebook C202SA2A, CHROMEBOOK C204MA, Chromebook C204MA-1A, Chromebook C204MA-BU0005, Chromebook C204MA-BU0010, Chromebook C204MA-BU0030, Chromebook C204MA-BU1430, Chromebook C204MA-GJ0003, CHROMEBOOK C204MA-GJ0023, Chromebook C204MA-GJ0074, Chromebook C204MA-GJ0080, ChromeBook C223NA, ChromeBook C223NA-DH02, CHROMEBOOK C223NA-GJ0002, CHROMEBOOK C223NA-GJ0006, CHROMEBOOK C223NA-GJ0007, CHROMEBOOK C223NA-GJ0014, ChromeBook C223NA-GJ0025, CHROMEBOOK C223NA-GJ0029, CHROMEBOOK C223NA-GJ0044, CHROMEBOOK C223NA-GJ0049, CHROMEBOOK C300MA, CHROMEBOOK C300MA-DB01, CHROMEBOOK C300MADB01, Chromebook C423NA, Chromebook C423NA-1A, Chromebook C423NA-BV0016, Chromebook C423NA-BV0047, Chromebook C423NA-BZ0040, Chromebook C423NA-BZ0045, Chromebook C423NA-DH02, Chromebook C423NA-EB0020, Chromebook C423NA-EB0030, Chromebook C423NA-EB0048, Chromebook C423NA-EB0049, Chromebook C423NA-EC0109, Chromebook C523NA, CHROMEBOOK C523NA-1A, ASUS [Chromebook C523NA-A20026](#) Laptop Battery, Chromebook C523NA-A20045, Chromebook C523NA-A20057, Chromebook C523NA-A20071, Chromebook C523NA-BR0067, Chromebook C523NA-DH02, Chromebook C523NA-EJ0054, Chromebook C523NA-EJ0055, Chromebook C523NA-EJ0130, CHROMEBOOK C523NA-IH24T, Chromebook Flip C100PA, Chromebook Flip C100PA-DB01, Chromebook Flip C100PA-DB02, Chromebook Flip C100PA-FS Series, Chromebook Flip C100PA-RBRKT07, Chromebook Flip C100PADB01, Chromebook Flip C100PADB02, Chromebook Flip C101PA, Chromebook Flip C101PA-DB02, ASUS [Chromebook Flip C101PA-FS002](#) Laptop Battery, Chromebook Flip C101PADB02, Chromebook Flip C101PAFS002, Chromebook Flip C213, Chromebook Flip C213NA, Chromebook Flip C213NA-BU0033, Chromebook Flip C213NA-BW0024, Chromebook Flip C213NA-BW0026, Chromebook Flip C213SA, Chromebook Flip C213SA-YS02, Chromebook Flip C214MA,

CHROMEBOOK FLIP C214MA-BW0077, CHROMEBOOK FLIP C214MA-YS02T, Chromebook Flip C302, Chromebook Flip C302C, Chromebook Flip C302CA, Chromebook Flip C302CA-DHM4, Chromebook Flip C302CA-GU003, Chromebook Flip C302CA-GU006, Chromebook Flip C434, Chromebook Flip C434TA, Chromebook Flip C434TA-1A, Chromebook Flip C434TA-DSM4T, Chromebook Flip C434TA-E10013, Chromebook-c523na-a20117, D450C, D450CA-AH21, D450CA-BM1-H, D450CA-BMA-H, D450CA-BMB-H, D450LA, D450LC, D452C, D452CP, D452E, D452EA, D452EP, D452V, D452VP, D540SA, D550, D550C, D550CA-BH01, D550CA-BH21, D550CA-MH31, D550CA-RS31, D550CA-SX060D, D550CA-SX097H, D550CA-SX172H, D550CA-SX191H, D550CA-SX224D, D550CA-SX280H, D550CA-SX281H, D550CA-SX353H-BE, D550M, D550MA, D550MA-DS01, D550MADS01, D551, D551C, D551CA, D551E, D551EA, D552CL, D552E, D552EA, D552EP, D552V, D552VL, DBNOCV115497455, Deluxe13, Deluxe14, DESKTOP-RT85P71, DX992L, E200HA, ASUS [E202SA](#) Laptop Battery, E202SA Serie, E202SA-1A, E202SA-1B, E202SA-1D, E202SA-1E, E202SA-FD0011T, E202SA-FD0012T, E203MA, E203MA-1A, E203MA-1B, E203MA-1E, E203MA1A, E203MA1B, E203MA1E, E203MAH, E203MAH-1A, E203MAH-1B, E203MAH-1E, E203MAH-FD004T, E203MAH-FD005T, E203MAH-FD006, E203MAH-FD011, E203MAH-FD011T, E203MAH-FD012T, E203MAH-FD013T, E203MAH-FD015, E203MAH-FD016T, E203MAH-FD411T, E203MAH-FD412T, E203MAH1A, E203MAH1B, E203MAH1E, E203N, E203NA, E203NA-1A, ASUS [E203NA-1B](#) Laptop Battery, E203NA-1E, E203NA1A, E203NA1B, E203NA1E, E203NAH-1A, E203NAH-1B, E203NAH-1E, E203NAH1A, E203NAH1B, E203NAH1E, E402BA, E402BA-2A, E402BA-2B, E402BA2A, E402BA2B, E402BP, ASUS [E402BP-1R](#) Laptop Battery, E402BP-2A, E402BP-2B, E402BP1R, E402BP2A, E402BP2B, E402MA, E402NA-2A, E402NA-2B, E402NA2A, E402NA2B, E403SA, E406MA, E406MA-0073GN5000, E406MA-0091BN5000, E406MA-1B, E406MA-1C, E406MA-3B, E406MA-3G, E406MA-BV005TS, E406MA-BV009TS, E406MA-BV010TS, ASUS [E406MA-BV021T](#) Laptop Battery, E406MA-BV024T, E406MA-BV026TS, E406MA-BV031T, E406MA-BV044TS, E406MA-BV045, E406MA-BV046TS, E406MA-BV074TS, E406MA-BV085TS, E406MA-BV129TS, E406MA-BV149T, E406MA-BV173T, E406MA-BV175T, E406MA-BV199TS, E406MA-BV202TS, E406MA-BV211TS, E406MA-BV212T, E406MA-BV235T, E406MA-BVREVIEW, ASUS [E406MA-C4DHDSX1](#) Laptop Battery, E406MA-C4DHDSX1 14, E406MA-EB021T, E406MA-EB024T, E406MA-EB031T, E406MA-EB044TS, E406MA-EB149T, E406MA-EB173T, E406MA-EB175T, E406MA-EB193TS, E406MA-EB199TS, E406MA-EK142TS, E406MA-QP2S-CB, E406MA-WE5003T, E406SA, E406SA-1B, E406SA-1C, E406SA-3G, E406SA-BV001T, E406SA-BV004T, E406SA-BV004TS, E406SA-BV005T, E406SA-BV009T, E406SA-BV011T, E406SA-BV012T, E406SA-BV013T, E406SA-BV017T, E406SA-BV023T, E406SA-BV028T, E406SA-BV028TS, ASUS [E406SA-BV037T](#) Laptop Battery, E406SA-BV043T, E406SA-BV059, E406SA-BV072TS, E406SA-BV124T, E406SA-BV133T, E406SA-BV133TS, E406SA-BV153T, E406SA-BV162T, E406SA-BV187T, E406SA-BV211T, E406SA-DS04, E406SA-DS21, E406SA-EB086T, E406SA-EB087T, E406SA-EB087TS, E406SA-EB089T, E406SA-EB090T, E406SA-EB094T, E406SA-EB095T, E406SA-EB097T, E406SA-EB107T, E406SA-EB110T, E406SA-EB123T, E406SA-QP2S-CB, E406SA-QQ2S-CB, E406SA-S3060G, E406SA-S3060W, E406SA-SB01, E450CA, E451, E451L, E451LA, E451LD, E451LD-XB51, E46, E46C, E46CA, E46CB, E46CM, E502M, E502S, E550C, ASUS [E550CA](#) Laptop Battery, E550CC, E551, E551J, E551JA, E551JD, E551JF, E551JH, E551L, E551LA, E551LD, E551LG, E8NOCX181592324, EA-800 Eee Note, EasyNote BG35, EasyNote BG35 Series, EasyNote BG35-u-022, EasyNote BG35-U-442, EasyNote BG35-V-071, EasyNote BG45, EasyNote BG45 Series, EasyNote BG45-P-015, EasyNote BG45-U-009D, EasyNote BG45-U-040FR, EasyNote BG45-U-075, EasyNote BG45-U-300, ASUS [EasyNote BG46](#) Laptop Battery, EasyNote Bg46 Series, EasyNote BG46-P-004, EasyNote BG46-P-024, EasyNote BG48,

EasyNote BG48 Series, EasyNote BG48-M-047FR, EasyNote BG48-M-056FR, EasyNote BG48-T-001AC, EasyNote BG48-T-543, EasyNote BG48-U-001CL, EasyNote BG48-U-091, EasyNote BG48-U-332, EasyNote BG48-V-010GR, EE Pad TF500, EE406SA-EB110T, Eee 1201, Eee 1201HA, Eee 1201N, Eee 1201NL, Eee 1201PN, Eee 1201T, Eee Box B204, Eee Pad B121 Tablet PC Series, Eee Pad EP121, Eee Pad EP121-1A004M, Eee Pad EP121-1A005M, Eee Pad EP121-1A008M, Eee Pad EP121-1A009M, Eee Pad EP121-1A010M, ASUS [Eee Pad EP121-1A011M](#) Laptop Battery, Eee Pad EP121-1A013M, Eee Pad EP121-1A016M, Eee Pad EP121-1A019M, Eee Pad MeMo EP71 N71PNG3, Eee Pad Slate EP121, Eee Pad Slider EP102, Eee Pad TF201, Eee Pad Transformer Prime TF201, Eee Pad Transformer Prime TF201-1I014A, Eee Pad Transformer Prime TF201-B1-CG, Eee Pad Transformer Prime TF201-B1-GR, ASUS [Eee Pad Transformer Prime TF201-C1-CG](#) Laptop Battery, Eee Pad Transformer Prime TF201-C1-GR, Eee Pad Transformer TF101, Eee Pad Transformer TF101-1B001A, Eee Pad Transformer TF101-B1, Eee Pad Transformer TF101-X1, Eee Pad Transformer TR101, Eee PC 1000, Eee PC 1000 Series, Eee PC 1000-BK003, Eee PC 1000H, Eee PC 1000H 20GB, Eee PC 1000H 80GB, Eee PC 1000H GO, Eee PC 1000H Series, Eee PC 1000HA, Eee PC 1000HD, Eee PC 1000HE, Eee PC 1000HG, Eee PC 1001, Eee PC 1001 Series, Eee PC 1001HA, Eee PC 1001P, Eee PC 1001PQ, Eee PC 1001PQD, Eee PC 1001PX, Eee PC 1001PX - BLK3X, Eee PC 1001PX BLK3X, Eee PC 1001PX-BLK003X, Eee PC 1001PX-WHI002X, Eee PC 1001PX-WHI0065, Eee PC 1001PXBK003X, Eee PC 1001PXWHI002X, Eee PC 1001PXWHI0065, EEE PC 1001XXXXX, EEE PC 1002, EEE PC 1002 Series, Eee PC 1002HA, EEE PC 1002HA Series, Eee PC 1002HAE, Eee PC 1002HE, Eee PC 1002HG, Eee PC 1002SA, Eee PC 1003, Eee PC 1003HA, Eee PC 1003HAG, Eee PC 1003HG, Eee PC 1004, Eee PC 1004D, Eee PC 1004DN, Eee PC 1005, Eee PC 1005 Series, Eee PC 1005H, ASUS [Eee PC 1005HA](#) Laptop Battery, Eee PC 1005HA-A, Eee PC 1005ha-blk068x, Eee PC 1005ha-e, Eee PC 1005ha-eu1x, Eee PC 1005ha-eu1x-bk, Eee PC 1005HA-H, Eee PC 1005HA-H-BLK093X, Eee PC 1005HA-M, Eee PC 1005HA-P, Eee PC 1005ha-pu1x, Eee PC 1005ha-pu1x-bk, Eee PC 1005ha-pu1x-bu, Eee PC 1005ha-v, Eee PC 1005ha-vu1x, Eee PC 1005ha-vu1x-bk, Eee PC 1005ha-vu1x-bu, Eee PC 1005ha-vu1x-pi, Eee PC 1005ha-vu1x-wt, Eee PC 1005HA-WHI014X, Eee PC 1005HA-WHI045X, Eee PC 1005haa, Eee PC 1005HAB, Eee PC 1005HAB-BLU001X, ASUS [Eee PC 1005HAB-PIK001X](#) Laptop Battery, Eee PC 1005HABBLU001X, Eee PC 1005hablk068x, Eee PC 1005HABPIK001X, Eee PC 1005hae, Eee PC 1005haeu1x, Eee PC 1005HAEU1XBK, Eee PC 1005HAG, Eee PC 1005HAH, Eee PC 1005HAHBLK093X, Eee PC 1005HAM, Eee PC 1005hap, Eee PC 1005hapu1x, Eee PC 1005hapu1xbk, ASUS [Eee PC 1005hapu1xbu](#) Laptop Battery, Eee PC 1005hav, Eee PC 1005havu1x, Eee PC 1005havu1xbk, Eee PC 1005havu1xbu, Eee PC 1005havu1xpi, Eee PC 1005havu1xwt, Eee PC 1005HAWHI014X, Eee PC 1005HAWHI045X, Eee PC 1005HE, Eee PC 1005HR, Eee PC 1005P, Eee PC 1005PE, Eee PC 1005PR, Eee PC 1005XXXXX, EEE PC 1008HA, Eee PC 1008P, Eee PC 1011, Eee PC 1011P, Eee PC 1011PD, Eee PC 1011PN, Eee PC 1011PX, Eee PC 1011PXD, EEE PC 1015, Eee PC 1015B, Eee PC 1015BX, Eee PC 1015P, Eee PC 1015PD, Eee PC 1015PDG, Eee PC 1015PDT, Eee PC 1015PE, Eee PC 1015PEB, EEE PC 1015PED, EEE PC 1015PED N455, Eee PC 1015PEG, Eee PC 1015PEM, Eee PC 1015PN, Eee PC 1015PW, Eee PC 1015PX, Eee PC 1015T, Eee PC 1016, Eee PC 1016P, Eee PC 1016PE, Eee PC 1016PEB, Eee PC 1016PED, Eee PC 1016PEM, Eee PC 1016PG, Eee PC 1016PN, Eee PC 1016PT, Eee PC 1018 Series(All), Eee PC 1018 SeriesAll, Eee PC 1018P, Eee PC 1018PB, Eee PC 1018PD, Eee PC 1018PE, Eee PC 1018PEB, Eee PC 1018PED, Eee PC 1018PEM, Eee PC 1018PG, Eee PC 1018PN, EEE PC 1025, Eee PC 1025 Series, eee pc 1025c, Eee PC 1025C Series, Eee PC 1025CE, Eee PC 1025CE Series, Eee PC 1101HA, Eee PC 1101HA-M, Eee PC 1101ha-mu1x, Eee PC 1101ha-mu1x-bk, Eee PC 1101HA-MU1X-WT, Eee PC 1101HAM, Eee PC 1101hamu1x, ASUS [Eee PC 1101hamu1xbk](#) Laptop Battery, Eee PC 1101HAMU1XWT, Eee PC 1101HGO, Eee PC 1200, Eee PC 1200 Series, ASUS [Eee PC 1201](#) Laptop Battery, Eee PC 1201HA, Eee PC 1201N, Eee PC

1201N-PU17-BK, Eee PC 1201N-PU17-SL, ASUS [Eee PC 1201NL](#) Laptop Battery, Eee PC 1201PN, Eee PC 1201T, Eee PC 1215, ASUS [Eee PC 1215B](#) Laptop Battery, Eee PC 1215N, EEE PC 1215n-pu17, Eee PC 1215P, Eee PC 1215PE, Eee PC 1215PED, Eee PC 1215PEM, Eee PC 1215PN, Eee PC 1215PW, Eee PC 1215T, Eee PC 1225, Eee PC 1225 Series, Eee PC 1225B, Eee PC 1225B Series, Eee PC 1225C Series, ASUS [Eee PC 12G](#) Laptop Battery, Eee PC 12G (2G RAM), Eee PC 20G, Eee PC 20G (1G RAM), Eee PC 2G, Eee PC 2G Linux, Eee PC 2G Surf, Eee PC 2G Surf (256 RAM), Eee PC 2G Surf/Linux, Eee PC 2G Surf/XP (700X/RU), Eee PC 4G, Eee PC 4G (512 RAM), Eee PC 4G Linux, Eee PC 4G Surf, Eee PC 4G Surf (1G RAM), ASUS [Eee PC 4G Surf \(512 RAM\)](#) Laptop Battery, Eee PC 4G Surf/Linux, Eee PC 4G XP, Eee PC 700, Eee PC 701, Eee PC 701C, Eee PC 701SD, Eee PC 701SDX, Eee PC 703, Eee PC 703 Series, Eee PC 801, Eee PC 8G, Eee PC 8G (1G RAM), Eee PC 900, Eee PC 900 Series, ASUS [Eee PC 900-BK010X](#) Laptop Battery, Eee PC 900-BK028, Eee PC 900-BK039X, Eee PC 900-BK041, Eee PC 900-W012X, Eee PC 900-W017, Eee PC 900-W047, Eee PC 900-W072X, Eee PC 900a, Eee PC 900A Series, ASUS [Eee PC 900H](#) Laptop Battery, Eee PC 900HA, Eee PC 900HA Series, Eee PC 900HD, Eee PC 900HD Serie, Eee PC 900HD Series, Eee PC 901, Eee PC 901 GO, Eee PC 901 Series, Eee PC 901-BK002X, Eee PC 901-W001, Eee PC 901-W003X, Eee PC 901BK002X, Eee PC 901W001, Eee PC 901W003X, Eee PC 904, Eee PC 904 Series, ASUS [Eee PC 904H](#) Laptop Battery, Eee PC 904HA, Eee PC 904HA, Eee PC 904HD, Eee PC MK90, Eee PC R011, EEE PC R011 Series, Eee PC R011/08S, EEE PC R011C, EEE PC R011CX, EEE PC R011P, Eee PC R011PX, Eee PC R051, Eee PC R051B, Eee PC R051BX, Eee PC R051PEM, Eee PC R051PX, Eee PC R052 Series, Eee PC R052C, Eee PC R052C Series, Eee PC R052CE, Eee PC R052CE Series, Eee PC R101, Eee PC RO52 Series, Eee PC RO52C, Eee PC RO52C Series, Eee PC RO52CE, Eee PC RO52CE Series, Eee PC S101, Eee PC S101H, Eee PC S101H-BLK042X, Eee PC S101H-BRN043X, Eee PC S101H-CHP035X, Eee PC S101H-PIK025X, Eee PC S101X, Eee PC S121, Eee PC S121 Series, EEE PC T101, EEE PC T101MT, Eee PC T91, Eee PC T91 MT, Eee PC T91 Tablet, Eee PC T91MT, Eee PC T91MT-BLK027M, Eee PC T91MT-WHI021M, Eee PC T91SA-VU1X-BK, EEE PC VX6, Eee PC X101 Series, Eee PC X101C Series, Eee PC X101CH Series, Eee PC X101H Series, Eee PC X101H Series., Eee PC900HA, Eee Slate B121-1A001F, Eee Slate B121-1A008F, ASUS [Eee Slate B121-1A010F](#) Laptop Battery, Eee Slate B121-1A016F, Eee Slate B121-1A018F, Eee Slate B121-1A031F, Eee Slate B121-A1, Eee Slate B1211A001F, Eee Slate B1211A008F, Eee Slate B1211A010F, Eee Slate B1211A016F, Eee Slate B1211A018F, Eee Slate B1211A031F, Eee Slate B121A1, Eee Slate EP-121, Eee Slate EP121, Eee Slate EP121-1A004M, Eee Slate EP121-1A005M, Eee Slate EP121-1A008M, Eee Slate EP121-1A009M, Eee Slate EP121-1A010M, Eee Slate EP121-1A011M, Eee Slate EP121-1A013M, Eee Slate EP121-1A016M, Eee Slate EP121-1A019M, Eee Transformer TF101, Eee Transformer TR101, EeeBook E205SA, EeeBook E402MA, EeeBook E402MA-EH, EeeBook E402MA-EH01, EeeBook E402MA-WX0001H, EeeBook E402MA-WX0002T, ASUS [EeeBook E402MA-WX0018H](#) Laptop Battery, EeeBook E402MAEH, EeeBook E402MAEH01, EeeBook E402MAWX0001H, EeeBook E402MAWX0002T, EeeBook E402MAWX0018H, EeeBook E403SA, EEEBOOK E403SA-US21, EeeBook E403SA-WX0002H, EeeBook E403SA-WX0003H, EeeBook E403SA-WX0004T, EEEBOOK E403SA-WX0017T, EEEBOOK E403SAUS21, EeeBook E403SAWX0002H, EeeBook E403SAWX0003H, EeeBook E403SAWX0004T, EEEBOOK E403SAWX0017T, EeeBook E502MA, EeeBook E502MA-XX0016D, EeeBook E502MA-XX0020H, EeeBook E502MAXX0016D, EeeBook E502MAXX0020H, EeeBook F205TA, EeeBook F205TA-FD0015BS, EeeBook F205TA-FD0019BS, EeeBook F205TA-FD0035BS, EeeBook F205TA-FD0036BS, EeeBook F205TA-FD0063TS, EeeBook F205TA-FD0064TS, EeeBook F205TA-FD0065TS, EeeBook F205TA-FD0066TS, ASUS [EeeBook F205TA-FD018BS](#) Laptop Battery, EeeBook F205TA-FD019BS, EeeBook L402MA-WX0139T, EeeBook L402MAWX0139T, EeeBook X205, EeeBook X205TA, EeeBook X205TA-BING-FD005BS,

EeeBook X205TA-BING-FD015BS, EeeBook X205TA-FD005BS, EeeBook X205TA-FD0060TS, EeeBook X205TA-FD0061TS, EeeBook X205TA-FD015BS, EeeBook X205TA-FD019BS, EeePC 1001HA-BLK055X, EeePC 1011CX, EEEPC 1015, EeePC 1015CX, ASUS [EeePC 1015E](#) Laptop Battery, EeePC 1025C, EeePC 1025CE, EeePC 1225B, EeePC 1225C, EEEPC 901HA, EeePC MK90, EeePC MK90H, EeePC R052C, EEEPC R052CE, EEEPC RO52, EEEPC RO52C, EEEPC RO52CE, EeePC S101, EeePC X101CH, EP121, EPC 1015, EPC 1015P, EPC 1015PE, EPC 1015PED, EPC 1015PED N455, EPC 1016, EPC 1016P, EPC 1201N, EPC 1201N-SIV047M, EPC 1215, F102B, F102BA, F102BA-DF070H, F102BADF038H, F2 Series, F200M NETBOOK, F200MA, F205TA, F205TA-1A, F205TA-1B, F2F, F2Hf, F2J, F2Je, F3 Series, F301 Series, F301A Series, F301A1 Series, F301U Series, f302l, F302LJ, F302LJ-FN023H, F302LJ-R4025H, ASUS [F302U](#) Laptop Battery, F3E, F3F, F3H, F3J, F3Ja, F3Jc, F3Jf, F3Jm, F3Jp, F3Jr, F3Jv, F3Ka, ASUS [F3Ke](#) Laptop Battery, F3L, F3M, F3P, F3Q, F3Sa, F3Sc, F3Se, F3Sr, F3Sv, F3T, F3Tc, F3U, F401 Series, F401A Series, F401A1 Series, F401U Series, ASUS [F411QA](#) Laptop Battery, F411UF, F412DA, F412FA, F412FA-EB019T, F412FJ, F412UA, F412UB, F420UA, F442U, F450, F450C, F450CA-WX287P, F450CC, F450E, F450E323VC-SL, F450E323VCSL, F450E3337CC-SL, F450E3337CCSL, F450E42JF-SL, F450E42JFSL, F450E47JF-SL, F450E47JFSL, F450J, F450J/E, F450JF, F450V, F450VB, F450VC, F451, F451MA-VX015H, F451MA-VX049H, F451MA-VX076H, F451MA-VX084H, F451MA-VX106H, F451MA-VX308H, F451MA-VX708H, F452C, F452CA, F452E, F452EA, F452V, F452VP, F455L, F5, F50, F50 Series, F501 Series, F501A Series, F501A1 Series, F501U Serie, F501U SERIES, F505, ASUS [F505BA](#) Laptop Battery, F505BP, F505ZA, F50Gx, F50Q, F50S, F50SF, F50SL, F50SV, ASUS [F50sv-x1](#) Laptop Battery, F510UF, F510UN, F510UN-EJ473T, ASUS [F510UQ](#) Laptop Battery, F510UR, ASUS [F512DA](#) Laptop Battery, F512DA-PB31-SL, F512DK, F512FA, F512FA-BQ067T, F512UA, F512UB, ASUS [F52](#) Laptop Battery, F52 Series, F522L, F52A, F52Q, F540LJ-XX030T, F541NA, F541UA, F541UA-GQ1333T, F541UA-GQ933T, F541UA-XO242T, F541UA-XO401D, F541UA-XO405D, F541UA-XX054T, F541UA-XX057T, F541UA-XX061T, F541UAGQ1333T, F541UAGQ933T, F541UAXO242T, F541UAXO401D, F541UAXO405D, F541UAXX054T, F541UAXX057T, F541UAXX061T, F541UV, ASUS [F541UV-XX291T](#) Laptop Battery, F541UVXX291T, F550, F550 ZE, ASUS [F550C](#) Laptop Battery, F550CA, F550CA-CJ687H, F550CA-CJ863H, F550CA-SX079H, f550ca-xo416h, F550CA-XX077H, F550CA-XX078D, F550CA-XX079H, F550CA-XX080H, F550CA-XX134H, F550CA-XX213H, F550CC, F550CC-CJ832H, F550CC-XX066H, F550CC-XX080H, F550CC-XX086H, F550CC-XX1024H, F550CC-XX117H, F550CC-XX118H, F550CC-XX125H, F550CC-XX999H, F550D, F550DP, ASUS [F550DP-XX008H](#) Laptop Battery, F550DP-XX021H, F550DP-XX022H, F550DP-XX033D, F550DP-XX042D, F550DP-XX042H, F550DP-XX057H, F550DP-XX088H, F550DP-XX178H, F550DPXX008H, F550DPXX021H, F550DPXX022H, F550DPXX042D, F550DPXX042H, F550DPXX057H, F550DPXX088H, F550E, F550EA, ASUS [F550JK](#) Laptop Battery, F550L, F550L-XO225H, F550LA, ASUS [F550LA-XO005H](#) Laptop Battery, F550LA-XO068H, F550LA-XO174H, F550LA-XO249H, F550LA-XO261G, F550LA-XO297H, F550LA-XX018H, F550LA-XX078D, F550LAV, F550LAV-XO440H, F550LAV-XO815H, F550LAV-XX385H, F550LAV-XX426H, F550LAV-XX444H, F550LAV-XX455H, F550LB, F550LB-XX082D, F550LB-XX082H, F550LB-XX084H, F550LC, F550LC-XO078H, F550LC-XO110H, ASUS [F550LC-XO111H](#) Laptop Battery, F550LC-XO305H, F550LC-XX044H, F550LC-XX078D, F550LC-XX086H, F550LC-XX089H, F550LC-XX129H, F550LC-XX166H, F550LC-XX207H, F550LC-XX238H, F550LD-XO225H, F550LDV, F550LDV-XX486H, F550LDV-XX487H, F550LDV-XX918H, F550LN, F550LN Series, F550LN-CN89H, F550LN-XX023H, ASUS [F550LN-XX077H](#) Laptop Battery, F550LN-XX131D, F550LNV, F550LNV-XO207H, F550LNV-XO209H, F550LNV-XO271H, F550LNV-XO272H, F550LNV-XO569H, F550VB, F550VB-XX011H, F550VB-XX027H, ASUS [F550VB-XX028H](#) Laptop

Battery, F550VB-XX029H, F550VB-XX039D, F550VC, F550VC-XX035H, F550WA-CJ049H, F550ZE, F550ZE-XX024H, F550ZEXX024H, F551, F551A, F551C, F551CA-SX040H, F551CA-SX050H, F551CA-SX070H, ASUS [F551CA-SX072H](#) Laptop Battery, F551CA-SX079D, F551CA-SX080D, F551CA-SX094H, F551CA-SX101H, F551CA-SX154H, F551CA-SX160H, ASUS [F551CA-SX167H](#) Laptop Battery, F551CA-SX204H-BE, F551CA-SX209H, F551CA-SX232H-LU, F551CA-SX241H, F551CA-SX254H, F551CA-SX290H, F551CA-SX304H, F551CA-SX345H, F551M, F551MA, F551MA-SX029H, F551MA-SX033D, ASUS [F551MA-SX033H](#) Laptop Battery, F551MA-SX062H, ASUS [F551MA-SX065H](#) Laptop Battery, F551MA-SX096H, F551MA-SX098H, F551MA-SX190D, F551MA-SX190H, F551MAF-BING-SX522B, F551MAV, F551MAV-BIG-SX10078, F551MAV-BING-SD522B, F551MAV-BING-SX652B, F551MAV-SX1002B, F551MAV-SX1007B, F551MAV-SX339H, F551MAV-SX347H, F551MAV-SX395B, F551MAV-SX955H, ASUS [F551MAV-SX996H](#) Laptop Battery, F551MAV-SX998B, F551MAVSX1002B, F551MAVSX1007B, F551MAVSX998B, F552C, F552C Series, F552CL, F552CL Series, F552CL-SX060D, F552CL-SX070H, F552CL-SX092H, F552CL-SX138H, F552E, F552E Series, F552EA, F552EA Series, F552EA-SX039D, F552EA-SX077H, F552EA-SX101H, F552EA-XX133D, F552EA-XX134H, F552EP, F552EP Series, ASUS [F552EP-SX016H](#) Laptop Battery, F552EP-SX018D, ASUS [F552EP-SX018H](#) Laptop Battery, F552L, F552LAV-sxa27H, F552LDV-SX698H, F552M, F552V, F552V Series, F552VL, F552VL Series, F552W, F552WA, F552WA-SX039H, F554, F554L, F555, ASUS [F555BA](#) Laptop Battery, F555BP-X0004T, F555BP-XO175T, F555L, F555LN, F555LN-XO055D, F555LN-XO355D, F555Y, F556U, F556UA, F556UA-AB54, F556UA-AS54, F556UA-DM1014T, F556UA-DM130T, F556UA-DM409T, F556UA-DM793T, F556UA-DM893R, F556UA-EB71, F556UA-UH71, F556UA-XO063T, F556UA-XO093T, F556UA-XO094T, ASUS [F556UA-XO218T](#) Laptop Battery, F556UB-DM026T, F556UB-DM052T, F556UB-DM059T, F556UB-DM060T, F556UB-DM061T, F556UB-DM063T, F556UB-DM064T, F556UB-DM068T, F556UB-DM114T, F556UB-DM139T, F556UB-DM212T, F556UB-DM213T, F556UB-DM214T, F556UEGEOM, F556UF-DM028T, ASUS [F556UF-DM065T](#) Laptop Battery, F556UF-DM066T, F556UJ, F556UJ-DM036T, F556UJ-XO009T, F556UJ-XO010T, F556UJ-XO057T, F556UJ-XO155T, F556UJ-XX021T, F556UJ-XX024T, F556UJ-XX025T, F556UJ-XX157T, F556UQ-DM1011T, F556UQ-DM1209, F556UQ-DM1237, F556UQ-DM1289, F556UQ-DM627D, F556UQ-DM705T, F556UQ-DM736T, F556UQ-DM739, F556UQ-DM831T, F556UQ-X01257T, F556UQ-XO528D, F556UQ-XO626D, F556UQ-XO628D, F556UR, F556UR-DM210T, F556UR-DM295T, ASUS [F556UR-DM554T](#) Laptop Battery, F556UR-XO039T, F556UR-XO278T, F556UR-XX356T, F556UV, F556UV-DM154T, F556UV-DM196T, F556UV-DM204T, F556UV-DM244T, F556UV-DM245T, F556UV-XO019T, F556UV-XO223T, F556UV-XX024T, F556UV-XX185T, F556UV-XX243T, F556UV-XX249T, F556UV-XX305T, F556UV-XX306T, F556UV-XX307T, F55U, F570, F570ZD, F570ZD-DM226T, ASUS [F5M](#) Laptop Battery, F5N, F5R, F5RI, F5SL, F5V, F5VI, F5VL, F6, F6A, F6E, F6H, F6K, F6K233E-SI, F6K54S-SI, F6S, F6V, F6VE, F70, F7000 L7, F70S, F70SL, F751L, F751LAV-TY089H, F751LAV-TY175H, F751LAV-TY538T, F751LAV-TY570T-BE, F751LDV-T4182H, ASUS [F751LDV-T4350H](#) Laptop Battery, F751LDV-TY204H, F751LDV-TY354H, F751LJ, F751LJ-TY038T, F751LJ-TY270T, F751LJ-TY307T, F751LJ-TY465T, F751LK-T4009H, F751LK-T4050D, F751LK-TY157H, F751LN-T4005D, F751LN-T4087H, F751LN-T4181H, F751LN-TY036H, F751LN-TY108H, F751MA-TY075-BE, F751MA-TY163H, F751MA-TY236H, F751MA-TY258H, F751SA-TY023T, F751SA-TY071T, F751SA-TY119T, F751SA-TY123T, F8, F80A, F80H, F81, F81 Series, F81S, F81Se, F82, F82 Series, F82Q, F83, F83 Series, F83Cr, F83S, F83S Series, F83SE, F83T, ASUS [F83V](#) Laptop Battery, F83VD, F83VF, F85 Series, F86 Series, F9, F9 Series, F9Dc, F9E, F9F, F9G, F9J, F9S, F9SG, FHD6, FL5500, FL5500L, FL5600, FL5600L, FL5900U, Flip UX362, Fone Pad 7 FE375, Fone Pad 7 FE375CXG, Fone Pad 7 ME375C, Fonepad 7 K019, FonePad 8 (FE380C), FonePad

8 (FE380CG), Fonepad 8 (FE8030CXG), Fonepad 8 (FE8030CXG-1A002A), Fonepad 8 (FE8030CXG1A002A), Fonepad 8 FE380CG, FonePad 8 FE8030CXG, FonePad ME175CG Fonepad 7, FonePad ME175KG HD 7, FonePad ME560CG, Fonepad Note 6, Fonepad Note FHD 6, FX-Plus, FX-Plus4200, ASUS [FX-PLUS4720](#) Laptop Battery, FX-PRO, FX-PRO6700, FX50, FX502VD, FX502VD-2A, FX502VE, FX502VE-2A, FX502VM, FX502VM-AH51, FX502VM-DM107T, FX502VM-DM120T, FX502VT, FX503VD, FX503VM, FX503VM-DM020, FX503VM-DM032T, ASUS [FX503VM-DM044T](#) Laptop Battery, FX503VM-DM081T, FX503VM-EH73, FX503VMDM020, FX503VMDM032T, FX503VMDM044T, FX503VMDM081T, FX503VMEH73, FX504, FX504GD, FX504GE, FX504GM, FX505, FX505GE, FX50J, FX50JK, FX50JK4200, FX50JK4710, FX50JX4200, FX50JX4720, FX53VD-ES74, FX53VD-MH71, FX53VD-MS72, FX53VD-RH71, FX553VD, ASUS [FX553VD-DM234](#) Laptop Battery, FX553VD-DM234T, ASUS [FX553VD-DM235T](#) Laptop Battery, FX553VD-DM236T, FX553VD-DM248T, FX553VD-DM603, FX553VD-DM917T, FX553VD-DM973T, FX553VE-DM062, FX553VE-DM062T, FX553VE-DM079T, FX553VE-DM1158T, FX553VE-DM131T, FX553VE-DM209T, FX553VE-DM252T, FX553VE-DM289T, FX553VE-DM322T, FX553VE-DM353T, FX553VE-DM406, FX553VE-DM486T, FX553VE-DM494T, FX553VE-DM506, FX553VE-FY177, FX553VW, FX570, FX570UD, FX570UD-1C, FX570UD-DM002T, FX570UD-DM090T, FX570UD-DM147T, FX570UD-DM148T, ASUS [FX570UD-DM150T](#) Laptop Battery, FX570UD-DM151T, FX570UD-DM205T, ASUS [FX570UD-DM332T](#) Laptop Battery, FX570UD-DM359T, FX570UD-E4013T, FX570UD-E4014T, FX570UD-E4021T, FX570UD-E4035T, FX570UD-E4158T, FX570UD-E4168T, FX570UD-I5S2RO, FX570UD-I7G1050, FX570UD-I7H1S1RO, FX60, FX60VM, FX60VM-DM135T-BE, FX60VM-DM135T-LU, FX60VM6300, FX60VM6700, FX63V, FX63VD, FX63VD7300, FX63VD7700, Fx63vm, FX63VM7300, FX753VD, Fx753vd-0142b7300hq, FX753VD-GB078T, FX753VD-GC007T, FX753VD-GC013T, FX753VD-GC071, FX753VD-GC079T, FX753VD-GC086T, FX753VD-GC129T, FX753VD-GC151, ASUS [FX753VD-GC171T](#) Laptop Battery, FX753VD-GC193T, FX753VD-GC195T, FX753VD-GC206T, FX753VD-GC256T, FX753VD-GC261T, FX753VD-GC384T, FX753VD-GC436T, FX753VD-GC441T, FX753VD-GC448T, FX753VD-GC490T, FX753VE, FX753VE-GC028T, FX753VE-GC093, FX753VE-GC108T, FX753VE-GC111T, FX753VE-GC153T, FX753VE-GC155T, FX753VE-GC215, FX753VE-GC218, FX753VE-GC224, FX80, FX80G, FX80GD, FX80GD8750-1, FX80GE, FX80GE8750-1, FX80GM, FX86FE, FX86FM, FXPlus, FXPlus4200, FXPLUS4720, FXPRO, FXPRO6700, FZ025T, FZ50V, FZ50VL, FZ50VW, FZ50VW-56C96PB1, FZ50VW-NS51, FZ50VX, FZ50VX-56A95CB1, FZ50VX-76A95SB1, FZ50VX-76B95CS2, FZ50VX-WS74, G1S, G2 Series, G2K, G2P, G2Pb, G2Pc, G2S, G2Sg, G46, G46V, G46VW, G50 Series, G50-vt, G501, G501J, G501jw, G501JW-CN030H, G501JW-CN030T, G501JW-CN168H, G501JW-CN168T, G501JW-CN217H, G501JW-CN217T, G501JW-DS71, G501JW-F1053H, G501VW, G502VM, G502VM-FY057T, G502VM-FY081T, G502VM-FY083T, G502VM-FY087T, G502VM-FY088T, G502VM-FY232T, G502VMK, G502VT, G502VT-FY068, G502VT-FY090T, G502VT-FY166T, G50V, ASUS [G50VT Series](#) Laptop Battery, ASUS [G50vt-x2](#) Laptop Battery, G50vt-x5, G51J, G51J-A1, G51J1-X1, G51vx, G53 Series, G53J, G53J Series, G53JW Series, G53s, G53S Series, G53SW Serie, G53SW Series, G55, G55 Series, G550, G550 Series, ASUS [G550J](#) Laptop Battery, G550J Series, G550JK, G550JK Series, G550JK-1C, ASUS [G550JK-CN147H](#) Laptop Battery, G550JK-CN154H, G550JK-CN155H, G550JK-CN156H, G550JK-CN234H, G550JK-CN252H, G550JK-CN253H, G550JK-CN264H, G550JK-CN268D, G550JK-CN272H, G550JK-CN285H, G550JK-CN287H, G550JK-CN314H, G550JK-CN349H, G550JK-CN363H, G550JK-CN366D, G550JK-CN366H, G550JK-CN367H, G550JK-CN405H, G550JK-CN435H, G550JK-CN436H, G550JK-CN474, G550JK-CN519H, G550JK-CN534H, G550JK-CN536D, G550JK-CN545H, G550JK-DS71, G550JK4200-SL, G550JK4700 Series,

G550JK4700-SL, G551, G551 Series, G551J, G551J Series, G551JK, G551JK Series, G551JK-CN074H, G551JK-CN280D, G551JK-CN302H, G551JK-DM053H, G551JM, ASUS [G551JM Series](#) Laptop Battery, G551JM-CN102H, G551JM-DM052H, G551JM-DM053H, G551JM-DM169H, G551JM-DM197H, G551JW, ASUS [G551JW-CN042H](#) Laptop Battery, G551JW-CN080H, G551JW-DS71, G551JW-DS71-CA, G551JW-DS74, G551JX, G551JX-DM036H, G551JX-DM198H, G551JX-ES71, G551VW, G551VW- FW280T, G551VW-FW184T, G551vw-fw280t, G552VX, G553VD-DM154T, G553VD-DM361T, G553VD-DM434T, G553VD-DM737T, G553VD-FY025T, G553VD-FY126T, G553VD-FY383T, G553VD-FY622T, G553VE, G553VE-FY118T, G553VE-FY404T, G553VW, G553VW-DM141T, G55V, G55V G55VM, G55V Series, G55VM, G55VM SERIES, G55VM-DH71, G55VM-DH71-CA, G55VM-DS71, G55VM-ES71, G55VM-RS71, G55VM-S1020V, ASUS [G55VW](#) Laptop Battery, G55VW Series, G55VW-DH71-CA, G55VW-ES71, G55VW-RS71, G55VW-S1016V, G55VW-S1020V, ASUS [G55VW-S1024V](#) Laptop Battery, G55VW-S1073V, G55VW-S1129V, G55VW-S1136V, G55VW-S1168P, G55VW-S1177H, G55VW-S1183H, G55VW-S1197H, G55VW-S1202D, G55vw-v2g, G55XI361VW-BL, G55XI363VW-BL, G56JK, G56JR, G56JR SERIES, G56JR-CN232H, G56JR-CN273H, G56JRCN232H, G56JRCN273H, g571jy, G58, G58J, G58JM, G58JM Series, G58JM4200, G58JM4710, G58JW4200, G58JW4720, G601J, G60JW4720, G70, G70 series, G701VI, G701VI-1A, G701VI-XB72K, G701VI-XS72K, G701VI1A, G701VIK, G701VIK-BA049T, G701VIKBA049T, G701VIXB72K, G701VO-1A, G701VO-CS74K, G701VO-CS74K XoticPC, G701VO1A, G701VOCS74K, G701VOCS74K XoticPC, G703VI, G70g, G70s, G70S-7S007C, ASUS [G70S-7S018C](#) Laptop Battery, G70S-7T015G, G70S-7T020G, G70S-7T024G, G70S-7T025G, G70S-7T028J, G70s-a1, G70s-b1, G70S-X1, G70S7S007C, G70S7S018C, G70S7T015G, G70S7T020G, G70S7T024G, G70S7T025G, ASUS [G70S7T028J](#) Laptop Battery, G70sa1, G70sb1, G70sg, G70SG-7S007C, G70SG-7T002G, G70SG-7T005G, G70SG-7T006G, G70SG-7T011C, G70sg-a1, G70Sg-A2, G70sg-a3, G70SG7S007C, G70SG7T002G, G70SG7T005G, G70SG7T006G, G70SG7T011C, G70sga1, G70SgA2, G70sga3, G70SX1, G71, G71 Series, G71G, G71G-X1, G71GX, G71GX-7S008K, G71GX-7S022K, G71GX-7S023K, G71GX-A1, G71Gx-A2, G71Gx-X2, G71V, G71V G71G-A1, G71V-7S036C, G71V-7T025C, G71VG, ASUS [G72](#) Laptop Battery, G72G, G72GX, G72Gx-A1, G72GX-TY013V, G72GX-TY014V, G72V, G73, G73 Series, G73G Series, G73GW Series, G73J Series, G73JH, G73JH Series, G73JH-A1, G73JH-A2, G73JH-X1, G73JH-X2, G73JW, G73JW Series, G73S Series, ASUS [G73SW](#) Laptop Battery, G73SW Serie, G74 Series, G741jm-t4046h, G741JM-T4047H, G74J Series, ASUS [G74JH Series](#) Laptop Battery, G74JH-A1, G74S Series, G74S-XR1, G74SW Series, G74SW-A1, G74SW-A2, G74SX Series, G74SX-021A2670QM, G74SX-3D, G74SX-3DE, G74SX-91079V, G74SX-91131Z, G74SX-A1, G74SX-A2, G74SX-BBK7, G74SX-FHD-TZ048V, G74SX-TY151V, G74SX-TZ078V, G74SX-XA1, ASUS [G74SX-XC1](#) Laptop Battery, G74SX-XR1, G74SX-XT1, G75, G75 3D, G75 3D series, G75 Series, G750, G750 J, G750 jm, G750 Series, G750GM-BSI7N23, G750J, G750JH, G750JH-CV132H, G750JH-DB71, G750JH-DB72, G750JH-DB72-CA, G750JH-T4032H, G750JH-T4040H, G750JH-T4060H, G750JH-T4070H, G750JH-T4071H, G750JH-T4076H, G750JH-T4080H, G750JH-T4081H, G750JH-T4086D, G750JH-T4100, G750JH-T4103H, G750JH-T4106H, G750JH-T4129H, G750JH-T4134H, G750JH-T4165H, G750JH-T4168H, G750JH-T4170H, G750JH-T4180H, G750JH-T4188H, G750JM, G750JM-1A, G750JM-BSI7N23, G750JM-BSI7N24, G750JM-DB71-CA, G750JM-DS71, G750JM-T4012H, G750JM-T4014H, G750JM-T4016H, ASUS [G750JM-T4018P](#) Laptop Battery, G750JM-T4031H, G750JM-T4037H, ASUS [G750JM-T4038H](#) Laptop Battery, G750JM-T4039H, G750JM-T4049H, G750JM-T4050H, G750JM-T4051H, G750JM-T4056H, G750JM-T4057H, G750JM-T4061H, G750JM-T4069H, ASUS [G750JM-T4087H](#) Laptop Battery, G750JM-T4099H, G750JM-T4109H, G750JM-T4110H, G750JM-T4111H, G750JM-T4112H, G750JM-T4119H, G750JM-T4121H, G750JM-T4131H, G750JM-T4144H, G750JM-T4153H,

G750JS, G750JS-DS71, G750JS-NH71, G750JS-RS71, G750JS-T4001H, G750JS-T4003H, G750JS-T4008H, G750JS-T4019H, G750JS-T4022H, G750JS-T4023H, G750JS-T4028H, G750JS-T4031H, G750JS-T4046H, G750JS-T4054H, G750JS-T4056H, G750JS-T4064H, G750JS-T4067H, G750JS-T4068H, G750JS-T4069H, ASUS [G750JS-T4072H](#) Laptop Battery, G750JS-T4077H, G750JS-T4078H, G750JS-T4093H, G750JS-T4094H, G750JS-T4122H, G750JS-T4129H, G750JS-T4133H, G750JS-T4147H, G750JS-T4151H, G750JS-T4154H, G750JS-T4155H, G750JS-T4163H, G750JS-T4168H, G750JS-T4179H, G750JS-T4193H, ASUS [G750JS-T4228](#) Laptop Battery, G750JS-T4231H, G750JW, G750JW-1A, G750JW-BBI7N05, G750JW-DB71, G750JW-DB71-CA, G750JW-DH71, G750JW-NH71, G750JW-RB71, G750JW-RB71-CB, G750JW-T4013H, G750JW-T4019H, ASUS [G750JW-T4030H](#) Laptop Battery, G750JW-T4031, G750JW-T4031H, G750JW-T4041H, G750JW-T4042H, ASUS [G750JW-T4044H](#) Laptop Battery, G750JW-T4053H, G750JW-T4055H, G750JW-T4057H, G750JW-T4066H, G750JW-T4071H, G750JW-T4075H, G750JW-T4091H, G750JW-T4096H, G750JW-T4099H, G750JX, G750JX-CV025H, G750JX-CV030H, G750JX-CV038H, G750JX-CV040H, G750JX-CV050H, G750JX-CV069P, G750JX-CV200H, G750JX-DB71, G750JX-DH71-CA, G750JX-DS77, ASUS [G750JX-DS77-CA](#) Laptop Battery, G750JX-IB71, G750JX-RB71, G750JX-T4032H, G750JX-T4035H, G750JX-T4041H, G750JX-T4052H, G750JX-T4059H, G750JX-T4061H, G750JX-T4064H, G750JX-T4070H, G750JX-T4073H, G750JX-T4101D, G750JX-T4119H, G750JX-T4133H, G750JX-T4137H, G750JX-T4144H, G750JX-T4145H, G750JX-T4150H, G750JX-T4166H, G750JX-T4167H, G750JX-T4179H, G750JX-T4191H, G750JX-T4195H, G750JX-T4201H, G750JX-T4202H, G750JX-T4204H, G750JX-T4211H, ASUS [G750JX-T4215H](#) Laptop Battery, G750JX-T4230H, G750JX-T4246H, G750JX-T4259H, G750JX-T4264H, G750JX-T4279H, G750JX-TB71, G750JX4700, G750JY, G750JY-1A, G750JY-T4003H, G750JY-T4009H, G750JY-T4010H, G750JY-T4013P, G750JY-T4015H, G750JY-T4016H, G750JY-T4023H, G750JY-T4026H, G750JY-T4032H, G750JY-T4033H, G750JY-T4036D, G750JY-T4037P, G750JY-T4039H, G750JY-T4044H, G750JY-T4049H, G750JY-T4050D, G750JY-T4051H, G750JY-T4055H, G750JY-T4057H, G750JZ, G750JZ-1A, G750JZ-DB73-CA, G750JZ-DS71, G750JZ-QB72-CB, G750JZ-RB73-CA, G750JZ-T4004H, G750JZ-T4013H, G750JZ-T4017H, G750JZ-T4023H, G750JZ-T4024H, G750JZ-T4025H, G750JZ-T4030H, G750JZ-T4039D, G750JZ-T4044H, G750JZ-T4046H, G750JZ-T4056H, G750JZ-T4071H, G750JZ-T4079H, G750JZ-T4088H, G750JZ-T4089, G750JZ-T4096H, G750JZ-T4103H, G750JZ-T4105H, ASUS [G750JZ-T4110H](#) Laptop Battery, G750JZ-T4116H, G750JZ-T4122H, G750JZ-T4129HM, ASUS [G750JZ-T4139P](#) Laptop Battery, G750JZ-T4146H, G750JZ-T4148H, G750JZ-T4152D, G750JZ-T4160H, G750JZ-T4169H, G750JZ-T4172H, G750JZ-T4182H, G750JZ-T4203H, G750JZ-T4210P, G750JZ-T4H, G750JZ-XS72, G750M-T4018P, G751, G751 Series, G751J Series, G751J-BHI7T25, G751JM, G751JM Series, G751JT Series, G751JY, G751JY Series, G752v, G752VL, G752VL-1A, G752VL-2A, G752VL-BHI7N32, G752VL-DH71, G752VL-GC057T, G752VL-GC058T, G752VL-GC059T, G752VL-GC060T, G752VL-GC085T, G752VL1A, G752VL2A, G752VLBHI7N32, G752VLDH71, ASUS [G752VLGC057T](#) Laptop Battery, G752VLGC058T, G752VLGC059T, G752VLGC060T, G752VLGC085T, G752VM, G752VM-GC034D, G752VM-GC058T, G752VMGC034D, G752VMGC058T, ASUS [G752VS](#) Laptop Battery, G752VS-GC087T, G752VS-GC089T, G752VS-GC090D, G752VS-XB78K, G752VSGC087T, G752VSGC089T, G752VSGC090D, G752VSXB78K, G752VT, G752VT-1A, G752VT-DH72, G752VT-DH74, ASUS [G752VT-GC030T](#) Laptop Battery, G752VT-GC031T, G752VT-GC032T, G752VT-GC037T, G752VT-GC046D, G752VT-GC053T, G752VT-GC062T, G752VT-GC075T, G752VT-GC104T, G752VT-RH71, G752VT1A, G752VTDH72, G752VTDH74, G752VTGC030T, G752VTGC031T, G752VTGC032T, G752VTGC037T, G752VTGC046D, G752VTGC053T, G752VTGC062T, G752VTGC075T, G752VTGC104T, G752VTRH71, G752VW, G752VY, G752VY-1A, G752VY-GC082T, G752VY-GC083T, G752VY-GC086T, G752VY-GC087T, G752VY-

GC088T, G752VY-GC144D, G752VY-GC261T, G752VY-GC263T, G752VY-GC264T, G752VY1A, G752VYGC082T, G752VYGC083T, G752VYGC086T, G752VYGC087T, G752VYGC088T, ASUS [G752VYGC144D](#) Laptop Battery, G752VYGC261T, G752VYGC263T, G752VYGC264T, G753, G75LM2H, G75LM2H-G750JM, G75V, G75V 3D, G75V 3D Series, ASUS [G75V Series](#) Laptop Battery, G75VM, G75VM 3D, G75VM 3D SERIES, G75VM SERIES, G75VW, G75VW 3D, G75VW 3D Series, G75VW Series, G75VW-DS7, G75VW-NS7, G75vw-t1443h, G75VW-TH71, G75VW-TH72, G75VW-TS71, G75VW-TS72, G75VX, G75VX-BHI7N09, G75VX-T4121H, G75YI361VW-BL, G75YI361VWBL, G75YI363VX-BL, G75YI363VXBL, G771, G771 Series, G771J, G771J Series, G771JK, G771JK Series, G771JM, G771JM Series, G771JM-DH71, G771JM-DH71-CA, G771JM-QH71-CB, G771JM-T4039D, G771JM-T4103H, G771JM-T7018H, G771JM-T7021H, G771JM-T7022H, G771JM-T7025D, G771JM-T7025H, G771JM-T7031H, G771JM-T7043D, G771JM-T7053H, G771JM-T7058H, G771JM-T7061H, ASUS [G771JM-T7063H](#) Laptop Battery, G771JM-T7064H, G771JM-T7067H, G771JM-T7068H, G771JM-T7080H, G771JW, G771JW Series, G771JW-T7028D, G771JW-T7056H, G771JW-T7076H, G771JW-T7078H, G771JW-T7115H, G771JW-T7191T, G800VI, GDSOGS5, GFX70J, GFX70JZ, GFX70JZ4710, GFX71 Series, GFX71J Series, GFX71JM Series, GFX71JT Series, GFX71JY Series, GFX71JY4710, GFX71JY4720, GFX71JY4860, ASUS [GFX72J](#) Laptop Battery, GFX72VL6700, GFX72VT6700, GFX72VY6700, GL502V, GL502VM, ASUS [GL502VM-1A](#) Laptop Battery, GL502VM-DB71, GL502VM-DB74, ASUS [GL502VM-DS74](#) Laptop Battery, GL502VM1A, GL502VMD71, GL502VMD74, GL502VMDS74, GL502VMK, GL502VS-1A, GL502VS-1E, GL502VS-DB71, GL502VS-DS71, GL502VS-FY028T, GL502VS-FY030T, GL502VS-FY039T, GL502VS-FY043T, GL502VS-FY057T, ASUS [GL502VS-FY058T](#) Laptop Battery, GL502VS-FY081T, GL502VS-FY099T, GL502VS-FY110T, GL502VS-FY111T, GL502VS-FY169T, GL502VS-FY247T, ASUS [GL502VS-FY255T](#) Laptop Battery, GL502VS-FY256T, GL502VS-FY272, GL502VS-FY280T, GL502VS-FY281T, GL502VS-FY306T, GL502VS-FY313T, GL502VS-FY323T, GL502VS-FY332T, GL502VS-FY333T, GL502VS-FY353, GL502VS-FY353T, GL502VS-FY385T, GL502VS-FY403T, GL502VS-GZ120T, GL502VS-GZ128T, GL502VS-GZ132T, GL502VS-GZ137T, GL502VS-GZ140T, GL502VS-GZ147T, GL502VS-GZ164T, GL502VS-GZ217T, GL502VS-GZ222, GL502VS-GZ223T, GL502VS-GZ227T, GL502VS-GZ228T, GL502VS-GZ233T, GL502VS-GZ234T, GL502VS-GZ287, GL502VS-GZ302T, GL502VS-GZ303T, GL502VS-GZ363T, GL502VS-GZ381, GL502VS-GZ384, ASUS [GL502VS-GZ392T](#) Laptop Battery, GL502VS-GZ422T, GL502VS-GZ427T, GL502VS-GZ428T, GL502VS-GZ440, GL502VS-Q72S-CB, GL502VS-WS71, GL502VS1A, GL502VS1E, GL502VT, GL502VT-1A, GL502VT-1B, GL502VT-FW055T, GL502VT1A, GL502VT1B, GL502VY, GL502VY-1A, ASUS [GL502VY-DS71](#) Laptop Battery, GL502VY-DS74, GL502VY-FI048T, GL502VY-FI063T, GL502VY-FI076T, GL502VY-FI122T, GL502VY-FI129T, GL502VY-FY023T, GL502VY-FY024T, GL502VY-FY040T, GL502VY-FY060D, GL502VY-FY064T, GL502VY-FY075T, GL502VY-FY107, GL502VY-FY119T, GL502VY-FY131T, GL502VY1A, GL502VYDS71, GL502VYDS74, GL502VYFY023T, GL503GE, GL503VD, GL503VD-1A, GL503VD-1B, ASUS [GL503VD-1D](#) Laptop Battery, GL503VD1A, GL503VD1B, GL503VD1D, GL503VM, GL503VM-1A, GL503VM-1B, GL503VM-1C, GL503VM-1D, GL503VM-1E, GL503VM1A, GL503VM1B, GL503VM1C, GL503VM1D, GL503VM1E, GL503VS, GL551, GL551J, ASUS [GL551JK](#) Laptop Battery, GL551JM, GL551JM-DH71, GL551JW, GL551jw-cn085h, GL551JX, GL552, GL552J, GL552JX, GL552V, ASUS [GL552VW](#) Laptop Battery, GL552VW-DH71, GL553VD, GL553VD-1A, GL553VD-1B, GL553VD-2B, GL553VD-2D, GL553VD-DM016T, ASUS [GL553VD-DM030](#) Laptop Battery, ASUS [GL553VD-DM049T](#) Laptop Battery, GL553VD-DM064T, GL553VD-DM065T, GL553VD-DM066T, GL553VD-DM067T, GL553VD-DM078T, GL553VD-DM086T, GL553VD-DM1006T, GL553VD-DM1096T, GL553VD-DM1150T, GL553VD-

DM1171T, GL553VD-DM146T, GL553VD-DM176, GL553VD-DM176T, ASUS [GL553VD-DM203T](#) Laptop Battery, GL553VD-DM254T, ASUS [GL553VD-DM256T](#) Laptop Battery, GL553VD-DM262T, GL553VD-DM282T, GL553VD-DM287T, GL553VD-DM303T, GL553VD-DM33, GL553VD-DM331T, GL553VD-DM350T, GL553VD-DM365T, GL553VD-DM373T, GL553VD-DM409T, GL553VD-DM410T, GL553VD-DM432T, GL553VD-DM467T, ASUS [GL553VD-DM468T](#) Laptop Battery, GL553VD-DM469T, GL553VD-DM470T, GL553VD-DM515, GL553VD-DM535T, GL553VD-DM548T, ASUS [GL553VD-DM596T](#) Laptop Battery, GL553VD-DM609T, GL553VD-DM664T, GL553VD-DM665T, GL553VD-DM666T, GL553VD-DM672T, GL553VD-DM730T, GL553VD-DM764T, GL553VD-DM792, GL553VD-DM792T, GL553VD-DM793T, GL553VD-DM819T, GL553VD-DM824T, GL553VD-DM853T, GL553VD-DM934, GL553VD-DM985T, ASUS [GL553VD-FY009T](#) Laptop Battery, GL553VD-FY019T, GL553VD-FY025T, GL553VD-FY026T, GL553VD-FY027T, GL553VD-FY047T, GL553VD-FY072T, GL553VD-FY103T, GL553VD-FY1071, GL553VD-FY124T, GL553VD-FY130T, GL553VD-FY143T, GL553VD-FY175T, GL553VD-FY217T, GL553VD-FY230T, GL553VD-FY280T, GL553VD-FY297T, GL553VD-FY380T, GL553VD-FY399T, GL553VD-FY460T, GL553VD-FY461T, GL553VD-FY478T, GL553VD-FY484T, GL553VD-FY570, GL553VD-FY578T, GL553VD-FY594T, GL553VD-FY659, GL553VD1A, GL553VD1B, ASUS [GL553VD2B](#) Laptop Battery, GL553VD2D, ASUS [GL553VDFY072T](#) Laptop Battery, GL553VDFY124T, GL553VE-1B, GL553VE-DM019T, GL553VE-DM028T, GL553VE-DM066T, GL553VE-DM107T, GL553VE-DM233T, GL553VE-DM253T, GL553VE-DM292T, GL553VE-DM299T, GL553VE-DM305T, GL553VE-DM309T, GL553VE-DM332T, GL553VE-DM400T, GL553VE-DS74, GL553VE-FY003T, GL553VE-FY022T, GL553VE-FY025T, GL553VE-FY035T, GL553VE-FY040T, GL553VE-FY047T, GL553VE-FY050T, GL553VE-FY101T, GL553VE-FY104T, ASUS [GL553VE-FY114T](#) Laptop Battery, GL553VE-FY117T, GL553VE-FY127T, GL553VE-FY160, GL553VE-FY168T, GL553VE-FY169T, GL553VE-FY200T, GL553VE-FY218T, GL553VE-FY242T, GL553VE-FY243T, GL553VE-FY256T, GL553VE-FY269T, GL553VE-FY280T, GL553VE-FY329T, GL553VE-FY330T, GL553VE-FY337, GL553VE-FY337T, GL553VE-FY343T, GL553VE-FY404T, GL553VE-FY421, GL553VE-FY425T, GL553VE-FY437T, GL553VE-FY468T, GL553VE-FY472T, GL553VE1B, GL553VEDS74, GL553VEFY003T, GL553VW, GL553VW-1A, GL553VW-2B, GL553VW-2D, GL553VW-DM059T, GL553VW-DM086T, GL553VW-DM129T, GL553VW-DM133T, GL553VW-DM134D, GL553VW-FY002T, GL553VW-FY015T, ASUS [GL553VW-FY022T](#) Laptop Battery, GL553VW-FY025, GL553VW-FY032T, GL553VW-FY036T, GL553VW-FY037T, GL553VW-FY051T, GL553VW-FY060D, GL553VW-FY062T, GL553VW-FY073T, GL553VW-FY079T, GL553VW-FY084T, GL553VW-FY094T, ASUS [GL553VW-FY101T](#) Laptop Battery, GL553VW-FY109, GL553VW-FY148D, GL553VW-FY159T, GL553VW-FY179T, GL553VW-FY182D, GL553VW-FY185D, GL553VW1A, GL553VW2B, GL553VW2D, GL702, GL702V, GL702VI, GL702VI-1A, GL702VI1A, GL702VM, GL702VM-1A, GL702VM-BA135T, ASUS [GL702VM-BA195T](#) Laptop Battery, GL702VM-BA230T, GL702VM-BA323T, GL702VM-BA324, GL702VM-BA325T, GL702VM-BA414, ASUS [GL702VM-DB71](#) Laptop Battery, GL702VM-DB74, GL702VM-GB031T, GL702VM-GB032T, GL702VM-GC004T, GL702VM-GC005T, GL702VM-GC010T, GL702VM-GC017T, GL702VM-GC020T, GL702VM-GC026T, GL702VM-GC035T, GL702VM-GC059T, GL702VM-GC100T, GL702VM-GC102D, GL702VM-GC143T, GL702VM-GC154T, GL702VM-GC194T, ASUS [GL702VM-GC234](#) Laptop Battery, GL702VM-GC279T, ASUS [GL702VM-GC280T](#) Laptop Battery, GL702VM-GC301T, GL702VM1A, GL702VMD71, GL702VMD74, GL702VMGB031T, GL702VMGB032T, GL702VMGC004T, GL702VMGC010T, GL702VMGC017T, GL702VMGC020T, GL702VMGC035T, GL702VMGC100T, GL702VMGC102D, GL702VMGC279T, GL702VMGC280T, GL702VMGC301T, GL702VS, GL702VS-1A, GL702VS-1C, GL702VS-BA023T,

GL702VS-BA101, GL702VS-BA181T, GL702VS-BA207T, GL702VS-BA222T, GL702VS-BA230T, GL702VS-BI7N12, GL702VS-GC066T, GL702VS-GC079T, GL702VS1A, GL702VS1C, GL702VSK-R, GL702VSKR, GL702VT, ASUS [GL702VT-1A](#) Laptop Battery, GL702VT-GC018T, GL702VT-GC023T, GL702VT-GC024T, GL702VT-GC025T, GL702VT-GC033T, GL702VT-GC057T, GL702VT-GC061T, GL702VT-GC090TC, GL702VT-GC109T, GL702VT1A, GL702VTGC018T, GL702VTGC023T, GL702VTGC024T, GL702VTGC025T, GL702VTGC033T, GL702VTGC057T, GL702VTGC061T, GL702VTGC090TC, GL702VTGC109T, GL702ZC, GL702ZC-GC006T, GL702ZC-GC007T, GL702ZC-GC098T, GL702ZC-GC104T, GL702ZC-GC105T, GL702ZC-GC174T, GL702ZC-GC177T, GL702ZC-GC178T, GL702ZC-GC179T, GL702ZC-GC204T, GL702ZC-R7, GL702ZCR7, GL703, GL703G, GL703GE, GL703GE-ES73, GL703GEES73, GL703GM, ASUS [GL703GM-0051A8750H](#) Laptop Battery, GL703GM-71200T, GL703GM-78B06CS1, GL703GM-E5011T, GL703GM-E5014T, GL703GM-E5016, GL703GM-E5018T, ASUS [GL703GM-E5024T](#) Laptop Battery, GL703GM-E5033T, GL703GM-E5044T, GL703GM-E5054T, GL703GM-E5055T, GL703GM-E5063T, ASUS [GL703GM-E5070T](#) Laptop Battery, GL703GM-E5091T, GL703GM-E5095T, GL703GM-E5100T, GL703GM-E5108, GL703GM-E5159T, GL703GM-E5171T, GL703GM-E5172T, GL703GM-E5174T, GL703GM-E5187T, GL703GM-E5189T, GL703GM-E5210, GL703GM-E5211T, GL703GM-E5232T, GL703GM-EE014T, GL703GM-EE015T, GL703GM-EE017T, GL703GM-EE019T, GL703GM-EE024T, GL703GM-EE032, GL703GM-EE033T, GL703GM-EE034T, GL703GM-EE036T, GL703GM-EE044T, GL703GM-EE049, GL703GM-EE049T, GL703GM-EE056, GL703GM-EE057T, GL703GM-EE059T, GL703GM-EE063T, GL703GM-EE073, GL703GM-EE074, GL703GM-EE074T, GL703GM-EE077T, GL703GM-EE079T, ASUS [GL703GM-EE093T](#) Laptop Battery, GL703GM-EE094T, GL703GM-EE095T, ASUS [GL703GM-EE101T](#) Laptop Battery, GL703GM-EE103, GL703GM-EE115T, GL703GM-EE129T, GL703GM-EE163T, GL703GM-EE172T, GL703GM-EE183, GL703GM-EE186, GL703GM-EE188T, GL703GM-EE225, GL703GM-EE231, GL703GM-EE232T, GL703GM-EE241, GL703GM-NS73, GL703GM-WS71, GL703GS-0041A8750H, GL703GS-1A, GL703GS-71250, GL703GS-DS74, GL703GS-E5010T, GL703GS-E5011T, GL703GS-E5012T, GL703GS-E5015T, GL703GS-E5017T, GL703GS-E5020T, GL703GS-E5027T, GL703GS-E502T, GL703GS-E5034T, GL703GS-E5035T, GL703GS-E5036T, GL703GS-E5057, GL703GS-E5069, GL703GS-E5070T, GL703GS-E5071T, GL703GS-E5081T, GL703GS-EE070T, GL703GS-EE071T, GL703GS-EE074T, GL703GS-EE091, GL703GS-EP005T, GL703GS-EP009T, GL703VD, GL703VD-1A, GL703VD-1B, GL703VD-DB74, GL703VD1A, GL703VD1B, GL703VDDDB74, GL703VM, GL703VM-1A, GL703VM-1B, GL703VM1A, GL703VM1B, GL704, GL704GM, GL704GM-DH74, GL704GW, GL742VW TY134T, GL742VW-T4423T, GL742VW-TY134T, GL752, ASUS [GL752JW](#) Laptop Battery, ASUS [GL752V](#) Laptop Battery, GL752VL, GL752VL-1A, GL752VL-2B, GL752VL-GC057T, GL752VLM, GL752VW, GL752VW Serie, GL752VW-1A, GL752VW-2B, GL752VW-3B, GL752VW-DH71, GL752VW-DH74, GL752VW-GS71, GL752VW-T4004T, GL752VW-T4016D, GL752VW-T4064D, GL752VW-T4065D, GL752VW-T4077T, GL752VW-T4079T, GL752VW-T4091T, GL752VW-T4104T, GL752VW-T4105, GL752VW-T4108D, GL752VW-T4122T, GL752VW-T4130T, GL752VW-T4137T, GL752VW-T4138T, ASUS [GL752VW-T4179T](#) Laptop Battery, GL752VW-T4180T, GL752VW-T4188T, GL752VW-T4189T, GL752VW-T4243T, GL752VW-T4322D, GL752VWDH71, GL752VWM, GL753V, GL753VD-GC003, GL753VD-GC009T, GL753VD-GC010T, GL753VD-GC015T, GL753VD-GC025T, GL753VD-GC042T, GL753VD-GC060T, GL753VD-GC117T, GL753VD-GC139T, GL753VD-GC141T, GL753VD-GC148T, GL753VD-GC180T, GL753VD-GC184T, GL753VD-GC185T, GL753VD-GC186T, ASUS [GL753VD-GC197](#) Laptop Battery, GL753VD-GC210, GL753VD-GC214T, GL753VD-GC225T, GL753VD-GC236T, GL753VD-GC273T, GL753VD-GC278T, GL753VD-GC280T, GL753VD-

GC324T, GL753VD-GC348T, GL753VD-GC366T, GL753VD-GC377, GL753VD-GC377T, GL753VD-GC387T, GL753VD-GC403T, GL753VD-GC412T, GL753VD-GC417T, GL753VD-GC505, GL753VD-SB71, GL753VE, GL753VE-0021B7700HQ, GL753VE-GC002, GL753VE-GC004T, GL753VE-GC008T, GL753VE-GC016T, GL753VE-GC024T, GL753VE-GC039T, GL753VE-GC050T, GL753VE-GC070T, GL753VE-GC090T, GL753VE-GC105T, GL753VE-GC139T, GL753VE-GC147, GL753VE-GC165T, GL753VE-GC168T, GL753VE-GC179T, GL753VE-GC216T, GL753VE-GC226T, GL753VE-GC247T, GL753VE-IS74, ASUS [GL771](#) Laptop Battery, GL771J, GL771J Series, GL771JM, GL771JM Series, GL771JM-DH71, GL771JM-T4034H, ASUS [GL771JM-T7093H](#) Laptop Battery, GL771JM-T7128H, GL771JM-T7129H, GL771JM-T7130H, GL771JM-T7143H, GL771JW, GM501GM, GM501GM-0021A8750H, ASUS [GM501GM-EI003T](#) Laptop Battery, GM501GM-ei004T, GM501GM-EI005T, GM501GM-EI007T, GM501GM-EI008T, GM501GM-EI017T, GM501GM-EI021T, GM501GM-EI028T, GM501GM-EI029T, GM501GM-EI031T, GM501GM-ei039T, GM501GM-WS74, GM501GM0021A8750H, GM501GMEI003T, GM501GMEI005T, GM501GMEI007T, GM501GMEI008T, GM501GMEI017T, GM501GMEI021T, GM501GMEI028T, GM501GMEI029T, GM501GMEI031T, GM501GMWS74, GM501GS, GM501GS-0021A8750H, GM501GS-EI001T, ASUS [GM501GS-EI004T](#) Laptop Battery, GM501GS-EI012T, GM501GS-EI013T, GM501GS-EI014T, GM501GS-EI015T, GM501GS-EI017T, GM501GS-EI018T, GM501GS-EI023T, GM501GS-EI024T, GM501GS-EI027T, ASUS [GM501GS-EI028T](#) Laptop Battery, GM501GS-EI030T, GM501GS-XS74, GM501GS0021A8750, GM501GSEI001T, GM501GSEI004T, GM501GSEI012T, GM501GSEI013T, GM501GSEI014T, GM501GSEI015T, GM501GSEI017T, GM501GSEI018T, GM501GSEI023T, GM501GSEI024T, GM501GSEI027T, GM501GSEI028T, GM501GSEI030T, GM501GSXS74, gm750, Google Nexus 7, Google Nexus 7 2nd Generation K008, gs70 2pu 009au, GS70-2PE781, GU501GM-B17N8, GU502DU, GU502GU, GU502GU-AZ047T, GU502GV, GU532GU, ASUS [GU532GU-AZ076T](#) Laptop Battery, GX501, GX501G, GX501GI, GX501GM, GX501GS, GX501VI, GX501VI-1A, GX501VIK, GX501VS, ASUS [GX501VS-XS71](#) Laptop Battery, GX501VSK, GX502GV, GX502GW, GX531, ASUS [GX531G](#) Laptop Battery, GX531GM, GX531GS, GX531GV, GX531GW, GX531GW-78A27CB1, GX531GW-AH76, GX531GW-AS73, GX531GW-ES006T, GX531GW-ES007T, GX531GW-ES009T, GX531GW-ES010T, GX531GW-ES026T, GX531GW-ES027T, GX531GW-ES035R, GX531GW-ES036T, GX531GW-I7R2070, GX531GX, GX531GXR, GX532GV, GX532GW, GX700VO-1A, GX700VO1A, GX700VO6820, GX701G, GX701GV-EV016T, GX701GV-EV052T, GX701GW-EV056T, GX701GWR, GX701GX-EV001T, GX701GX-EV007T, GX701GX-EV009T, GX701GX-EV015T, GX701GX-EV016R, GX701GX-EV021T, GX701GX-EV023T, GX701GX-EV048T, GX701GX-EV052T, ASUS [GX701GX-EV054T](#) Laptop Battery, GX701GX-EV058R, GX701GX-EV058T, GX701GX-EV059T, GX701GX-EV064T, GX701GX-EV067T, ASUS [GX701GX-EV081T](#) Laptop Battery, GX701GX-EV58T, GX701GX-XB78, GX701GXH, GX735GV, GX735GVR, GX735GW, GX735GX, GX735GXR, GX800V, ASUS [GX800VH-1A](#) Laptop Battery, GX800VH1A, H100HA, H53PAC6, I403FA, I403FA-2C, i5-3317u, INFINITY, J750, K00B, K00G, K010 TF103CX, K01E ME0310K 1B 6A, ASUS [K40](#) Laptop Battery, K40 Series, K401J, K401LB, K401LB5010, K401LB5200, K401LB5500, K401N, K401U, K401UB, K40AB, K40AC, K40AD, K40AE, K40AF, K40C, K40E, K40E Series, K40I, K40ID, K40IE, K40IJ, K40IJ Series, K40IL, K40IN, K40IN Series, K40IP, K410UA, K410UA-EB010R, K410UA-EB151R, K410UA-EB193T, K410UA-EB364T, K410UA-EB407R, K410UA-EB485T, K410UA-EB785T, K410UF, K410UF-V400, K410UN, K410UQ-FA120D, K42, K42 Series, K42D, K42DE, K42DQ, K42DR, K42F, K42F-A2B, K42J, K42JA, K42JB, K42JC, K42JE, K42JK, K42JR, K42JR-VX047X, ASUS [K42JV](#) Laptop Battery, K42JY, K42N, K43, K430FA, K430FN, K430UF, K431FA, K431FL, ASUS [K43B](#) Laptop Battery, K43BE, K43BR, K43BY, K43E, K43F, K43J, K43JC, K43JM, K43JS, K43JY, K43S, K43S, ASUS [K43SA](#) Laptop

Battery, K43SC, K43SD, K43SE, K43SJ, K43SJ, K43SM, K43SR, K43SV, ASUS [K43SV](#) Laptop Battery, K43SV-VX250V, K43SVVX250V, K43SY, K43T, K43TA, K43TK, K43U, K43U, K45 Series, K450C, K450C Series, K450CA, K450CA Series, K450CC, K450CC Series, K450J, K450L, K450L Series, K450LA, K450LA Series, K450LB, K450LB Series, K450LC, K450LC Series, K450ld, K450V, K450V Series, K450VB, ASUS [K450VB Series](#) Laptop Battery, K450VC, K450VC Series, K450VE Series, K451L, K451LN, ASUS [K451LN-WX162H](#) Laptop Battery, K451LNWX162H, K455LD, ASUS [K455LD-FH71-CB](#) Laptop Battery, K455LDFH71CB, K455LN, K45A, K45DE, K45DR, K45DR-VX007D, K45DR-VX008D, K45DRVX007D, K45DRVX008D, K45EI361VD-SL, K45EI361VDSL, K45L, K45LA45A, ASUS [K45N](#) Laptop Battery, K45V, K45VD, K45VD-VX061D, K45VD-VX061V, K45VDVX061D, K45VDVX061V, K45VG, K45VJ, K45VM, K45VM-VX070, K45VM-VX071, K45VMVX070, K45VMVX071, K45VS, K46, K46 SERIES, K46C, ASUS [K46CA](#) Laptop Battery, K46CA-WX013, K46CA-WX014, K46CA-WX015, K46CAWX013, K46CAWX014, K46CAWX015, ASUS [K46CB](#) Laptop Battery, K46CM, ASUS [K46CM-1AWX](#) Laptop Battery, K46CM-WX002D, K46CM-WX003D, K46CM-WX004D, K46CM-WX007, K46CM-WX025V, K46CM-WX047V, K46CM-WX090V, K46CM1AWX, K46CMWX002D, K46CMWX003D, K46CMWX004D, K46CMWX007, K46CMWX025V, K46CMWX047V, K46CMWX090V, K46E3317CM, K46EI2365CM, K46EI3317CM-SL, K46EI3317CM-SM, K46EI3317CMSL, K46V, K50, K50 Series, K501J, K501LB, K501LB SERIES, ASUS [K501LX](#) Laptop Battery, K501LX SERIES, K501LX-NH52, K501LXNH52, K501n, K501U, K501UB, K501UB SERIES, K501UX, K501UX SERIES, K501UX-AH71, K501UXAH71, K505ZA, ASUS [K50AB](#) Laptop Battery, K50AB-X2A, K50AB-X2A Series, K50AD, K50AE, K50AF, K50C, K50I, K50ID, K50IE, K50ij, ASUS [K50ij Series](#) Laptop Battery, K50IL, K50IN, K50IN Series, K50IP, K51, K51 Series, K510UA-BQ024, K510UA-BQ1318, K510UA-BQ366T, K510UA-BQ602T, K510UF, K510UF-BQ047T, K510UF-BQ298R, K510UF-BQ389R, K510UF-BQ502R, K510UN, K510UN-BQ196T, K510UN-BQ242T, K510UN-BQ267T, K510UN-BQ268T, K510UN-BQ297T, K510UN-BQ497T, K510UN-BQ502T, K510UQ, K510UQ-BQ097T, K510UQ-BQ336R, K510UQ-BQ338R, K510UQ-BQ559R, K510UQ-BQ654T, K510UQ-BQ667T, K510UQ-BQ668T, K510UQ-BQ684R, ASUS [K510UQ-BQ831T](#) Laptop Battery, K510UQ-BR159T, K510UR, K510UR-BQ020T, K510UR-BQ205T, K510UR-BR038T, K510UR-EJ293T, K510UR-EJ307T, K510UR-EJ321T, K51AB, K51AC, K51AE, K51IO, K52, K52 Series, K52D, K52DR, K52f, k52f-a1, k52f-sx051v, K52F-SX060D, k52f-sx065x, k52f-sx074v, K52JB, K52JC, K52JE, K52JK, K52jr, k52jr-a1, k52jr-x2, k52jr-x4, k52jr-x5, K52JT, K52M, K53, K53 Series, K53-L893, K53B, K53B, K53B Series, K53BE, K53BR, K53BY, K53BY, K53E, K53E, ASUS [K53E-1BSX](#) Laptop Battery, K53E-A1, K53E-B1, K53E-BBR1, K53E-BBR11, K53E-BBR14, K53E-BBR15, K53E-BBR17, K53E-BBR19, K53E-BBR23, K53E-BBR3, K53E-BBR7, K53E-BD4TD, K53E-C1, K53E-DH31, K53E-DH51, K53E-DH52, K53E-DH91, ASUS [K53E-DS31](#) Laptop Battery, K53E-DS51, K53E-DS52, K53E-RBR4, K53E1BSX, K53EA1, K53EB1, K53EBBR1, K53EBBR11, K53EBBR14, K53EBBR15, K53EBBR17, K53EBBR19, K53EBBR23, K53EBBR3, K53EBBR7, K53EBD4TD, K53EC1, K53EDH31, K53EDH51, K53EDH52, K53EDH91, K53EDS31, K53EDS51, K53EDS52, K53ERBR4, K53F, K53F, K53F Series, K53J, K53J, K53JA, K53JC, K53JE, K53JF, K53JG, K53JN, K53JN Series, K53JS, K53JT, K53L853, K53L85H, K53L893, K53S, K53S, ASUS [K53SA](#) Laptop Battery, K53SC, K53SC-SX054, ASUS [K53SCSX054](#) Laptop Battery, K53SD, K53SD, K53SD-DS51, K53SD-DS71, K53SD-SX168D, K53SDDS51, K53SDDS71, K53SDSX168D, K53SE, K53SE Series, K53SJ, K53SJ, K53SK, K53SM, K53SM-SX010D, K53SMSX010D, K53SN, K53SV, K53SV, K53SV Series, K53SV-A1, K53SV-B1, ASUS [K53SV-DH51](#) Laptop Battery, K53SV-DH71, K53SV-SX393V, K53SV-XR1, K53SVA1, K53SVB1, K53SVDH51, K53SVDH71, K53SVSX393V, K53SVXR1, K53T, K53T, K53TA, K53TA, K53TA-A1, K53TA-BBR6, K53TAA1, K53TABBR6, K53TK, ASUS [K53U](#) Laptop

Battery, K53U, K53U-A1, K53U-DH21, K53U-RBR5, K53U-RBR7, K53UA1, K53UDH21, K53URBR5, K53URBR7, K53X30TK, K53X342TK, K53X34TA, K53XI231SC, K53XI231SJ, K53XI233SC, K53XI235SD, K53XI241SC, K53XI241SJ, K53XI241SV, K53XI243SC, K53XI245SD, K53XI245SM, K53XI263SV, K53Z, K53Z-BBR3, K53ZBBR3, K54, K54 Series, K54C, K54C-SX036V, K54CSX036V, K54H, K54HO, K54HR, K54HR Series, K54HY, K54L, K54LY, K55 Series, k550c, K550C Series, K550CA, K550CA Series, K550CC, K550CC Series, K550D, K550DP-XX010H, K550DP-XX017H, K550DP-XX060H, K550DP-XX064P, K550DP-XX141H, K550DP5350, K550E, K550JK-X0172H, K550JK-XO003H, K550JK4200, K550JK4710, K550L, K550L Series, K550LA, K550LA Series, K550LA-QS52-CB, K550LB, K550LB Series, K550LB-XX166H, K550LC, K550LC Series, K550LD4200, K550LD4210, K550V, K550V Series, K550VB, K550VB Series, K550VC, ASUS [K550VC Series](#) Laptop Battery, K550VX, K550VX-DM028D, K550VX6300, K550VX6300-154ASCA2X10, K550X1007CC-SL, K550X4500LN-SL, K550X555DP-SL, K550X575DP-SL, K550XI323VB-SL, K550XI323VC-SL, K550XI3337CC, K551L, K551L-DM550H, K551LA Serie, K551LA-XX235D, K551LA-XX314D, K551LA-XX317H, K551LA-XX318H, K551LB, K551LB-XX184H, K551LB-XX210H, K551LB-XX225D, K551LB-XX226D, K551LM-XX400H, K551LN, K551LN-DM092H, K551LN-XO401H, K551LN-XX021H, K551LN-XX144H, ASUS [K551LN-XX250H](#) Laptop Battery, K551LN-XX251H, K551LN-XX519H, K551LN-XX520H, K552EA, K555, K555L, K555LA-XO848H, K555LB, K555LB-XO474T, K555LD-XX284D, K555LD-XX286D, K555LJ, K555LJ-XX1008T, K555LJ-XX1349T, K555LJ-XX135D, K555LJ-XX974T, K555Z, K556UA, K556UB, K556UB-DM162T, K556UB-XX019D, K556UB-XX023D, K556UB-XX033D, K556UB-XX115D, K556UB-XX175D, K556UB-XX177D, K556UB-XX178D, K556UJ, K556UJ-XX032D, K556UJ-XX034D, K556UJ-XX109T, K556UQ-0221B7200U, K556UQ-DM001D, K556UQ-DM002D, K556UQ-DM022D, K556UQ-DM1023T, K556UQ-DM1024T, K556UQ-DM1040T, K556UQ-DM1130T, K556UQ-DM1140T, K556UQ-DM1142T, K556UQ-DM1144T, K556UQ-DM1145D, K556UQ-DM1354, K556UQ-DM1370T, K556UQ-DM1423, K556UQ-DM1423D, K556UQ-DM611T, K556UQ-DM712T, ASUS [K556UQ-DM713T](#) Laptop Battery, K556UQ-DM732T, K556UQ-DM799T, K556UQ-DM802T, K556UQ-DM897T, ASUS [K556UQ-DM898T](#) Laptop Battery, K556UQ-DM956D, K556UQ-DM957D, K556UQ-Q52P-CB, K556UQ-Q72-CB, K556UQ-XO1029T, K556UQ-XO899T, K556UQ-XX1073D, K556UQ-XX348T, K556UQ-XX466T, K556UQ-XX557T, K556UQ-XX688D, K556UQ-XX935T, K556UR-DM180T, K556UR-DM181T, K556UR-DM271T, K556UR-DM339T, K556UR-DM466T, K556UR-DM498T, K556UR-DM499T, K556UR-DM621T, ASUS [K556UR-XX010T](#) Laptop Battery, K556UR-XX033T, K556UR-XX044D, K556UR-XX127T, K556UR-XX134T, K556UR-XX252D, K556UR-XX252T, K556UR-XX269T, K556UR-XX338T, K556UV, K556UV-GA056D, K55A, K55A-1B, K55A-2A, K55A-3C, K55A-3D, K55A-3E, K55A-3F, K55A-3G, K55A-3H, K55a-sx006h, K55A-SX071, K55A-SX244V, K55A-SX373H, K55A1B, K55A2A, K55A3C, K55A3D, K55A3E, K55A3F, K55A3G, K55A3H, K55ASX071, ASUS [K55ASX244V](#) Laptop Battery, K55ASX373H, K55DE, K55DE-1A, K55DE1A, K55DR, K55DR-1A, K55DR-SX026H, K55DR-SX026V, K55DR-SX027H, K55DR-SX027V, K55DR-SX028D, K55DR-SX029D, K55DR-SX051H, K55DR-SX051V, ASUS [K55DR-SX072H](#) Laptop Battery, K55DR-SX072V-BE, K55DR-SX076H, K55DR-SX088D, K55DR-SX126D, K55DR-SX152D, K55DR-SX178H, K55DR1A, K55DRSX026H, K55DRSX026V, K55DRSX027H, K55DRSX027V, K55DRSX028D, K55DRSX029D, K55DRSX051H, ASUS [K55DRSX051V](#) Laptop Battery, K55DRSX072H, K55DRSX072VBE, K55DRSX076H, K55DRSX088D, K55DRSX126D, K55DRSX152D, K55DRSX178H, K55L89C, K55N, K55N-1A, K55N-BA8094C, K55N-DB81, K55N-DS81, ASUS [K55N-SA80403V](#) Laptop Battery, K55N1A, K55NBA8094C, K55NDB81, K55NDS81, K55NSA80403V, K55V, K55V Series, K55VD, K55VD Series, K55VD-3C, K55VD-3D, K55VD-3E, K55VD-3F, K55VD-3G, K55VD-3H, K55VD-DS71,

K55VD-QS71, K55VD-SK03S, K55VD-SX009H, K55VD-SX010H, K55VD-SX010S, K55VD-SX023D, K55VD-SX032X, K55VD-SX047V, K55VD-sx049v, K55VD-SX067H, ASUS [K55VD-SX068V](#) Laptop Battery, K55VD-SX069V, K55VD-SX071V, K55VD-SX091D, K55VD-SX135D, K55VD-SX138D, K55VD-SX234H, K55VD-SX313D, K55VD-SX314D, K55VD-SX404H, K55VD-SX443H, K55VD-SX595H, K55VD3C, K55VD3D, K55VD3E, K55VD3F, K55VD3G, K55VD3H, K55VDDS71, K55VDQS71, K55VDSK03S, K55VDSX009H, K55VDSX010H, ASUS [K55VDSX010S](#) Laptop Battery, K55VDSX023D, ASUS [K55VDSX032X](#) Laptop Battery, K55VDSX047V, K55VDSsx049v, K55VDSX067H, K55VDSX068V, K55VDSX071V, K55VDSX091D, K55VDSX135D, K55VDSX138D, K55VDSX234H, K55VDSX313D, K55VDSX314D, K55VDSX404H, K55VDSX443H, ASUS [K55VDSX595H](#) Laptop Battery, K55VJ, K55VJ Series, K55VJ-3C, K55VJ-3D, K55VJ-SX006H, K55VJ-SX017H, K55VJ-SX140H, K55VJ3C, K55VJ3D, K55VJSX006H, K55VJSX017H, K55VJSX140H, K55VM, K55VM Series, K55VM-3C, K55VM-3D, K55VM-SX006V, K55VM-SX027V, K55VM-SX031V, K55VM-SX032, K55VM-SX045V, K55VM-SX052V, K55VM-SX064V, K55VM-SX077V, K55VM-SX078D, K55VM-SX084V, K55VM-SX086D, K55VM-SX087V, K55VM-SX090V, K55VM-SX114D, K55VM-SX115D, K55VM-SX116D, K55VM-SX173V, K55VM3C, K55VM3D, K55VMSX006V, K55VMSX027V, K55VMSX031V, K55VMSX032, K55VMSX045V, K55VMSX052V, K55VMSX064V, K55VMSX077V, K55VMSX078D, K55VMSX084V, K55VMSX086D, K55VMSX087V, ASUS [K55VMSX090V](#) Laptop Battery, K55VMSX114D, K55VMSX115D, K55VMSX116D, K55VMSX173V, K55VS, K55VS Series, ASUS [K55X45DR-SL](#) Laptop Battery, K55X45DRSL, K55XI321VD-SL, K55XI321VDSL, K55XI321VM-SL, K55XI321VMSL, K55XI323VD-SL, K55XI323VDSL, K55XI361VD-SL, K55XI361VDSL, K55XI361VM-SL, K55XI361VMSL, K55XI555DP-SL, K55XI555DPSL, K56, K56 Series, K56C, K56C Series, K56CA, K56CA Series, K56CA-1A, K56CA-XO099D, K56CA-XO102D, K56CA-XO125H, K56CA-XO191P, K56CA-XO198H, K56CA-XX008H, K56CA-XX009H, ASUS [K56CA-XX009P](#) Laptop Battery, K56CA-XX044H, K56CA-XX050H, K56CA-XX058D, K56CA-XX059D, K56CA-XX062D, K56CA-XX096H, K56CA-XX108D, K56CA-XX139D, K56CA-XX166H, ASUS [K56CA-XX187H](#) Laptop Battery, K56CA1A, K56CAXO099D, K56CAXO102D, K56CAXO125H, K56CAXO191P, K56CAXO198H, K56CAXX008H, K56CAXX009H, K56CAXX009P, K56CAXX044H, K56CAXX050H, K56CAXX058D, K56CAXX059D, K56CAXX062D, K56CAXX096H, K56CAXX108D, K56CAXX139D, K56CAXX166H, K56CAXX187H, K56CB, K56CB-1A, K56CB-1B, K56CB-XO135H, K56CB-XO092H, K56CB-XO129H, K56CB-XX101H, K56CB-XX102H, K56CB-XX122H, K56CB-XX123H, K56CB-XX306H, K56CB1A, K56CB1B, K56CBXO129H, K56CBXX101H, K56CBXX102H, K56CBXX122H, K56CBXX123H, K56CBXX306H, K56CM, K56CM Series, K56CM-1A, ASUS [K56CM-XO213H](#) Laptop Battery, k56cm-xo282d, ASUS [K56CM-XX003H](#) Laptop Battery, ASUS [K56CM-XX008](#) Laptop Battery, K56CM-XX008H, K56CM-XX014, K56CM-XX014D, K56CM-XX039H, K56CM-XX054D, K56CM-XX054H, K56CM-XX055, K56CM-XX055D, K56CM-XX056D, K56CM-XX128H, K56CM-XX131H, K56CM-XX164H, K56CM-XX293H, K56CM1A, K56CMXO213H, k56cmxo282d, K56CMXX003H, K56CMXX008, K56CMXX008H, K56CMXX014, K56CMXX014D, K56CMXX039H, K56CMXX054D, K56CMXX054H, K56CMXX055, K56CMXX055D, K56CMXX056D, K56CMXX128H, K56CMXX131H, K56CMXX164H, K56CMXX293H, K56LM2H, K56V, K570ZD, K60, K60 Series, K601, ASUS [K601J](#) Laptop Battery, k601rbbbr05, K60I, K60IJ, K61, K61 Series, k611C, K61IC, K6C11 Series, K70, K70 Series, k7010, K701O, K70AB, ASUS [K70AC](#) Laptop Battery, K70AD, K70AE, K70AF, K70IC, K70IC Series, K70ID, K70IJ, ASUS [K70IJ Series](#) Laptop Battery, K70IL, K70IO, K70IO Series, K72, K72 Series, K72D, K72DR, K72DR-A1, K72DR-X1, K72DY, K72f, K72F Series, K72f-A1, K72F-A2B, K72F-B1, K72F-TY005V, K72F-TY130V, K72F-TY279V, K72F-

TY318V, K72F-X1, K72J, ASUS [K72JA](#) Laptop Battery, K72JB, K72JC, K72JE, K72JF, K72JH, K72JK, K72JK-A1, K72JK-TY001V, K72JK-X1, K72JL, K72JM, K72JO, K72JQ, K72JR, K72JR-A1, K72JR-B1, ASUS [K72JR-TY028X](#) Laptop Battery, K72JR-TY108V, K72JR-X1, K72JR-XN1, K72JT, K72JU, K72JV, K72JW, K72K, K72L, K72N, ASUS [K72P](#) Laptop Battery, K72Q, K72R, K72S, K72Y, K73 Series, K73E, K73E-A1, K73E-TY080V, K73E-TY202V, K73J, K73JK, K73S, K73SJ-TY020V, K73SJ-TY021V, K73SV, K73SV-A1, K73SV-DH51, K73SV-TY032V, K73SV-TY053V, ASUS [K73SV-TY082V](#) Laptop Battery, K73SV-TY137V, K73SV-TY147V, K73SV-TY171V, K73SV-TY201V, K73SV-TY291V, K73SV-TY299V, K73SV-TY300V, K73SV-TY381V, K73TA-TY027V, K75 Series, ASUS [K750J](#) Laptop Battery, K751L, K751LB-TY079H, K751LB-TY212T, K751LB-TY242T, K751LJ-T4305T-BE, K751LJ-TY059H, K751LJ-TY087H, ASUS [K751LJ-TY401T](#) Laptop Battery, K751LJ-TY414T, K751LJ-TY418T, K751LJ-TY452T, K751LN, K751LN4210, K751LX5200, K751MJ2940, K75A, ASUS [K75D](#) Laptop Battery, K75V, K75VM, K75VM-T2094V, K75VM-T2119V-BE, K75VM-TY02, K75VM-TY023V, K75VM-TY024V, K75VM-TY027, K75VM-TY086V, K75VM-TY090V, K75VM-TY096V, K75VM-TY12, K75VM-TY126, K75VM-TY126V, K75VMT2094V, K75VMT2119VBE, K75VMTY023V, K75VMTY024V, K75VMTY027, K75VMTY086V, K75VMTY090V, K75VMTY096V, K75VMTY126V, ASUS [K84](#) Laptop Battery, K84C, K84H, K84H Series, K84HO, K84HR, K84HY, K84KL, K84L, K84LY, ASUS [K84LY Series](#) Laptop Battery, K93, K93 Series, ASUS [K93S](#) Laptop Battery, K93S Series, K93SM, K93SM Series, K93SM-YZ017D, K93SM-YZ019V, K93SM-YZ036V, K93SM-YZ061V, K93SM-YZ072, K93SM-YZ081V, K93SM-YZ085V, K93SM-YZ099, K93SM-YZ115V, K93SV, K93SV Series, K93SV-YZ094V, K93SV-YZ125D, K93SV-YZ166, K93SV-YZ211V, K95, K95 Series, K95A, K95V, K95VM, K95VM-YZ001V, K95VM-YZ002V, K95VM-YZ005D, ASUS [K95VM-YZ006V](#) Laptop Battery, K95VM-YZ007V-BE, K95VM-YZ008V, K95VM-YZ009V, K95VM-YZ010V, K95VM-YZ013V, K95VM-YZ015V, K95VM-YZ030V, K95VM-YZ037V, K95VM-YZ045V, K95VM-YZ052, K95VM-YZ052., L3, L3 Series, L3000, L3000C, L3000D, L3000S, L3100, L3400, L3400C, L3400S, L3420, L3500, L3500T, L3600C, ASUS [L3800](#) Laptop Battery, L3800C, L3800D, L3800S, L3C, L3D, L3H, L3M, L3S, L3T, L406MA, L406MA-BV157TS, L406MA-DS24, ASUS [L406MA-EK954TS](#) Laptop Battery, L406SA, L5, L50 Series, L5000, L5000C, L5000D, L5000DF, L5000G, L5000GA, ASUS [L5000GM](#) Laptop Battery, L5000GX, L5500C, L5500D, L5500DF, L5500G, L5500GA, L5500GM, L5500GX, L55C, L55D, L55DF, L55G, L55GA, L55GM, L55GX, L5800C, L5800D, L5800DF, L5800G, L5800GA, L5800GM, L5800GX, ASUS [L58C](#) Laptop Battery, L58D, L58DF, L58G, L58GA, L58GM, L58GX, L5900C, L5900D, L5900DF, L5900G, ASUS [L5900GA](#) Laptop Battery, L5900GM, L5900GX, L59C, L59D, L59DF, L59G, L59GA, L59GM, L59GX, L5C, L5D, L5DF, L5G, L5GA, L5GM, L5GX, L7000, L7000B, L7000C, L7200, L7300, L7400, L8, ASUS [L8 Series](#) Laptop Battery, L8000, L8000 Series, L8000B, L8000B Series, L8000C, L8000C Series, L8000Ce, L8000Ce Series, L8000F, L8000F Series, L8000K, L8000K Series, L8000L, L8000L Series, L84, L84 Series, L8400, L8400 Series, L8400B, L8400B Series, L8400C, L8400C Series, L8400Ce, L8400Ce Series, L8400F, L8400F Series, ASUS [L8400K](#) Laptop Battery, L8400K Series, L8400L, L8400L Series, L84B, L84B Series, L84C, L84C Series, L84Ce, L84Ce Series, L84F, L84F Series, L84K, ASUS [L84K Series](#) Laptop Battery, L84L, L84L Series, Lamborghini VX6, Lamborghini VX65, Lamborghini VX6S, Ling Yao X, M2 Series, M2000, M2000 Series, ASUS [M2000A](#) Laptop Battery, M2000A Series, M2000C, M2000C Series, M2000E, M2000E Series, M2000N, ASUS [M2000N Series](#) Laptop Battery, M2000Ne, M2400, M2400 Series, M2400A, M2400C, M2400E, M2400N, M2400Ne, M2422N, M2442N, M2A, M2C, M2E, M2N, M2Ne, M3, M3000, M3000N, M3000NP, M3N, M3NP, M5, M50 Series, M5000, M5000A, M5000N, M5000NP, M50Q, M50Q Series, M50Sa, M50Sa Series, M50Sr, M50Sr Series, M50Sv, M50Sv Series, M50VM, M51 Series, M51A, M51E, ASUS [M51E Series](#) Laptop Battery, M51Kr, M51Kr Series,

M51Se, M51Se Series, M51Sn, M51Sn Series, M51Sr, M51Sr Series, ASUS [M51Ta](#) Laptop Battery, M51Tr, M51V, M51Va, M51Va Series, M51Vr, M51Vr Series, M5200A, M5200N, M52N, M5600N, M5A, M5AE, M5N, M5NP, M6, M6 Series, M60 Series, M6000, M6000A, M6000C, M6000N, M6000R, M6000V, M60J Series, ASUS [M60JV Series](#) Laptop Battery, M60Q Series, M60V Series, M60VP Series, M60W Series, M67, M6700, M6700A, M6700C, M6700N, M6700R, M6700V, M6706, M6722, M6742, M6762, M67N, M68, M6800, M6800A, M6800N, M6802N, M6806N, M6822N, M6842N, M6862N, M68A, M68C, M68N, M68R, M68V, M6A, M6B00N, M6C, M6N, M6Ne, M6R, M6V, M6Va, M7, M70, M70 Series, M700C, M700KL 1A, M700KL 1B, M70AD, M70L, M70S, M70SA, M70Sa Series, M70SR, M70Sr Series, M70T, M70TL, M70V, M70VC, M70VM, ASUS [M70vn](#) Laptop Battery, M70VR, M7V, M9, M9 Series, ASUS [M90V](#) Laptop Battery, M9A, M9F, M9J, M9V, MB VER K55VD, ME102A, ME102A 1A, ME102A 1B, ME102A 1F, ME175CG, ME175KG K00S, ME176C, ME176CX, ME181C, ME371, ME371MG, ASUS [ME560CG](#) Laptop Battery, ME571, ME571-32G, ME571-LTE, ME57132G, ME571K, ME571K K009, ME571K-1A078A, ME571K1A078A, ME571KL, ME571KL K008, ME571KL-1A004A, ME571KL-1A039A, ME571KL1A004A K00B, ME571KL1A039A, ASUS [ME571LTE](#) Laptop Battery, ME70CX, ME70CX K01A, ME715, ME7610C, ME7610CX, Memo Pad, MeMo Pad 10, MeMo Pad 10 K00F, MeMO Pad 10 ME0310K, MeMo Pad 10 ME102A, MeMo Pad 10 ME102A-1A018A, MeMo Pad 10 ME102A-1A030A, MeMo Pad 10 ME102A-1B023A, MeMo Pad 10 ME102A-1B028A, MeMo Pad 10 ME102A-1B032A, MeMo Pad 10 ME102A-1F027A, MeMo Pad 10 ME102AK00F, MeMO Pad 7, MeMO Pad 7 (ME70CX), MEMO PAD 7 inch, MeMO Pad 7 ME175CG K00Z, MeMO Pad 8 (AST21), MeMO Pad 8 (ME181C), ASUS [MeMO Pad 8 \(ME181C-1A008A\)](#) Laptop Battery, MeMO Pad 8 (ME181C-1A013A), MeMO Pad 8 (ME181C-1A027A), MeMO Pad 8 (ME181C-1B012A), MeMO Pad 8 (ME181C1A008A), MeMO Pad 8 (ME181C1A013A), MeMO Pad 8 (ME181C1A027A), MeMO Pad 8 (ME181C1B012A), MeMO Pad 8 (ME181CX) Serie, MeMO Pad 8 (ME181CX-1A035A), MeMO Pad 8 (ME181CX-1B036A), MeMO Pad 8 (ME181CX1A035A), MeMO Pad 8 (ME181CX1B036A), MeMO Pad 8 ME581CL Tabet, MEMO PAD HD 7, MEMO PAD K00A (ME302C), Memo Pad ME102, Memo Pad ME102A, MEMO PAD ME173X, MeMO Pad ME175KG HD 7, MeMO Pad ME7510KG, MemoPad 10.1, MemoPad Memo Pad ME173X, MID R50A, MV51VA, MX36 Series, MX51 Series, MX52 Series, MX65 Series, MX65-042, MX65042, MX66 Series, MX66-207, MX66207, N10, N10E, N10E, N10E-A1, N10J, N10J-A1, N10J-A2, N10JB, N10Jc, N10Jc, N10JC-A1, N10JH, N10JM, N10V, N10VN, N20, N20 Series, N20A, N2815, N43 Series, N43EI46JF-SL, N43EI52JF-SL, N43JF, N43S, N43SD, N43SL, N43SN, N43SV, N45, N45 Series, N45E, N45E Series, N45EI241SF-SL, N45EI243SF-SL, N45EI245SL-SL, N45EI263SF-SL, N45EI267SF-SL, N45EI267SL-SL, N45F, N45J, N45S, N45S Series, N45SF, N45SF Series, N45SF-V2G-VX041V, N45SF-V2G-VX042V, N45SL, N45SL Series, N46, N46EI321VM-SL, N46EI321VMSL, N46EI321VZ-SL, N46EI321VZSL, N46EI323VZ-SL, N46EI323VZSL, N46EI361VM-SL, N46EI361VMSL, N46EI361VZ-SL, N46EI361VZSL, n46jv, N46V, N46VB, N46VJ, N46VJ N46VM, N46VM, N46VZ, N50, N50 SERIES, N501JW, N501JW-1A, N501JW-1B, N501JW-2A, N501JW-2B, N501L, N501VW, N501VW-2B, N501VW2B, N50VC, N50VC Series, N50VC-B3WM, N50VC-FP008C, N50VC-FP021C, N50VC-FP035G, N50VC-FP044C, N50VC-FP106C, N50VC-FP125C, N50VC-FP154C, N50VC-FP164C, N50VC-FP168C, N50VC-FP190C, N50VC-FP192C, N50VC-FP212E, N50VC-FP216E, N50VC-FP222E, ASUS [N50VC-FP233E](#) Laptop Battery, N50VCFP154C, N50VCFP164C, N50VCFP168C, N50VCFP190C, N50VCFP192C, N50VCFP212E, N50VCFP216E, N50VCFP222E, N50VCFP233E, N50VN, N50VN Series, N50VN-A1B, N50VN-B1B, N50VN-C1S, N50VN-C2S, N50VN-D1, N50VN-FP024G, N50VN-FP154C, N50VN-FP229E, N50VN-T9550, N50VN-X5A, N50VN-X6, N50VNA1B, N50VNB1B, N50VNC1S, N50VNC2S, N50VND1, N50VND1, N50VNFP024G, N50VNFP024G, N50VNFP154C,

N50VNFP154C, N50VNFP229E, N50VNFP229E, N50VNT9550, N50VNT9550, N50VNX5A, N50VNX5A, ASUS [N50VNX6](#) Laptop Battery, ASUS [N50VNX6](#) Laptop Battery, N51 Series, N51-Vf, N51A, N51S, N51TP, N51V, N51VF, ASUS [N51VF-A1](#) Laptop Battery, N51VF-X1, N51VF-X2, N51VFA1, N51VFX1, N51VFX2, N51VG, N51VG-SX039C, N51VN, N51VN-A1, N51VN-X1A, N51VNA1, N51VNX1A, N52, N522V, N52A, N52D, N52DA, N52DC, N52DR, N52F, N52J, N52JA, N52JB, N52JC, N52JE, N52JF, N52JG, N52JL, ASUS [N52JN](#) Laptop Battery, N52JQ, N52JT, N52JV, N52S, N52SN, N52SV, N52V, N52VF, N53J, N53JF, N53JF-a1, ASUS [N53JQ](#) Laptop Battery, N53JQ-A1, N53S, N53SV, N543UA, N55, N55 Series, N550, N550J, N550J-CN244H, N550Ja, N550JA-1A, N550JA-CM012H, N550JA-SB71T, N550JA-XO011H, N550JA-XO023H, N550JK, N550JK-1A, N550JK-1B, N550JK-CM097H, N550JK-CM137H, N550JK-CM141H, N550JK-CM175H, N550JK-CM362H, N550JK-CM452H, N550JK-CM467H, N550JK-CM489H, N550JK-CM493H, N550JK-CM525H, N550JK-CM531H, N550JK-CM604H, N550JK-CN001H, N550JK-CN002H, N550JK-CN015H, N550JK-CN042H, N550JK-CN057H, N550JK-CN090H, N550JK-CN096H, N550JK-CN102H, N550JK-CN109H, ASUS [N550JK-CN110H](#) Laptop Battery, N550JK-CN111H, N550JK-CN112H, N550JK-CN113H, N550JK-CN149H, N550JK-CN166H, N550JK-CN167D, N550JK-CN168H, N550JK-CN239H, N550JK-CN241H, N550JK-CN274H, N550JK-CN296H, N550JK-CN297H, N550JK-CN298H, N550JK-CN323, N550JK-CN338D, N550JK-CN352H, N550JK-CN360H, N550JK-CN372H, N550JK-CN393D, N550JK-CN412H, N550JK-CN453H, N550JK-CN457H, N550JK-CN466H, N550JK-CN539D, N550JK-CN565H, N550JK-DB74T, N550JK-DS507H, N550JK-DS580H, N550JK-DS71T, N550JV, N550JV-1A, N550JV-1B, N550JV-CM068H, N550JV-CM205H, N550JV-CM230H, N550JV-CM233H, N550JV-CMI7BR, N550JV-CN088H, N550JV-CN127H, N550JV-CN139H, N550JV-CN199H, N550JV-CN200H, N550JV-CN201H, N550JV-CN229H, N550JV-CN240H, N550JV-CN241H, N550JV-CN253H, N550JV-CN270H, ASUS [N550JV-CN277H](#) Laptop Battery, N550JX, N550JX-1A, N550JX-1C, N550JX-CM037H, N550JX-DS71T, N550JX-DS74T, ASUS [N550JX-FI057H](#) Laptop Battery, N550LF, N550LF-1A, ASUS [N550LF-CK026H](#) Laptop Battery, N550LF-CK064H, N550LF-CK095H, N550LF-CK108H, N550LF-CM025H, N550LF-CM094H, N550LF-CM115H, N550LF-CN023H, N550LF-CN037H, N550LF-CN061H, N550LF-CN065H, N550LF-CN077H, ASUS [N550LF-CN083H](#) Laptop Battery, N550LF-CN087H, N550LF-CN099H, N550LF-CN100H, ASUS [N550LF-CN126H](#) Laptop Battery, N550LF-XO029H, N550LF-XO036H, N550LF-XO068H, N550LF-XO069H, N550X47JV, N550X47JV-S, N550X47JV-SL, N551, N551J, N551JB, N551JB-1A, N551JB-2A, N551JB-8A, N551JB-CN001H, N551JB-CN021H, N551JB-CN029H, N551JB-DM019H, N551JK, N551JK-1A, N551JK-1B, N551JK-CN124H, N551JK-CN125H, N551JK-CN166H, N551JK-CN167H, N551JK-CN173H, N551JK-CN175H, N551JK-CN176H, N551JK-CN177H, N551JK-CN189H, N551JK-CN220H, N551JK-CN283H, N551JK4200, N551JM, N551JM-1A, N551JM-1B, N551JM-1C, N551JM-CN029H, N551JM-CN078H, ASUS [N551JM-XO023D](#) Laptop Battery, N551JM4200, N551JM4710, N551JN, N551JQ, N551JQ-1A, N551JQ-2A, N551JQ-AS71, N551JQ-CN003H, N551JQ-CN037H, N551JQ-CN094H, ASUS [N551JQ-CN218H](#) Laptop Battery, N551JQ-DS71, N551JQ-EH71, N551JV, N551JW, N551JW-1A, N551JW-1B, N551JW-1C, N551JW-CN079H, N551JW-CN094H, N551JW-CN095H, N551JW-CN217H, N551JW-XX477H, N551JW4200, N551JW4720, N551JX, N551JX-1A, N551JX-1B, N551JX-1C, N551JX-8A, N551JX-CN034H, ASUS [N551JX-CN079H](#) Laptop Battery, N551JX-CN080H, N551JX-CN083H, N551JX-CN156H, N551JX-CN157H, N551JX-CN203H, N551JX-CN215H, N551jx-dm341t, N551VW, N551VW-1A, N551VW-1B, N551VW-1C, N551VW-8A, N551vw-cn057t, N551VW-CN058T, N551VW-CN089T, N551VW-FY196T, N551VW-FY197T, N551Z, N551ZU, ASUS [N551ZU-1A](#) Laptop Battery, ASUS [N551ZU-CN007H](#) Laptop Battery, N551ZU-CN010D, N551ZU-CN024H, N551ZU-DM002H, N551ZU7400, N551ZU7600, N552, N552V, N552V-W-FY136T, N552VW,

N552VW-1A, N552VW-1B, N552VW-2A, N552VW-FI040T, N552VW-FI043T, N552VW-FI056T, N552VW-FI057T, N552VW-FI061T, N552VW-FI140T, N552VW-FI202T, N552VW-FW026T, N552VW-FW055T, N552VW-FY059T, ASUS [N552VW-FY060T](#) Laptop Battery, N552VW-FY083T, N552VW-FY132T, N552VW-FY136T, N552VW-FY254T, N552VW1A, N552VW1B, N552VW2A, N552VWFI040T, N552VWFI043T, N552VWFI056T, N552VWFI057T, N552VWFI140T, N552VWFI202T, N552VWFW026T, N552VWFW055T, ASUS [N552VWFWY059T](#) Laptop Battery, N552VWFWY060T, N552VWFWY083T, N552VWFWY132T, N552VWFWY136T, N552VWFWY254T, N552VX, N552VX -FY024D, N552VX FY024D, N552VX-1A, N552VX-2A, N552VX-76A95SB1, N552VX-FI018T, N552VX-FW027T, N552VX-FW038T, N552VX-FW067T, N552VX-FW097T, ASUS [N552VX-FW120T](#) Laptop Battery, N552VX-FW131T, N552VX-FW140T, N552VX-FW197T, N552VX-FW198T, N552VX-FW320T, N552VX-FY012T, N552VX-FY017T, N552VX-FY024D, N552VX-FY026T, N552VX-FY071T, N552VX-FY103T, N552VX-FY104T, N552VX-FY105T, N552VX-FY113T, N552VX-FY137T, N552VX-FY200T, N552VX-FY209D, N552VX-FY299T, N552VX-FY382T, ASUS [N552VX1A](#) Laptop Battery, N552VX2A, N552VXFI018T, N552VXFW027T, N552VXFW038T, ASUS [N552VXFW097T](#) Laptop Battery, N552VXFW120T, N552VXFW131T, N552VXFW140T, N552VXFW197T, N552VXFW320T, N552VXFY012T, N552VXFY017T, N552VXFY024D, N552VXFY026T, N552VXFY071T, N552VXFY103T, N552VXFY104T, N552VXFY105T, N552VXFY137T, N552VXFY200T, N552VXFY209D, N552VXFY299T, N552VXFY382T, N55E, N55E Series, N55EI243SF-SL, N55JX-CN037, N55S, N55S Series, N55SF, ASUS [N55SF Series](#) Laptop Battery, N55SF-1284V Series, ASUS [N55SF-A1](#) Laptop Battery, N55SF-S1150V, N55SF-S2151V, N55SL, N55SL Series, N55VW, N55XI243SF-SL, N55XI245SL-SL, N55XI263SF-SL, N55XI267SF-SL, N55XI267SL-SL, N56, N56-VJ, N56D, N56DP, N56DY, N56J, N56JK, N56JN, N56JN-CN086H, N56JNCN086H, N56JR, N56JR-FHD, N56JR-S4045H, N56L82H, N56V, N56V-N56L82H, N56V8, N56VB, N56VB-S3200H, N56VB-S4050H, N56VBS3200H, N56VBS4050H, N56VJ, ASUS [N56VJ-DH71](#) Laptop Battery, N56VJDH71, N56VM, N56VM-4110V, N56VM-84034V, N56VM4110V, N56VM84034V, N56VN56L82H, N56VV, N56VV-S3043H, N56vv-S4007h, N56VVS3043H, ASUS [N56vvS4007h](#) Laptop Battery, N56VZ, N56VZ S3226, N56VZ-4232H, N56vz-ds71, N56VZ-S3343H, N56VZ-S4027V, N56VZ-S4160V, N56VZ-S4278H, N56VZ-S4384H, N56VZ4232H, N56vzds71, N56VZS3343H, N56VZS4027V, N56VZS4160V, N56VZS4278H, N56VZS4384H, N56X45DP-SL, N56X45DPSL, N56XI321VM-BL, N56XI321VM-SL, N56XI321VMBL, N56XI321VM-SL, N56XI321VZ-SL, N56XI321VZSL, N56XI323VV-SL, N56XI323VVSL, ASUS [N56XI323VZ-SL](#) Laptop Battery, N56XI323VZSL, N56XI361VM-SL, N56XI361VM-SL, N56XI361VZ-SL, N56XI361VZSL, ASUS [N56XI363VZ-SL](#) Laptop Battery, N56XI363VZSL, ASUS [N580gd](#) Laptop Battery, N580VD, N580VN, N593UB, N593UB-1A, N593UB1A, N61, N61J, N61Ja, N61jq, ASUS [N61Jv](#) Laptop Battery, N61Vg, N61Vn, N61w, ASUS [N70](#) Laptop Battery, N70S, N70SV, N70SV-b1, N70SV-TY043C, N70SV-TY081C, N70Sv-TY127C, N70SV-x1, N71, N71 Series, N71J, N71Ja, N71Jq, N71JQ-A1, N71JQ-X1, N71JQ-X2, N71JQ-XT1, N71JV, N71V, N71VG, N71VN, N71VN-TY011V, N71VN-TY013V, N71VN-TY014V, N71YI, ASUS [N73](#) Laptop Battery, N73 Series, N73F, N73G, N73J, N73JF, ASUS [N73JG](#) Laptop Battery, N73JN, N73JN-TY021, N73JN-TY021V, N73JN-TY035V, N73JN-TY069X, N73JQ, N73JQ-XV1, N73Q, N73SD, N73SL, N73SN, N73SQ, N73SV, N73SV-A1, N73SV-A1-CBIL, N73SV-A3, N73SV-A3-CBIL, N73SV-DH72, N73SV-QH72-CBIL, ASUS [N73SV-V1G](#) Laptop Battery, N73SW, N73V, N75, N75 Series, N750JK, N750JK-T4092H, N750JV, N750Y47JV, N750Y47JV-SL, N751, N751J, N751JK, N751JK-T4144H, ASUS [N751JK-T4160H](#) Laptop Battery, N751JK-T4199H, N751JK-T4205H, N751JK-T7085H, N751JK-T7118H, N751JK-T7234H, N751JK-T7245H, N751JM, N751JQ, N751JW, N751JX, N752, N752V, N752VW, N752VX, N752VX-GC088T, N752VX-GC101T, N752VX-

GC128T, N752VX-GC133T, N752VX-GC134T, N752VX-GC190T, N752VX-GC197T, N752VX-GC234T, N752VX-GC249T, N752VXGC088T, N752VXGC101T, N752VXGC128T, N752VXGC133T, N752VXGC134T, N752VXGC190T, N752VXGC234T, N75E, N75E Series, N75S, N75S Series, N75SF, N75SF Series, N75SF-A1, N75SF-V2G-TZ04V, N75SF-V2G-TZ060V, N75SL, N75SL Series, ASUS [N75SL-V2G-TZ033V](#) Laptop Battery, N75VZ, N75YI267SL-SL, ASUS [N76](#) Laptop Battery, N76V, N76VB, N76VJ, N76VM, N76VZ, N76VZ-DH71-CA, N76VZ-DS71, N76VZDH71CA, N76VZDS71, ASUS [N76YI361VZ-SL](#) Laptop Battery, N76YI361VZSL, N76YI363VZ-SL, N76YI363VZSL, N80 Series, N80Vc, N80VM, N80VM-1A, N80VM-1B, N80VM-2B, N80VM-X2, N80VM1A, N80VM1B, N80VM2B, N80VMX2, N80Vn, N80VR, N81 Series, ASUS [N81Vg](#) Laptop Battery, N81Vp, N82, N82 Series, N82E, N82EI, N82J, N82JQ, N82JQ-VX002V, N82JV, N82JV-VX020V, N90, N90S, N90Sc, N90SC-A1, N90SC-UZ008V, N90SC-UZ024V, N90SV, N90SV-UZ022C, N90SV-UZ058C, N90SV-X1, NJ550JV, Note6, Notebook B Series B451JA, NOTEBOOK X455, NOTEBOOK X455LA, NOTEBOOK X455LD, NV752VX-GC101T, NX580VD7300, NX580VD7700, NX90 Series, NX90J, NX90JQ Series, P022, P024, ASUS [P1402FA](#) Laptop Battery, P1402UA, P1402UB, P1410UA, P1410UA-BV469R, P1410UA-BV706R, ASUS [P1410UA-EB451R](#) Laptop Battery, P1410UF, P1801, P2430 UA, P2430L, P2430LJ, P2430U, P2430UA, P2430UA-FA0789R, P2430UA-WO0079D, P2430UA-WO0144E, P2430UA-WO0543D, P2430UA-WO0646R, P2430UA-WO0646R-OSS, P2430UA-WO0791R, P2430UA-WO0800, P2430UA-WO0800R, P2430UA-WO0801R, P2430UA-WO0815D, P2430UA-WO1112R, P2430UA-WO1113T, P2430UA-WO1127D, P2430UA-XH53, P2430UA-XH73, P2430UJ, P2430UJ-WO0062D, P2430UJ-WO0186R, P2430UJ-WO0211E, P2430UJ-WO0350R, P2430UJ-WO0380D, P2438U, P2438U-0341A6500U, P2438U-0351A6200U, P2438U-0401A6500U, P2438U-0411A6200U, P2438U0, P2438U1, P2438U2, P2438U3, P2438U4, P2438U5, P2438U6, P2438U7, P2438U8, P2438U9, P2438UA, P2438UA-FA0327T, P2438UB, P2438UC, P2438UD, P2438UE, P2438UF, P2438UG, P2438UH, P2438UI, P2438UJ, P2438UK, P2438UL, P2438UM, P2438UN, ASUS [P2438UO](#) Laptop Battery, P2438UP, P2438UQ, P2438UR, P2438US, P2438UT, P2438UU, P2438UV, P2438UW, P2438UX, P2438UY, P2438UZ, P2440UA, P2440UA-1A, P2440UA-1B, P2440UA-FQ0155R, P2440UA-FQ0221R, P2440UA-XS51, P2440UF, P2440UF-1A, ASUS [P2440UF-1B](#) Laptop Battery, ASUS [P2440UQ](#) Laptop Battery, P2440UQ-1A, P2440UQ-1B, P24E, ASUS [P24E-PX023V](#) Laptop Battery, P24E-PX023X, P24EPX023V, P24EPX023X, P2501LA-XH52, P2520LA, P2520LA-XB31, P2520LA-XB51, P2520LA-XH31, P2520LA-XH52, P2520LA-XH71, P2520LA-XO0040G, P2520LA-XO0084G, P2520LA-XO0167H, P2520LA-XO0220G, P2520LA-XO0231G, P2520LA-XO0281T, P2520LA-XO0385T, P2520LA-XO0519D, P2520LA-XO0526D, P2520LA-XO0774E, P2520LJ, P2520LJ-DM0114R, P2520LJ-XO0028G, P2520LJ-XO0029E, P2520LJ-XO0029G, P2520LJ-XO0030E, ASUS [P2520LJ-XO0030G](#) Laptop Battery, P2520LJ-XO0074H, P2520LJ-XO0088G, P2520LJ-XO0090G, ASUS [P2520LJ-XO0171G](#) Laptop Battery, P2520LJ-XO0175T, P2520SA-XO0004D, P2520SA-XO0004T, ASUS [P2520SA-XO0044D](#) Laptop Battery, P2530U, P2530UA, P2530UA-DM0025E, P2530UA-DM0047E, P2530UA-DM0050E, P2530UA-DM0114E, P2530UA-DM0179E, P2530UA-DM0384T, P2530UA-DM0437R, P2530UA-DM0489R, P2530UA-DM0525D, P2530UA-DM1255R, P2530UA-DM1264R, P2530UA-DM1273R, P2530UA-DM1274R, P2530UA-XH31, P2530UA-XH52, P2530UA-XO0030E, P2530UA-XO0042E, P2530UA-XO0081R, P2530UA-XO0119D, P2530UA-XO0169E, P2530ua-xo016be, P2530UA-XO0178RB, P2530UA-XO0207R, P2530UA-XO0235E, P2530UA-XO0288R, P2530UA-XO0375D, P2530UA-XO0375R, P2530UA-XO0381D, P2530UA-XO0382T, P2530UA-XO0383T, P2530UA-XO0488T, P2530UA-XO0492D, P2530UA-XO0517R, P2530UA-XO0598D, P2530UA-XO0599E, P2530UA-XO0651E, P2530UA-XO0651R, P2530UA-XO0784R, P2530UA-XO0832E, P2530UA-XO0832R, P2530UA-XO0840R, P2530UA-XO0843R, P2530UA-

XO0868D, P2530UA-XO0876R, P2530UA-XO1246D, P2530UA-XO598E, P2530UJ-DM0134E, P2530UJ-DM0134R, P2530UJ-DM0145E, P2530UJ-DM0145R, P2530UJ-DM0474R, P2530UJ-XO0045D, ASUS [P2530UJ-XO0102E](#) Laptop Battery, P2530UJ-XO0103E, P2530UJ-XO0103R, P2530UJ-XO0104E, P2530UJ-XO0104R, P2530UJ-XO0170E, P2530UJ-XO0315E, P2530UJ-XO0541R, P2530UJ-XO0542R, P2530UJ-XO0543R, P2540NV, P2540NV-1A, P2540NV-1B, P2540UA, P2540UA-1A, P2540UA-1B, P2540UA-AB51, P2540UB, P2540UB-1A, P2540UB-1B, P2540UB-XB71, P2540UV, P2540UV-1A, P2540UV-1B, P30, P30A, P30AG, P30G, P31, P31 Series, P31F, P31J, P31JC, P31JG, P31S, P31SD, P3440, P3540, P3540FA, P3540fa-0091a8265u, P3540fa-0101a8565u, P3540FA-BQ0034, P3540FA-BQ0067R, P3540FA-BQ0072R, P3540FA-BQ0079R, P3540FA-BR0142R, P3540fa-ej00056r, P3540fa-ej0056r, P3540fa-ej0058r, P3540FB, P3548FA, P3548FB, P41, P41 Series, P41F, P41J, P41JC, ASUS [P41JF](#) Laptop Battery, P41JG, P41S, P41SV, P43, P43E, P43EB, P43EI, P43F, P43J, P43JC, P43JC Series, P43S, P43SJ, P43SL, P450C, P450C Series, P450CA, P450CA Series, P450CA-WO160G, P450CA-XH51, P450CC, P450CC Series, P450L, P450L Series, P450LA, P450LA Series, P450LB, ASUS [P450LB Series](#) Laptop Battery, P450LC, P450LC Series, P450V Series, P450VB, P450VB Series, P450VC, P450VC Series, P451, P451C, ASUS [P451CA](#) Laptop Battery, P452LA, P452LA-1A, P452LJ, ASUS [P452LJ-1A](#) Laptop Battery, ASUS [P452LJ-1B](#) Laptop Battery, P452SA, P452SA-1A, P452SJ, P452SJ-1A, ASUS [P452SJ-1B](#) Laptop Battery, P453UA, P453UA-1A, P453uj, P4540UQ, P4540UQ-1A, P45VA, P45VD, P45VJ, P46C, P46CA, P46CB, P46CM, P46V, P50, P50 Series, P50IJ, P53, P5340FF, P53E, P53E Series, ASUS [P53E-SO127X](#) Laptop Battery, P53E-XS51, P53ESO127X, P53EXS51, P53F, P53J, P53JC, P53S, P53SJ, P53SJ Series, P53XI, P5403U, P5430UA, P550-LAV-XO4290, P550C, P550C Series, P550CA, P550CA Series, P550CA-XH31, P550CA-XH51, P550CA-XH71, P550CA-XO330D, P550CA-XO330G, P550CA-XO482G, P550CA-XO522D, P550CA-XO522G, P550CA-XO600G, P550CA-XO601G, P550CC, P550CC Series, ASUS [P550CC-XO1129G](#) Laptop Battery, P550CC-XO558G, P550CC-XO747G, P550CC-XO989G, P550L, P550L Series, P550L-XO429H, P550LA, P550LA Series, P550LA-XX2126, P550LAV, P550LAV-XO1046H, P550LAV-XO1047H, P550LAV-XO397D, P550LAV-XO397G, P550LAV-XO397H, P550LAV-XO429D, P550LAV-XO429G, P550LAV-XO429GA, P550LAV-XO429H, P550LAV-XO514D, P550LAV-XO514G, P550LAV-XO514H, P550LAV-XO598G, ASUS [P550LAV-XO974D](#) Laptop Battery, P550LAV-XO974G, P550LAV-XO974H, P550LAV-XX599D, P550LAV-XX765D, P550LAV-XX787G, P550LAV-XX893G, P550LC, P550LC Series, ASUS [P551](#) Laptop Battery, P551C, P551CA-SX298D, P551CA-SX299D, P551CA-SX299H, P551CA-SX313D, P551CA-SX313H, P552E, P552EP, P552LA, P552LJ, P552SA, P552SJ, P553UA, P553UJ, P55V, P55VA, P56CB, P56CB-XO184G, P574FA, P574FB, P750LB, P750LB-T2057G, P750LB-T2062G, ASUS [P750LB-T2062GA](#) Laptop Battery, P750LB-T2063G, P750LBT2057G, P750LBT2062G, ASUS [P750LBT2062GA](#) Laptop Battery, P750LBT2063G, P81, P81 Series, P81IJ, P81U, P93L, Pad MeMO Pad ME181C MeMO Pad 8, Pad MeMO Pad ME181CX MeMO Pad 8, Pad MeMO Pad ME302C, Pad MeMO Pad ME302KL, Pad MeMO Pad ME8110C MeMO Pad 8, Pad Transformer Book T100TAL, Pad Transformer Book TX201LA, ASUS [Pad VivoTab M81C VivoTab 8](#) Laptop Battery, PAD VIVOTAB SERIES, Padfone 2 (A68) Tablet PC, PadFone A66, PadFone Infinity A80, PadFone S P92L, PadFone S P92L(Pad), PadFone S P93L(Pad), PadFone S PF500KL(Phone), PADFONE SERIES, Padfone Station A80, Padfone Station P05, PadFone X Mini 45, PadFone X Mini 45 4G, PADFONE X MINI T00S, PC1215N, PE574FA, ASUS [PE574FB](#) Laptop Battery, PF450CL, PF500K, PF500KL, PL30 SERIES, PL30J, PL30JT, PL30JT-R0112X, PL30JT-RO025X, PL30JT-RO029X, PL30JT-RO030V, PL30JT-RO030X, PL30JT-RO040X, PL30JT-RO062V, PL30JT-RO080X, PL30JT-RO084, PL80 SERIES, PL80J, ASUS [PL80JT](#) Laptop Battery, PL80JT-RO018X, ASUS [PL80JT-WO018X](#) Laptop Battery, ASUS [PL80JT-WO021X](#) Laptop Battery,

PL80JT-WO036X, PL80JT-WO055V, PL80JT-WO055X, PL80JT-WO065V, PL80VT, ASUS [Portable AiO PT2001](#) Laptop Battery, Pro 14 R424FA, Pro 14 R424FA-EK109R, Pro 14 R459UA, Pro 3548FB, Pro 52, Pro 52H, Pro 52L, Pro 52R, Pro 52RL, Pro 574FB, PRO 66I, PRO 66IC, PRO ADVANCED B551LG-1A, PRO ADVANCED B551LG1A, PRO Advanced BU201 Series, PRO Advanced BU201L Series, PRO Advanced BU201LA, PRO Advanced BU201LA Series, PRO Advanced BU201LA-DT022G, PRO Advanced BU201LA-DT028G, PRO Advanced BU201LA-DT030G, PRO Advanced BU201LA-DT036G, PRO ADVANCED BU400 Ultrabook Series, PRO ADVANCED BU400A Ultrabook Series, PRO ADVANCED BU400V Ultrabook Series, Pro B551, PRO B551 SERIES, Pro B551L, PRO B551L SERIES, Pro B551LA, Pro B551LG, PRO B551LG SERIES, Pro B551LG-CN009G, Pro B551LGCN009G, Pro B9440, PRO B9440UA, PRO BU400 Ultrabook, PRO BU400A Ultrabook, PRO BU400V Ultrabook Series, Pro Essential P2520LA, Pro Essential P2520LA-XO0164G, Pro Essential P2520LA-XO0290E, Pro Essential P2520LA-XO0291T, Pro Essential P2520LA-XO0561D, Pro Essential P2520LJ, Pro Essential P2520LJ-XO0027G, Pro Essential P2520LJ-XO0028E, PRO P2430UJ, Pro P2440UA, Pro P2440UA-FA0005R, ASUS [Pro P2440UA-FA0006R](#) Laptop Battery, ASUS [Pro P2440UA-FA0007R](#) Laptop Battery, Pro P2440UQ, Pro P2440UQ-FA0004R, ASUS [Pro P2440UQ-FA0006R](#) Laptop Battery, Pro P2530UA, Pro P2530UA-XO0081R, Pro P2530UA-XO0288R, Pro P2530UA-XO0375D, Pro P2530UA-XO0375R, Pro P2530UA-XO0381D, Pro P2530UA-XO0383T, Pro P2530UA-XO0919D, Pro P2530UA-XO0922T, Pro P2530UA-XO0923R, Pro P2530UA-XO1241R, Pro P2530UA-XO1242D, Pro P2530UA-XO1280D, Pro P2530UA-XO1281R, Pro P2530UA-XO1282R, Pro P2540NV, Pro P2540NV-YH21, Pro P2540UA, Pro P2540UA-DM0093T, Pro P2540UA-DM0094T, Pro P2540UA-DM0095T, Pro P2540UA-XO0025D, Pro P2540UA-XO0086D, Pro P2540UV, Pro P2540UV-DM0006R, Pro P2540UV-DM0035D, Pro P2540UV-DM0042R, PRO P5340, PRO P5340UA, PRO P5340UF, ASUS [Pro P56CB-XO193G](#) Laptop Battery, Pro P56CBXO193G, ASUS [PRO PU404](#) Laptop Battery, PRO ULTRABOOK, PRO23, PRO24E, PRO31P, PRO32 SERIES, PRO32A, PRO32JT, PRO32U, PRO32VJ, PRO32VM, PRO32VT, Pro3548FA, PRO450, PRO450C, PRO450CD, PRO450V, PRO450VB, Pro4GJM, Pro4H Series, Pro4J Series, PRO4JEI245SJ-SL, Pro4KVM, Pro4M Series, PRO4P Series, Pro550C, Pro550CA, Pro550CC, ASUS [Pro574FA](#) Laptop Battery, PRO5C, PRO5D, PRO5E, PRO5G SERIES, PRO5GAG, PRO5GAT, PRO5GVG, PRO5GVS, PRO5GVT, PRO5J, PRO5N, PRO5NBE, PRO5NSD, PRO5NTA, PRO5PE, PRO61S, PRO65, PRO66, Pro70, Pro70C, Pro70Db, ASUS [Pro70Dc](#) Laptop Battery, Pro70F, Pro70J, Pro70S, Pro70Sv, Pro70T, Pro70V, PRO79, Pro79 Series, Pro79AB, Pro79AC, Pro79AD, Pro79AE, Pro79AF, Pro79IC, Pro79ID, Pro79IJ, Pro79IO, Pro80 Series, Pro80E, Pro80F, Pro80Fm, Pro80H, Pro80Hm, ASUS [Pro80Jc](#) Laptop Battery, Pro80Jn, Pro80Jp, Pro80Jr, Pro80Js, Pro80Jt, Pro80Le, Pro80N, Pro80Sc, Pro80Se, Pro80Sr, PRO88, PRO8B, PRO8BC, PRO8BID, PRO8BIE, PRO8BIJ, PRO8BIL, PRO8BIN, PRO8BIP, PRO8D, PRO8DIJ, PRO8GBY, PRO8GSM, PRO91S, PRO91SM, PRO91SV, PT2001, PT2001-04, PT2001-05, PT2002, ASUS [PT2002-C1](#) Laptop Battery, PT91, PU 551LD, PU301, PU301L, PU301LA, PU301LA-RO064G, PU31L, PU401, PU401E4010LA, PU401E4200LA, PU401E4288LA, PU401E4500LA, ASUS [PU401L](#) Laptop Battery, PU401LA40384DX3, PU404, PU404UF, PU404UF8250, PU404UF8250 4GB/16GB 1TB, PU404UF8250 4GB/1TB, ASUS [PU404UF8250 4GB/256GB](#) Laptop Battery, PU404UF8250 8GB/256GB, PU404UF8550, PU404UF8550 4GB/1TB, PU404UF8550 8GB/256GB, PU450, PU450C, PU450CD, PU450V, PU450VB, PU451, PU451J, PU451JF, PU451JH, PU451L, PU451LA, PU451LD, PU500C, PU500CA, PU550, PU550C, PU550CA, PU550CC, PU551, PU551J, PU551JA, PU551JA-XO009, PU551JA-XO058G, PU551JD, PU551JD-CN026G, ASUS [PU551JF](#) Laptop Battery, PU551JH, PU551L, PU551LA, PU551LA-XO018G, PU551LA-XO028G, PU551LA-XO036G, PU551LA-XO036H, PU551LA-XO042G, PU551LA-XO149G, PU551LA-XO152G, PU551LA-XO153G, PU551LA-XO164G, PU551LA-XO194G, PU551LA-XO261G, PU551LA-XO359G, PU551LA-

XO413G, PU551LD, PU551LD-CN082G, ASUS [PU551LD-XO025G](#) Laptop Battery, PU551LD-XO026G, PU551LD-XO052D, PU551LD-XO078G, PU551LD-XO079G, PU551LD-XO088D, PU551LD-XO089D, PU551LD-XO098G, PULA551-XO036H, PX553VD-FY144R, PX574F, PX574FA, PX574FB8265, PX574FB8565, PX753VD-GC047R, PX753VD-GC081R, PX753VE, Q301L, Q302L, Q302LA-BBI5T14, Q302LA-BBI5T19, Q302LA-BHI3T09, Q302LA-BSI5T16, Q304UA, ASUS [Q325U](#) Laptop Battery, Q325UA, Q325UA-BI7T21, ASUS [Q326FA](#) Laptop Battery, Q326FA-BI7T13, Q400, Q400A, Q400A-BHI7N03, Q400C, Q400V, Q400VC, Q500A, Q501L, Q501LA, Q501LA-BBI5T03, Q502L, Q502LA, Q502LA-BBI5T12, Q503, ASUS [Q503U](#) Laptop Battery, Q503UA, Q504U, Q504UA, Q504UA-BBI5T12, Q504UA-BHI5T13, Q504UA-BHI7T21, Q504UA-BI5T26, Q504UAK, Q505UA, Q505UA-BI5T7, Q505UABI5T7, Q524U, Q524UQ, Q524UQ-BBI7T14, Q524UQ-BHI7T15, Q525UA, Q525UA-BI7T9, ASUS [Q525UABI7T9](#) Laptop Battery, Q526U, Q534U, Q534UA, Q534UX, Q534UX-B, Q534UX-BHI7T19, ASUS [Q534UX-BI7T22](#) Laptop Battery, Q534UXBHI7T19, Q535U, Q535UD-BI7T11, Q536FD, Q536FD-BI7T15, Q550L, Q550LF, Q550LF-1A, Q550LF-bb17t07, Q550LF-BBI7T07, Q550LF-BSI7T21, Q551, Q551L, Q551LN, Q553U, QCWB335, R1 Series Tablet PC, R103B, R103ba-df066h, R104HA, R104HA-FU020T, R1E, R1F, R2 Series, R202CA, R2C, R2E, R2H, R2Hv, R301LA-FN063H, R301LAFN063H, R404, R404A, R404C, R404V, R404VC, R405, R405C, R405CA, R405CB, R405CM, R405V, R409C, R409C Series, R409CA, R409CA Series, R409CC, R409CC Series, R409CCWX298H, R409L Series, R409LA, R409LA Series, R409LB, R409LB Series, R409LC, R409LC Series, R409LC-W118H, R409V, R409V Series, R409VB, R409VB Series, R409VC, R409VC Series, R409VE, R409VE Series, R411C, R411CA, R411MA, R420SA, R422QA, R422QA-EB028T, R422UF, R424FA, R424FA-EK109R, R424UA, R424UB, R430FA, R430FN, R455LD, R455LD-WX099H, R455LDWX099H, R459UA, R459UA-EK138R, R501V-S3150V, ASUS [R501VM-53150V](#) Laptop Battery, R501VM53150V, R501VS3150V, R501VZ SERIES, R501VZ-S4387N, R501VZS4387N, R504BA, R504BP, R504ZA, R505, R505C, R505CA, R505CB, R505CM, R50A-DV010E, R510C, ASUS [R510C Series](#) Laptop Battery, R510CA Series, R510CA-CJ679H, R510CA-CJ862H, ASUS [R510CA-XX187H](#) Laptop Battery, R510CC, R510CC Series, R510CC-XX098H, R510CC-XX406H, R510CC-XX439H, R510CC-XX466H, R510CC-XX476H, R510CC-XX483H, R510D Series, R510DP Series, R510E Series, R510EA Series, R510JK, R510JK-DM070H, R510JK-DM086H, R510JK-DM187H, R510JX, R510L Series, R510LA Series, ASUS [R510LB Series](#) Laptop Battery, R510LC Series, R510LC-XX084H, R510LCXX234, R510LDV-XX1062H, R510V Series, R510VB Series, R510VC Series, R510VX-DM008T, R510VX-DM133T, R512C, R512CA-SX068H, R512CA-SX124H, R512CA-SX134B, R512CA-SX134H, R512CA-SX135H, R512CA-SX147H, R512CA-SX242H, R512m, R512MAV-SX345H, R515m, R515MA, R515MA-XX1102T, ASUS [R515MA-XX422H](#) Laptop Battery, R520UA-BR580T, R520UA-EJ1147T, R520UA-EJ1536, R520UA-EJ1561T, R520UA-EJ729T, R520UA-EJ930T, R520UA-EJ932T, R520UA-EJ933T, R520UA-EJ979T, R520UF, R520UF-BQ275T, R520UF-EJ020T, R520UF-EJ521T, R520UF-EJ628T, R520UF-EJ635T, R520UF-EJ686T, R520UF-EJ724T, R520UN-EJ498T, R520UN-EJ499T, R520UN-EJ529T, R520UQ, R520UQ-BQ470T, R520UQ-BQ729T, R520UQ-BQ730T, R520UQ-BQ813T, R520UQ-BQ830T, R520UR, R540L, R540LA-XX092T, R540LA-XX093T, R540LA-XX247T, R540LA-XX254T, R540LA-XX411T, R540LJ-XX299T, R540LJ-XX301T, R540SA-XX040T, ASUS [R540SA-XX056T](#) Laptop Battery, R540SA-XX319T, R541UA, R541UA-DM993T, R541UA-GQ1099T, R541UA-RB51, R541UA-XO271T, R541UA-XO273T, R541UAGQ1099T, R541UARB51, R541UAXO271T, R541UAXO273T, R541UJ, R541UJ-DM246T, R541UJDM246T, R541UV, R541UV-DM445T, R541UVDM445T, R550, R550C, R550CA, R550CB, R550CM, R553L, R553LF, R553LN, R553LN-DM123H, R553LN-DM553H, R553LN-XO078H, R553LN-XO106H, ASUS [R553LN-XO106H-BE](#) Laptop Battery, R553LN-XO263H, R553LN-XO311H, R553LN-XO369H, R553LN-

XO370D, R553LN-XO420H, R553LN-XO516H, R553LN-XX134, R553LN-XX134H, R553LN-XX136, R5541L, R554L, R554LA, R556, R556L, R556LN, R557, R557L, R558UA-DM283T, ASUS [R558UA-DM479T](#) Laptop Battery, R558UA-DM485T, R558UA-DM540T, R558UA-DM750T, R558UA-XO134T, R558UA-XX007T, R558UA-XX340T, R558UB, R558UB-DM108T, R558UB-DM252T, R558UB-RS71, R558UB-XX086T, R558UF-DM147D, R558UF-DM175D, R558UF-XO043T, R558UF-XO044D, R558UF-XO044T, R558UJ, R558UJ-DM150T, R558UJ-XO086T, R558UJ-XO167T, R558UJ-XX076T, ASUS [R558UQ](#) Laptop Battery, R558UQ-DM1053T, R558UQ-DM1451T, R558UQ-DM230T, R558UQ-DM326T, R558UQ-DM358T, R558UQ-DM360T, ASUS [R558UQ-DM410T](#) Laptop Battery, R558UQ-DM665T, R558UQ-DM738T, R558UQ-DM753T, R558UQ-X0165T, R558UQ-X0171T, R558UQ-X0261T, ASUS [R558UQ-XO150T](#) Laptop Battery, R558UQ-XO313T, R558UQ-XO879T, R558UQ-XX021T, R558UQ-XX517T, R558UR, R558UR-DM068D, R558UR-DM069D, R558UR-DM124D, R558UR-DM149T, R558UR-DM225T, R558UR-DM324T, R558UR-DM458T, R558UR-DM515T, R558UR-XO072T, R558UR-XX463T, R558UR-XX490T, R558UV-DM116T, R558UV-DM131T, R558UV-DM146T, R558UV-DM193T, R558UV-DM232T, R558UV-DM274T, R558UV-DM344T, R558UV-DM345T, R558UV-X0400T, R558UV-XO056T, R558UV-XO065T, R558UV-XO242T, R558UV-XX286T, R564DA, R564DK, R570ZD, R570ZD-DM068T, R570ZD-DM126T, R570ZD-DM266, R701V SERIES, R701V8, R702U, R751J-TY016H, R751JB, R751JTY016H, R751JX, R751LB, R751LB-T4021H, R751LB-TY033H, R751LB-TY034H, R751LB-TY041H, R751LBT4021H, R751LBTY033H, R751LBTY034H, R751LBTY041H, R751LN, R751LN-T4059H, R751LN-T4090H, R751LN-T4091H, R751ln-t4097h, R751LN-T4102H, R751LN-TY095H, R751LN-TY107H, R751LN-TY160H, R751LNT4059H, R751LNT4090H, R751LNT4091H, R751LNT4102H, R751LNTY095H, R751LNTY107H, R751LNTY160H, R751N-T4091H, R752L, R752LAV, R752LAV-TY280H, R752LAV-TY359H, ASUS [R752LAV-TY368H](#) Laptop Battery, R752LAV-TY461T, R752LAVTY280H, R752LAVTY359H, R752LAVTY368H, R752LB, R752LB-T4081H, R752LB-T4099H, R752LB-T4099T, R752LB-TY040H, R752LB-TY050T, R752LB-TY080H, R752LB-TY086H, R752LB-TY180T, R752LB-TY270T, R752LBT4081H, R752LBT4099H, R752LBT4099T, R752LBTY040H, R752LBTY050T, R752LBTY080H, R752LBTY086H, R752LBTY180T, R752LBTY270T, R752LD, R752LD-T6037H, R752LD-T6043H, R752LD-TY042H, R752LD-TY045H, R752LD-TY047H, R752LD-TY091H, R752LD-TY092H, R752LD-TY109H, ASUS [R752LD-TY110H](#) Laptop Battery, R752LDT6037H, R752LDT6043H, ASUS [R752LDTY042H](#) Laptop Battery, R752LDTY045H, R752LDTY047H, R752LDTY091H, R752LDTY092H, R752LDTY109H, R752LDTY110H, R752LDV, R752LDV-T6251H, R752LDV-T6256H, R752LDV-T6320H, R752LDV-TY148H, R752LDV-TY149H, R752LDV-TY200H, R752LDV-TY246H, R752LDV-TY247H, R752LDV-TY250H, R752LDV-TY282H, R752LDV-TY310H, R752LDV-TY337H, R752LDVT6251H, R752LDVT6256H, R752LDVT6320H, R752LDVTY148H, R752LDVTY149H, R752LDVTY200H, R752LDVTY246H, R752LDVTY247H, R752LDVTY250H, R752LDVTY282H, R752LDVTY310H, R752LDVTY337H, R752LJ, R752LJ-TY097H, R752LJ-TY098H, R752LJ-TY114T, R752LJ-TY142H, R752LJ-TY258T, R752LJTY097H, ASUS [R752LJTY098H](#) Laptop Battery, R752LJTY114T, R752LJTY142H, R752LJTY258T, ASUS [R752LK](#) Laptop Battery, R752LK-T4058H, R752LK-T4147H, R752LKT4058H, R752LKT4147H, R752LN, R752LN-T4112H, R752LN-TY037H, R752LN-TY176H, R752LNT4112H, R752LNTY037H, R752LNTY176H, R752LX, R752LX-T4030T, R752LX-T4041H, R752LX-T4066H, R752LX-T4069H, R752LX-T4070H, R752LX-T4070T, R752LX-T4078H, R752LX-T4087H, R752LX-T4089T, R752LX-TY049H, R752LX-TY050H, R752LX-TY056H, ASUS [R752LX-TY079H](#) Laptop Battery, R752LX-TY080H, R752LXT4030T, R752LXT4041H, R752LXT4066H, R752LXT4069H, R752LXT4070H, R752LXT4070T, R752LXT4078H, R752LXT4087H, R752LXT4089T, R752LXTY049H, R752LXTY050H, ASUS [R752LXTY056H](#) Laptop Battery,

R752LXTY079H, R752LXTY080H, R752MA, R752MA-TY166H, R752MA-TY285H, R752MA-TY286H, R752MA-TY306T, R752MATY166H, R752MATY285H, R752MATY286H, R752MATY306T, R753UA, R753UA-T4040T, R753UA-T4170T, R753UA-T4172T, R753UA-T4249T, R753UA-TY030T, R753UA-TY049T, R753UA-TY169T, R753UB, R753UB-T4079T, R753UB-TY045T, R753UB-TY046T, R753UB-TY082T, R753UB-TY115T, R753UB-TY128T, ASUS [R753UB-TY132T](#) Laptop Battery, R753UX, R753UX-T4024T, R753UX-T4043T, R900V, ROG Essential PU301, ROG Essential PU301L, ROG Essential PU301LA, ROG Essential PU301LA-RO064G, ROG FX-PLUS, ROG FX502VE-FY004T, ROG FX502VE-FY018T, ROG FX502VE-FY028T, ROG FX502VE-FY029T, ROG FX502VE-FY042T, ROG FX502VE-FY047T, ROG FX502VE-FY048T, ROG FX502VE-FY049T, ROG FX502VE-FY050T, ROG FX502VE-FY053T, ROG FX502VM, ROG FX502VM-AS73, ROG FX502VM-DM092T, ROG FX502VM-DM095T, ROG FX502VM-DM105T, ROG FX502VM-DM112T, ROG FX502VM-DM113T, ROG FX502VM-DM114T, ASUS [ROG FX502VM-DM115T](#) Laptop Battery, ROG FX502VM-DM119T, ROG FX502VM-DM125T, ROG FX502VM-DM128T, ROG FX502VM-DM255T, ROG FX502VM-DM261T, ROG FX502VM-DM266T, ASUS [ROG FX502VM-DM277T](#) Laptop Battery, ROG FX502VM-DM298T, ROG FX502VM-DM310T, ROG FX502VM-DM311T, ROG FX502VM-DM334T, ROG FX502VM-DM347T, ROG FX502VM-DM425T, ROG FX502VM-DM435T, ROG FX502VM-DM444T, ROG FX502VM-DM549T, ROG FX502VM-DM560T, ROG FX502VM-DM572T, ROG FX502VM-DM613T, ROG FX502VM-FY249T, ROG FX502VM-FY250T, ROG FX502VM-FY256T, ROG FX502VM-FY291, ROG FX502VM-FY353T, ROG FX502VMDM092T, ROG FX502VMDM105T, ROG FX502VMDM112T, ROG FX502VMDM113T, ROG FX502VMDM115T, ROG FX502VMDM119T, ROG FX502VMDM125T, ROG FX502VMDM128T, ROG FX502VMFY256T, ROG FX502VMFY291, ROG FX502VMFY353T, ROG FXPLUS, ROG G501, ROG G501 SERIES, ROG G501J, ROG G501JW Series, ROG G501VW, ROG G501VW-FI074T, ROG G502VM-FY017T, ROG G502VM-FY183T, ASUS [ROG G502VM-FY231T](#) Laptop Battery, ROG G550, ROG G550 Series, ROG G550J, ROG G550J Series, ROG G550JK, ROG G550JK Series, ROG G551, ROG G551 Series, ROG G551J, ROG G551J Series, ROG G551JK, ROG G551JK Series, ROG G551JK-CN074H, ROG G551JK-CN280D, ROG G551JK-CN302H, ROG G551JK-DM053H, ROG G551JM, ROG G551JM Series, ROG G551JM-DM052H, ROG G551JM-DM053H, ROG G551JM-DM169H, ROG G551JM-DM197H, ROG G551JW, ROG G551JW-CN042H, ROG G551JW-CN080H, ROG G551JW-DS71, ROG G551JW-DS71-CA, ROG G551JW-DS74, ROG G551JX, ASUS [ROG G551JX-DM036H](#) Laptop Battery, ROG G551JX-DM198H, ROG G551JX-ES71, ROG G551VW, ROG G552VW-DM262T, ROG G552VW-DM272T, ROG G552VX-DM358T, ROG G553VD-DM206T, ROG G553VD-DM746T, ROG G553VW-DM096T, ASUS [ROG G56JK](#) Laptop Battery, ROG G56JR, ROG G58, ROG G58J, ROG G58JM, ROG G58JM4200, ROG G58JM4710, ROG G58JM4720, ROG G58JW4200, ROG G58JW4720, ROG G58VW6700, ROG G701, ROG G701VI, ROG G701VI-BA034T, ASUS [ROG G701VI-XB78K](#) Laptop Battery, ROG G701VIBA034T, ROG G701VIK, ROG G701VIXB78K, ROG G701VO-CS74K, ROG G701VOC74K, ROG G741JW, ROG G750, ROG G750GM-BSI7N23, ROG G750J, ROG G750JH, ROG G750JH-DB71, ROG G750JH-QS71-CB, ROG G750JH-T4070H, ROG G750JH-T4080H, ROG G750JM, ROG G750JM-BSI7N23, ROG G750JM-BSI7N24, ROG G750JM-DB71-CA, ROG G750JM-DS71, ROG G750JM-T4014H, ROG G750JM-T4018P, ROG G750JM-T4111H, ROG G750JS, ROG G750JS-DS71, ASUS [ROG G750JS-NH71](#) Laptop Battery, ROG G750JS-RS71, ROG G750JS-T4001H, ROG G750JS-T4008H, ROG G750JS-T4023H, ROG G750JS-T4064H, ROG G750JS-T4068H, ROG G750JS-T4069H, ROG G750JS-T4129H, ROG G750JS-T4193H, ROG G750JW, ROG G750JW-BBI7N05, ROG G750JW-DB71, ROG G750JW-DB71-CA, ROG G750JW-DH71, ROG G750JW-NH71, ROG G750JW-RB71, ROG G750JW-T4030H, ROG G750JW-T4042H, ROG G750JW-T4099H,

ASUS [ROG G750JX](#) Laptop Battery, ROG G750JX-CV025H, ROG G750JX-CV069P, ROG G750JX-DB71, ROG G750JX-IB71, ROG G750JX-T4101D, ROG G750JX-T4204H, ROG G750JX-T4259H, ROG G750JX-T4264H, ROG G750JX-TB71, ROG G750JZ, ROG G750JZ-DB73-CA, ROG G750JZ-DS71, ROG G750JZ-RB73-CA, ROG G750JZ-T4004H, ROG G750JZ-T4013H, ROG G750JZ-T4023H, ROG G750JZ-T4044H, ROG G750JZ-T4110H, ROG G750JZ-T4172H, ASUS [ROG G750JZ-XS72](#) Laptop Battery, ROG G751 Series, ROG G751J Series, ROG G751JL, ROG G751JL-T7003H, ROG G751JM, ROG G751JM Series, ROG G751JM-T7041H, ROG G751JM-T7061H, ROG G751JT Series, ROG G751JT-DH72-CA, ROG G751JT-QH72-CB, ROG G751JT-T7181T, ROG G751JY Series, ROG G751JY-T7016H, ROG G751JY-T7059H, ROG G751JY-T7163H, ROG G751JY-T7186H, ROG G751JY-T7188H, ROG G752, ROG G752V, ROG G752VL, ROG G752VS, ROG G752VT, ROG G752VY, ROG G771, ROG G771 Series, ASUS [ROG G771J](#) Laptop Battery, ROG G771J Series, ROG G771JK, ROG G771JK Series, ROG G771JM, ROG G771JM Series, ROG G771JM-DH71, ROG G771JM-DH71-CA, ROG G771JM-QH71-CB, ROG G771JM-T4039D, ROG G771JM-T7058H, ROG G771JM-T7064H, ROG G771JW, ROG G771JW Series, ROG G771JW-T7009H, ROG G771JW-T7028D, ROG G771JW-T7076H, ROG G771JW-T7078H, ROG G771JW-T7115H, ROG G7A, ROG G7AI7700, ROG G7AI7820, ROG G7AI7820 32GB2TB, ROG G7BI, ROG G800VI, ROG G800VI-XB78K, ROG G800VIXB78K, ROG GA502DU, ROG GFX70JZ4710, ASUS [ROG GFX70JZ4860](#) Laptop Battery, ROG GFX71 Series, ROG GFX71J Series, ROG GFX71JM Series, ASUS [ROG GFX71JT Series](#) Laptop Battery, ROG GFX71JY, ASUS [ROG GFX71JY Series](#) Laptop Battery, ROG GFX72, ROG GFX72V, ROG GFX72VL6700, ROG GFX72VS6700, ROG GFX72VS6820, ROG GFX72VT6700, ROG GFX72VY6700, ROG GFX72VY6820, ROG GL502VS, ROG GL502VT, ROG GL503GE, ROG GL503VD, ASUS [ROG GL503VD-DB74](#) Laptop Battery, ROG GL503VD-FY005, ROG GL503VD-FY007T, ROG GL503VD-FY009T, ROG GL503VD-FY077T, ROG GL503VD-FY111T, ROG GL503VD-FY126T, ROG GL503VDDDB74, ROG GL503VDFY005, ROG GL503VDFY007T, ROG GL503VDFY009T, ROG GL503VDFY077T, ROG GL503VDFY111T, ROG GL503VDFY126T, ROG GL503VS, ROG GL543VD-DM546D, ROG GL543VD-DM546T, ROG GL551, ROG GL551J, ROG GL551JK, ROG GL551JM, ROG GL551JW, ROG GL551JW-DS71, ROG GL551JX, ROG GL552, ROG GL552J, ROG GL552JX, ROG GL552JX-CN009H, ROG GL552JX-CN029D, ROG GL552JX-CN090D, ROG GL552JX-CN154H, ROG GL552JX-CN155H, ROG GL552JX-CN156H, ROG GL552JX-CN182H, ROG GL552JX-CN228D, ROG GL552JX-CN316T, ROG GL552JX-CN335T, ROG GL552JX-CN369D, ROG GL552JX-DM019D, ROG GL552JX-DM033H, ROG GL552JX-DM072H, ROG GL552JX-DM079H, ROG GL552JX-DM085H, ROG GL552JX-DM087D, ASUS [ROG GL552JX-DM088H](#) Laptop Battery, ROG GL552JX-DM144D, ROG GL552JX-DM144H, ROG GL552JX-DM165H, ROG GL552JX-DM174H, ROG GL552JX-DM188D, ROG GL552JX-DM264H, ROG GL552JX-DM269T, ROG GL552JX-DM285T, ROG GL552JX-DM291D, ROG GL552JX-DM292D, ROG GL552JX-DM343T, ROG GL552JX-DM356D, ROG GL552JX-DM390T, ROG GL552JX-XO083D, ROG GL552JX-XO083H, ROG GL552JX-XO093D, ROG GL552JX-XO139D, ROG GL552JX-XO305D, ROG GL552JX-XO345T, ROG GL552V, ROG GL552VL, ROG GL552VL-0023B6700HQ, ROG GL552VL-CN028T, ROG GL552VL-CN044D, ASUS [ROG GL552VL-CN046D](#) Laptop Battery, ROG GL552VL-DM023T, ROG GL552VW, ROG GL552VW-CN058D, ROG GL552VW-CN090D, ROG GL552VW-CN091D, ROG GL552VW-CN104T, ROG GL552VW-CN108T, ROG GL552VW-CN114T, ROG GL552VW-CN134T, ROG GL552VW-CN157T, ROG GL552VW-CN158T, ROG GL552VW-CN164T, ROG GL552VW-CN174D, ROG GL552VW-CN211D, ROG GL552VW-CN214T, ROG GL552VW-CN273T, ROG GL552VW-CN274T, ROG GL552VW-CN286T, ROG GL552VW-CN298T, ROG GL552VW-CN313T, ASUS [ROG GL552VW-CN320T](#) Laptop Battery, ROG GL552VW-CN335T, ROG GL552VW-CN353T, ASUS [ROG](#)

[GL552VW-CN354T](#) Laptop Battery, ROG GL552VW-CN387T, ROG GL552VW-CN388T, ROG GL552VW-CN426T, ROG GL552VW-CN430T, ROG GL552VW-CN446T, ROG GL552VW-CN461D, ROG GL552VW-CN470T, ROG GL552VW-CN471T, ROG GL552VW-CN480T, ROG GL552VW-CN481T, ROG GL552VW-CN501T, ROG GL552VW-CN515D, ROG GL552VW-CN516D, ROG GL552VW-CN565D, ROG GL552VW-CN601D, ROG GL552VW-CN602T, ROG GL552VW-CN618T, ROG GL552VW-CN624T, ROG GL552VW-CN625T, ROG GL552VW-CN704T, ROG GL552VW-CN739T, ROG GL552VW-CN793T, ROG GL552VW-CN875T, ROG GL552VW-CN893T, ROG GL552VW-CN896T, ROG GL552VW-CN897T, ROG GL552VW-CN923D, ROG GL552VW-CN926D, ROG GL552VW-CN926T, ROG GL552VW-CN947T, ROG GL552VW-CN951T, ROG GL552VW-DH71, ROG GL552VW-DH74, ROG GL552VW-DM002T, ASUS [ROG GL552VW-DM010D](#) Laptop Battery, ROG GL552VW-DM099D, ROG GL552VW-DM132T, ROG GL552VW-DM141, ROG GL552VW-DM141T, ROG GL552VW-DM142T, ROG GL552VW-DM149, ROG GL552VW-DM149T, ROG GL552VW-DM150T, ROG GL552VW-DM151T, ROG GL552VW-DM195T, ROG GL552VW-DM197T, ROG GL552VW-DM198T, ROG GL552VW-DM201T, ROG GL552VW-DM205T, ROG GL552VW-DM210T, ROG GL552VW-DM212T, ROG GL552VW-DM225T, ROG GL552VW-DM337T, ROG GL552VW-DM349T, ROG GL552VW-DM350T, ROG GL552VW-DM351T, ROG GL552VW-DM463T, ROG GL552VW-DM464T, ROG GL552VW-DM490T, ROG GL552VW-DM594T, ROG GL552VW-DM643T, ROG GL552VW-DM675T, ROG GL552VW-DM686T, ROG GL552VW-DM732D, ROG GL552VW-DM733D, ROG GL552VW-DM748T, ROG GL552VW-DM762D, ROG GL552VW-DM775T, ROG GL552VW-DM777T, ASUS [ROG GL552VW-DM789T](#) Laptop Battery, ROG GL552VW-DM797T, ASUS [ROG GL552VW-DM806T](#) Laptop Battery, ROG GL552VW-DM812T, ROG GL552VW-DM862T, ROG GL552VW-DM880D, ROG GL552VW-DM881T, ROG GL552VW-DM890T, ROG GL552VW-DM949D, ROG GL552VW-IH78, ROG GL552VX-CN036T, ROG GL552VX-CN055T, ROG GL552VX-CN059D, ROG GL552VX-CN060D, ASUS [ROG GL552VX-CN062D](#) Laptop Battery, ASUS [ROG GL552VX-CN117T](#) Laptop Battery, ROG GL552VX-CN146T, ROG GL552VX-CN198D, ROG GL552VX-CN239T, ROG GL552VX-CN246T, ROG GL552VX-CN267T, ROG GL552VX-CN312T, ROG GL552VX-CN368T, ROG GL552VX-DM018D, ROG GL552VX-DM044T, ROG GL552VX-DM070D, ASUS [ROG GL552VX-DM076T](#) Laptop Battery, ROG GL552VX-DM087T, ROG GL552VX-DM119T, ROG GL552VX-DM143D, ROG GL552VX-DM151D, ROG GL552VX-DM183D, ROG GL552VX-DM212D, ROG GL552VX-DM229D, ROG GL552VX-DM248T, ROG GL552VX-DM261T, ROG GL552VX-DM262D, ROG GL552VX-DM270T, ROG GL552VX-DM272T, ROG GL552VX-DM294D, ROG GL552VX-DM310D, ROG GL552VX-DM335T, ROG GL552VX-DM336D, ROG GL552VX-DM356D, ROG GL552VX-DM363T, ROG GL552VX-DM365T, ROG GL552VX-DM390T, ROG GL552VX-DM401T, ROG GL552VX-DM406T, ROG GL552VX-DM447D, ROG GL552VX-DM448T, ROG GL552VX-DM482, ROG GL552VX-DM493T, ROG GL552VX-XO081D, ROG GL552VX-XO103T, ROG GL552VX-XO104D, ROG GL552VX-XO104T, ROG GL553VW-DH71, ROG GL553VW-DM005T, ROG GL553VW-FY089T, ROG GL553VWDH71, ROG GL553VWDM005T, ROG GL553VW-FY089T, ROG GL703, ASUS [ROG GL703G](#) Laptop Battery, ROG GL703GM, ROG GL704, ROG GL704G, ROG GL704M, ROG GL742VW, ROG GL752VW-DH74, ROG GL752VW-T4003T, ROG GL752VW-T4004T, ROG GL752VW-T4032T, ROG GL752VW-T4079T, ROG GL752VW-T4091T, ASUS [ROG GL752VW-T4105](#) Laptop Battery, ROG GL752VW-T4122T, ROG GL752VW-T4130T, ROG GL752VW-T4137T, ROG GL752VW-T4138T, ROG GL752VW-T4179T, ROG GL752VW-T4180T, ROG GL753VD, ROG GL753VE-GC019T, ROG GL753VE-GC024T, ROG GL753VE-GC056T, ROG GL753VE-GC059, ASUS [ROG GL753VE-GC095T](#) Laptop Battery, ROG GL753VE-GC169, ROG GL753VE-Q72SP, ROG GL771, ROG GL771J Series, ROG GL771JM, ROG GL771JM Series, ROG

GL771JM-T4034H, ROG GL771JM-T7093H, ROG GL771JM-T7128H, ROG GL771JM-T7129H, ROG GL771JM-T7130H, ROG GL771JM-T7143H, ASUS [ROG GL771JW](#) Laptop Battery, ROG GL771JW Series, ROG GL771JW-T7080H, ROG GL771JW-T7081H, ROG GL771JW-T7081T, ROG GL771JW-T7082H, ROG GL771JW-T7083T, ROG GL771JW-T7098H, ROG GU502GV, ROG GX501, ROG GX501G, ROG GX501GI, ROG GX501GI8750, ROG GX501GM, ROG GX501GS, ROG GX501VI, ROG GX501VIK7700, ROG GX700, ROG GX700V, ROG GX700VO, ROG GX700VO-GC009T, ROG GX700VO6820, ASUS [ROG GX700VOGC009T](#) Laptop Battery, ROG GX701GVR, ROG GX701GVR-EV001T, ROG GX800VHK, ROG PU301, ROG PU301L, ASUS [ROG PU301LA](#) Laptop Battery, ROG S GX532GW-AZ111T, ROG s5, ROG S5VM6700, ROG S5VS6700, ROG S5VT6700, ROG S7V, ROG S7VM6700, ROG S7VM7700, ROG S7VT6700, ROG STRIX G502VM-FY398, ROG Strix GL502, ROG Strix GL502V, ROG Strix GL502VM, ROG Strix GL502VM-BI7N10, ROG Strix GL502VM-BM113T, ROG Strix GL502VM-FY009T, ROG Strix GL502VM-FY015T, ROG Strix GL502VM-FY022T, ROG Strix GL502VM-FY035T, ROG Strix GL502VM-FY036T, ROG Strix GL502VM-FY039T, ROG Strix GL502VM-FY044T, ROG Strix GL502VM-FY045T, ASUS [ROG Strix GL502VM-FY053T](#) Laptop Battery, ROG Strix GL502VM-FY163T, ROG Strix GL502VM-FY165T, ROG Strix GL502VM-FY170T, ROG Strix GL502VM-FY172T, ROG Strix GL502VM-FY185T, ROG Strix GL502VM-FY188T, ROG Strix GL502VM-FY197T, ROG Strix GL502VM-FY198T, ROG Strix GL502VM-FY200T, ROG Strix GL502VM-FY208T, ASUS [ROG Strix GL502VM-FY211T](#) Laptop Battery, ROG Strix GL502VM-FY212T, ROG Strix GL502VM-FY213T, ROG Strix GL502VM-FY219T, ROG Strix GL502VM-FY225T, ROG Strix GL502VM-FY292T, ROG Strix GL502VM-FY309T, ROG Strix GL502VM-FY323T, ROG Strix GL502VM-FY325T, ROG Strix GL502VM-FY377T, ROG Strix GL502VM-FY378T, ASUS [ROG Strix GL502VM-FY386T](#) Laptop Battery, ROG Strix GL502VM-FY410T, ROG Strix GL502VM-FY441T, ROG Strix GL502VM-FY461T, ROG Strix GL502VM-FY479T, ROG Strix GL502VM-FY497T, ROG Strix GL502VM-FY506T, ROG Strix GL502VM-FY511T, ROG Strix GL502VM-FY534T, ROG Strix GL502VM-FY536T, ROG Strix GL502VM-FY548T, ROG Strix GL502VM-FY593T, ROG Strix GL502VM-FY651, ROG Strix GL502VMFY039T, ROG Strix GL502VS, ROG Strix GL502VS-FY032T, ROG Strix GL502VSFY032T, ROG Strix GL502VT, ROG Strix GL502VT-bsi7n27, ROG Strix GL502VT-ds71, ROG Strix GL502VT-ds74, ROG Strix GL502VT-fy002T, ROG Strix GL502VT-fy010T, ROG Strix GL502VT-fy017T, ROG Strix GL502VT-fy026T, ROG Strix GL502VT-fy028T, ROG Strix GL502VT-fy034T, ROG Strix GL502VT-fy035T, ROG Strix GL502VT-fy044T, ROG Strix GL502VT-fy072T, ASUS [ROG Strix GL502VT-fy086T](#) Laptop Battery, ROG Strix GL502VT-fy124T, ROG Strix GL502VT-fy129T, ROG Strix GL502VT-fy145T, ROG Strix GL502VT-fy146T, ROG Strix GL502VT-fy148T, ROG Strix GL502VY, ROG STRIX GL503, ROG STRIX GL503GE-ES73, ASUS [ROG STRIX GL503GEES73](#) Laptop Battery, ROG Strix GL503VM, ROG Strix GL503VM-BI7N13, ROG Strix GL503VM-DB74, ROG Strix GL503VM-ED092T, ROG Strix GL503VM-FY022T, ROG Strix GL503VM-FY100T, ROG Strix GL503VM-GZ081, ROG Strix GL503VM-GZ083T, ROG Strix GL503VM-GZ084T, ROG Strix GL503VM-GZ211T, ROG Strix GL503VMBI7N13, ROG Strix GL503VMD74, ASUS [ROG Strix GL503VMED092T](#) Laptop Battery, ROG Strix GL503VMFY022T, ROG Strix GL503VMFY100T, ROG Strix GL503VMGZ081, ROG Strix GL503VMGZ083T, ROG Strix GL503VMGZ084T, ROG Strix GL503VMGZ211T, ROG STRIX GL553VD, ROG Strix GL553VD-DS71, ASUS [ROG Strix GL553VD-FY040T](#) Laptop Battery, ROG STRIX GL553VD-FY075T, ROG Strix GL553VD-FY076T, ROG Strix GL553VD-FY139T, ROG Strix GL553VDDS71, ROG Strix GL553VE, ROG Strix GL553VE-FY016T, ASUS [ROG Strix GL553VE-FY033T](#) Laptop Battery, ROG Strix GL553VE-FY054T, ROG Strix GL553VE-FY055T, ROG Strix GL553VE-FY056T, ROG Strix GL553VE-FY081T, ROG Strix GL553VE-FY082T, ROG Strix GL553VE-FY084T, ROG Strix

GL553VE-FY100T, ROG Strix GL553VE-FY156T, ROG Strix GL553VE-FY161, ROG Strix GL553VE-FY320T, ASUS [ROG Strix GL702VM](#) Laptop Battery, ROG Strix GL702VM-BA135T, ROG Strix GL702VM-BA195T, ROG Strix GL702VM-BA230T, ROG Strix GL702VM-BA323T, ROG Strix GL702VM-BA324, ROG Strix GL702VM-BA325T, ROG Strix GL702VM-BA414, ROG Strix GL702VM-DB71, ROG Strix GL702VM-DB74, ROG Strix GL702VM-GB031T, ASUS [ROG Strix GL702VM-GB032T](#) Laptop Battery, ROG Strix GL702VM-GC005T, ROG Strix GL702VM-GC010T, ROG Strix GL702VM-GC017T, ROG Strix GL702VM-GC020T, ROG Strix GL702VM-GC026T, ROG Strix GL702VM-GC035T, ROG Strix GL702VM-GC100T, ROG Strix GL702VM-GC102D, ROG Strix GL702VM-GC143T, ROG Strix GL702VM-GC154T, ROG Strix GL702VM-GC194T, ROG Strix GL702VM-GC234, ROG Strix GL702VM-GC279T, ROG Strix GL702VM-GC280T, ROG Strix GL702VM-GC301T, ROG Strix GL702VS, ROG STRIX GL702VS-0051C7700HQ, ROG Strix GL702VS-AH73, ROG Strix GL702VS-BA023T, ROG Strix GL702VS-BA101, ROG Strix GL702VS-BA181T, ROG Strix GL702VS-BA207T, ROG Strix GL702VS-BA222T, ROG Strix GL702VS-BA230T, ASUS [ROG Strix GL702VS-BI7N12](#) Laptop Battery, ROG STRIX GL702VS-DS74, ROG Strix GL702VS-GC066T, ROG Strix GL702VS-GC079T, ROG STRIX GL702VS-RS71, ROG Strix GL702VT, ROG Strix GL702VT-GC018T, ROG Strix GL702VT-GC023T, ROG Strix GL702VT-GC024T, ROG Strix GL702VT-GC025T, ROG Strix GL702VT-GC033T, ROG Strix GL702VT-GC090TC, ROG Strix GL702VT-GC109T, ROG Strix GL702ZC, ROG Strix GL702ZC-GC006T, ROG Strix GL702ZC-GC007T, ROG Strix GL702ZC-GC098T, ROG Strix GL702ZC-GC104T, ROG Strix GL702ZC-GC105T, ROG Strix GL702ZC-GC174T, ROG Strix GL702ZC-GC177T, ROG Strix GL702ZC-GC178T, ROG Strix GL702ZC-GC179T, ROG Strix GL702ZC-GC204T, ROG Strix GL702ZC-GC206T, ROG Strix GL702ZC-GC207T, ROG Strix GL702ZC-NS74, ROG Strix GL702ZC-WB74, ROG STRIX GL703, ROG Strix GL703GM, ROG Strix GL703GM Scar Edition, ROG Strix GL703VD, ASUS [ROG Strix GL703VD-DB74](#) Laptop Battery, ROG Strix GL703VD-GC008T, ROG Strix GL703VD-GC024T, ROG Strix GL703VD-WB71, ROG Strix GL703VDDDB74, ROG Strix GL703VDGC008T, ROG Strix GL703VDGC024T, ROG Strix GL703VDWB71, ROG Strix GL703VM, ROG Strix GL703VM-BA106T, ROG Strix GL703VM-DB74, ROG Strix GL703VM-GC002T, ROG Strix GL703VM-GC031T, ROG Strix GL703VM-GC038T, ROG Strix GL703VM-GC111T, ROG Strix GL703VMBA106T, ROG Strix GL703VMDB74, ROG Strix GL703VMGC002T, ROG Strix GL703VMGC031T, ROG Strix GL703VMGC038T, ROG Strix GL703VMGC111T, ROG Strix GL704, ROG STRIX GL704GM-DH74, ROG Strix GL704GW, ROG Strix GL753VD, ROG Strix GL753VD-GC009, ROG Strix GL753VD-GC011T, ROG Strix GL753VD-GC032T, ROG Strix GL753VD-GC041T, ROG Strix GL753VD-GC042, ROG Strix GL753VD-GC043T, ROG Strix GL753VD-GC045T, ROG Strix GL753VD-GC061T, ROG Strix GL753VD-GC133T, ROG Strix GL753VD-GC337T, ROG Strix GL753VE, ROG Strix GL753VE-DS74, ROG Strix GL753VE-GC133T, ROG Strix GL753VE-GC150T, ROG Strix GL753VE-GC151T, ROG STRIX PX753VD, ROG STRIX S5, ROG STRIX S5VS, ROG STRIX S7BS, ROG STRIX S7BS8750, ROG Strix S7ZC, ROG Strix SCAR Edition GL503VS, ROG Strix Scar GL703, ROG Strix Scar GL703GM, ROG Strix SCAR II GL704, ROG Strix Scar II GL704GM, ROG Strix Scar II GL704GM-EV027T, ASUS [ROG Strix SCAR II GL704GV-DS74](#) Laptop Battery, ROG Strix Scar II GL704GW, ROG Strix SCAR II GL704GW-DS74, ROG Strix SCAR II GL704GW-DS76, ROG Strix Scar II GL704GW-EV001T, ROG Strix Scar II GL704GW-EV002T, ROG Strix Scar II GL704GW-EV003T, ROG Strix Scar II GL704GW-EV004T, ROG Strix Scar II GL704GW-EV005T, ROG Strix Scar II GL704GW-EV006T, ASUS [ROG Strix Scar II GL704GW-EV010T](#) Laptop Battery, ROG Strix Scar II GL704GW-EV011T, ROG Strix Scar II GL704GW-EV012T, ROG Strix Scar II GL704GW-EV013T, ROG Strix Scar II GL704GW-EV018T, ROG Strix Scar II GL704GW-EV020T, ROG Strix Scar II GL704GW-EV021T, ROG Strix Scar II GL704GW-

EV022, ROG Strix Scar II GL704GW-EV042T, ROG Strix Scar II GL704GW-EV045T, ROG Strix Scar II GL704GW-EV047T, ROG Strix Scar II GL704GW-EV048T, ROG Strix Scar II GL704GW-EV059T, ROG Strix SCAR II GL704GW-PS71, ROG Zephyrus S GX502, ROG Zephyrus G GA502, ASUS [ROG Zephyrus G GA502DU](#) Laptop Battery, ROG Zephyrus G GA502DU-AL025T, ROG Zephyrus G GA502DU-BR7N6, ROG Zephyrus G GA502DU-PB73, ROG Zephyrus G GA502GU, ROG Zephyrus G GA502GU-PB73, ROG Zephyrus G GU532GU-ES036T, ROG Zephyrus GA502, ROG Zephyrus GU502GU-ES003T, ROG Zephyrus GX501, ROG Zephyrus GX501G, ROG Zephyrus GX501GI, ROG Zephyrus GX501GM, ASUS [ROG Zephyrus GX501GS](#) Laptop Battery, ROG Zephyrus GX501VI, ROG Zephyrus GX501VI-GZ020T, ROG Zephyrus GX501VI-GZ021T, ROG Zephyrus GX501VI-XS74, ROG Zephyrus GX501VS-XS71, ROG ZEPHYRUS GX701GX-EV058T, ROG Zephyrus M GM501, ROG Zephyrus M GM501GS-EI003T, ROG Zephyrus M GM501GS-EI005T, ROG Zephyrus M GM501GS-US74, ROG Zephyrus M GU502, ROG Zephyrus M GU502GU, ROG Zephyrus M GU502GU-ES014T, ROG Zephyrus M GU502GU-ES015T, ROG Zephyrus M GU502GU-XB74, ASUS [ROG ZEPHYRUS M GU502GV](#) Laptop Battery, ROG Zephyrus M GU502GV-BI7N10, ROG Zephyrus M GU502GV-ES004T, ROG Zephyrus M GU532GU-ES001T, ROG Zephyrus M GU532GV-AZ068T, ROG Zephyrus M GU532GV-AZ076T, ROG Zephyrus M GU532GV-AZ101R, ROG Zephyrus M GU532GV-ES023T, ROG Zephyrus M-GU532GU-ES003T, ROG Zephyrus S GX502, ROG Zephyrus S GX502GV-AZ039T, ROG Zephyrus S GX502GV-ES001T, ROG Zephyrus S GX502GV-ES004T, ROG Zephyrus S GX502GV-PB74, ROG Zephyrus S GX502GW, ROG Zephyrus S GX502GW-AZ054R, ROG Zephyrus S GX502GW-AZ064T, ROG Zephyrus S GX502GW-ES002T, ROG Zephyrus S GX502GW-ES006R, ROG Zephyrus S GX502GW-XB76, ASUS [ROG Zephyrus S GX531](#) Laptop Battery, ROG Zephyrus S GX531GM, ROG Zephyrus S GX531GS, ROG Zephyrus S GX531GV-ES003T, ROG Zephyrus S GX531GV-ES007T, ROG Zephyrus S GX531GV-ES017T, ROG Zephyrus S GX531GX-ES002T, ROG Zephyrus S GX531GX-ES008R, ROG Zephyrus S GX531GX-ES015T, ROG Zephyrus S GX531GX-ES018T, ROG Zephyrus S GX531GX-ES036R, ROG Zephyrus S GX531GX-XS74, ROG Zephyrus S GX531GX-XS76, ROG Zephyrus S GX531GXR-AZ042T, ROG Zephyrus S GX531GXR-AZ044T, ROG Zephyrus S GX531GXR-ES007T, ROG Zephyrus S GX531GXR-ES010R, ROG Zephyrus S GX531GXR-ES016T, ROG Zephyrus S GX532GV-ES010T, ROG Zephyrus S GX532GW-ES029T, ROG Zephyrus S GX701GVR-EV003R, ROG Zephyrus S GX701GVR-EV003T, ROG Zephyrus S GX701GVR-EV012T, ASUS [ROG Zephyrus S GX701GVR-EV021T](#) Laptop Battery, ASUS [ROG Zephyrus S GX701GW-DB76](#) Laptop Battery, ROG Zephyrus S GX701GW-EV008T, ROG Zephyrus S GX701GW-EV010T, ROG Zephyrus S GX701GW-EV023T, ROG Zephyrus S GX701GW-EV047R, ROG Zephyrus S GX701GW-PS74, ROG Zephyrus S GX701GWR-EV002T, ROG Zephyrus S GX701GWR-EV003T, ROG Zephyrus S GX701GWR-EV007T, ROG Zephyrus S GX701GWR-EV013T, ROG Zephyrus S GX701GWR-EV016T, ROG Zephyrus S GX701GWR-EV021R, ROG Zephyrus S GX701GWR-EV024T, ROG Zephyrus S GX701GWR-EV036T, ROG Zephyrus S GX701GWR-EV050T, ROG Zephyrus S GX701GWR-H6062T, ROG Zephyrus S GX701GX, ROG Zephyrus S GX701GX-EV020T, ROG Zephyrus S GX701GX-EV021R, ROG Zephyrus S GX701GX-EV404TC, ROG Zephyrus S GX701GX-XS76, ROG Zephyrus S GX701GXR, ROG Zephyrus S GX701GXR-EV007R, ROG Zephyrus S GX701GXR-EV013R, ROG Zephyrus S GX735GV-EV001T, ROG Zephyrus S GX735GV-EV017T, ROG Zephyrus S GX735GVR-016T, ROG Zephyrus S GX735GVR-EV005T, ROG Zephyrus S GX735GVR-EV015T, ROG Zephyrus S GX735GW-EV005T, ROG Zephyrus S GX735GW-EV036T, ROG Zephyrus S GX735GW-EV043R, ROG Zephyrus S GX735GW-EV055T, ROG Zephyrus S GX735GWR-EV030T, ROG Zephyrus S GX735GX-EV004T, ROG Zephyrus S GX735GX-EV068R, ROG Zephyrus S GX735GX-EV072T, ROG Zephyrus S GX735GX-EV079T, ROG Zephyrus S GX735GXR-025R, ROG ZEPHYRUS S GX735GXR-6100T,

ROG Zephyrus S GX735GXR-E026R, ROG ZEPHYRUS S GX735GXR-EV031T, ROG ZX50JX, ROG ZX50JX4200, ROG ZX50JX4720, ROG-G55VW, ROG-G56JK, Ros G751J, Ros GFX71J, RTL8821AE, RX310UA7100, RX333FA, RX333FA-A3141T, ASUS [RX333FN](#) Laptop Battery, RX333FN-A3138T, RX333FN-A3139T, RX430, RX430UA, RX430UQ, RX433FN, RX533, RX533FD, RX53BA, RX53BP, S1, S1 Series, S1000, S1000A, S1000B, S1000N, S101H-BLK042X, S101H-BRN043X, S101H-CHP035X, S101H-PIK025X, S1300, S1300A, S1300B, ASUS [S1300N](#) Laptop Battery, ASUS [S1A](#) Laptop Battery, S1B, S1N, S1XXX, S200LI236, S300C, S301 SERIES, S301A Series, S301A1 Series, S301U Series, S330 Series, S330U Series, S330UN Series, S37, S37 Series, ASUS [S37e](#) Laptop Battery, S37E, S37S, S37S, S37SP, S37SP, S40, S400, S400C, S400CA, S400E, S401 Series, S401A Series, S401A1 Series, S401QA, S401QA-EB091T, S401QA-EB976T, S401QA-EK434T, S401U Series, S401UA, ASUS [S401UA-BV1062T](#) Laptop Battery, S401UA-BV332T, S401UA-BV664T, S401UA-BV810T, S401UA-EB1047T, S401UA-EB279T, S401UA-EB308T, S401UA-EB425T, S401UA-EB812T, S401UA-EB947T, S401UF, S401UF-EB191T, S405, S405C, S405CA, S405CB, S405CM, S405CM-WX117H, S405CMWX117H, S40C, S40CA, S40CB, S40CM, S4100V, S4100VN, S4100VN8250U, S4100VN8550U, S410U, S410UA-0111B8250U, S410UA-0191B8130U, S410UA-AS51, S410UA-AS71, S410UA-AS8201T, S410UA-BV042, S410UA-BV050T, S410UA-BV110, S410UA-BV125T, S410UA-BV133T, S410UA-BV134T, S410UA-BV215R, S410UA-BV216R, S410UA-BV217R, S410UA-BV365, S410UA-BV452T, S410UA-BV455T, S410UA-EB003T, S410UA-EB017T, S410UA-EB029, S410UA-EB031T, S410UA-EB039T, S410UA-EB045, S410UA-EB045R, S410UA-EB046T, S410UA-EB076, S410UA-EB093T, S410UA-EB1056T, ASUS [S410UA-EB1074T](#) Laptop Battery, S410UA-EB108T, S410UA-EB109T, S410UA-EB113T, S410UA-EB127T, S410UA-EB132T, S410UA-EB145T, ASUS [S410UA-EB178T](#) Laptop Battery, S410UA-EB179, ASUS [S410UA-EB218T](#) Laptop Battery, S410UA-EB220T, S410UA-EB222T, ASUS [S410UA-EB264T](#) Laptop Battery, ASUS [S410UA-EB265T](#) Laptop Battery, S410UA-EB266T, S410UA-EB267T, S410UA-EB324T, ASUS [S410UA-EB325T](#) Laptop Battery, S410UA-EB336T, S410UA-EB337T, S410UA-EB367T, S410UA-EB408T, S410UA-EB409T, ASUS [S410UA-EB450T](#) Laptop Battery, S410UA-EB456T, ASUS [S410UA-EB516T](#) Laptop Battery, S410UA-EB547T, S410UA-EB590T, S410UA-EB606T, S410UA-EB616T, S410UA-EB629T, S410UA-EB630T, S410UA-EB633T, S410UA-EB666T, S410UA-EB723T, S410UA-EB724T, S410UA-EB796T, S410UA-EB943T, S410UA-EB962T, S410UF, S410UN-NS74, S4200U, S4200UF, ASUS [S4200UF8250](#) Laptop Battery, S4300UF, ASUS [S430FA](#) Laptop Battery, S430FA-EB008T, S430FA-EB039R, S430FA-EB061T, S430FN, S430UA, S430UF, S430UN, S431FA, S431FL, S431FL-AM043T, S431FL-EB064T, S4500FA, S4500FL, S451LA, S451LA-DS51T-CA, S451LADS51TCA, S451LN, S46, S46 Series, S46C, S46C Series, S46C Ultrabook, S46CA, S46CA Series, S46CA-DH31-CA, S46CA-WX016, S46CA-WX017H, S46CA-WX017R, S46CA-WX021R, s46ca-wx044r, S46CAWX016, S46CAWX017H, S46CAWX017R, S46CAWX021R, ASUS [S46CAWX044R](#) Laptop Battery, S46CB, S46CB-WX058H, S46CB-WX119H, S46CM, S46CM Series, ASUS [S46CM-DH71-CA](#) Laptop Battery, S46CM-V2G, S46CM-WX023V, S46CM-WX046V, S46CM-WX049D, S46CM-WX050H, S46CM-WX053R, S46CM-WX124H, S46CMV2G, S46CMWX023V, S46CMWX046V, S46CMWX049D, S46CMWX050H, S46CMWX053R, S46CMWX124H, S46E, S46E3217CM, ASUS [S46E3317CB-SL](#) Laptop Battery, S46E3317CBSL, S46E3317CM-SL, S46E3317CMSL, S5000, S5000A, S5000N, S500C, S500CA, ASUS [S501 Series](#) Laptop Battery, S501A Series, S501A1 Series, S501U Series, S501UA, S501UA-BR530T, S501UF, S501UR, S505, S505C, S505CA, S505CM, S505CM-XX188HS, S505CM-XX189P, S505CMXX188HS, S505CMXX189P, S5100U, S510UA, S510UF, S510UN, S510UQ, S510UR, S5200A, S5200N, S5200Ne, S52N, S530 Series, S5300UN, S530U Series, S530UN Series, ASUS [S550 SERIES](#) Laptop Battery, S550c, S550CA, S550CA-CJ36, S550CA-DS51T, S550cb, S550CB-CJ182H, S550CB-CJ187H, S550CB-CJ193H,

S550CBCJ182H, S550CBCJ187H, S550CBCJ193H, s550ch-cj124h, s550chcj124h, S550CM, S550CM-CJ038H, S550CM-CJ119H, s550cm-cjo28h, S550CMCJ038H, s550cmcjo28h, S550V, S550X3217CM-SL, S550X3217CMSL, S550X3317CM-SL, S550X3317CMSL, S550X3517CM-SL, S550X3517CMSL, S550XI3517CB-SL, S550XI3517CBSL, S551L, S551L-CJ074H, S551LB-CJ109H, S551LN, S551LN-1A, S55IL, S56, S56 Series, S56C, S56C Series, S56CA, S56CA Series, S56CA-BH51-CB, S56CA-WH31, S56CA-XX011D, S56CA-XX011H, S56CA-XX011V, S56CA-XX015D, S56CA-XX019D, S56CA-XX030R, ASUS [S56CA-XX056R](#) Laptop Battery, S56CAXX011D, S56CAXX011H, S56CAXX011V, S56CAXX015D, S56CAXX019D, S56CAXX030R, S56CAXX056R, s56cb-x0164H, S56CB-XO453H, S56CB-XX009H, S56CB-XX173H, S56CB-XX372H, s56cbx0164H, S56CBXO453H, S56CBXX009H, S56CBXX372H, S56CM, S56CM Series, S56CM-DH51-CA, S56cm-QH71-CB, S56CM-XO263H, s56cm-XX0, S56CM-XX017V, S56CM-XX018V, S56CM-XX028H, S56CM-XX032D, S56CM-XX034X, S56CM-XX035H, S56CM-XX035V, S56CM-XX035X, S56CM-XX046R, S56CM-XX047H, S56CM-XX069D, S56CM-XX070D, S56CM-XX072V, S56CM-XX079H, S56CM-XX079V, S56CM-XX08, S56CM-XX140, S56CM-XX3317S, ASUS [S56CMXX0263H](#) Laptop Battery, s56cmXX0, S56CMXX017V, S56CMXX018V, S56CMXX032D, S56CMXX034X, S56CMXX035H, S56CMXX035V, S56CMXX035X, S56CMXX046R, ASUS [S56CMXX047H](#) Laptop Battery, S56CMXX069D, S56CMXX070D, ASUS [S56CMXX072V](#) Laptop Battery, S56CMXX079H, S56CMXX079V, S56CMXX08, S56CMXX140, S56CMXX3317S, S56X3217CA-SL, S56X3217CASL, S56X3317CB-SL, S56X3317CBSL, S56X3317CM-SL, S56X3317CMSL, ASUS [S5A](#) Laptop Battery, S5N, S5Ne, S5NP, S5V, S5VT6700, S5VT6700-158AXDA6X30, S5VT6700-1B8AXHA6X30, S5VT6700-1C1BXJA6X30, S5VT6700158AXDA6X30, S5VT67001B8AXHA6X30, S5VT67001C1BXJA6X30, ASUS [S6](#) Laptop Battery, S6 Series, S62, S62, S62EP, S62FP, S62H, S6F, S6F Leather Collection, S6Fm, S7VT6700, S8 Series, S8000 Series, S82 Series, S8200 Series, S8600 Series, S96, ASUS [S96J](#) Laptop Battery, S96JF, S96JH, S96JP, S96JS, Series, ASUS [SFB-ASL7000L](#) Laptop Battery, sl101, SONIC MASTER, Sonic Master R202CA, SQU-601, STRISX S5VM, Strix GL502VM-DS74, Strix GL553VD-FY075T, Strix GL553VDFY075T, Strix GL703GM-DS74, Strix S5VM, Strix S5VS, SUSPRO B43A Series, T005, T100H, T100HA, T100HA-3A, T100HA-3D, T100HA-3E, T100HA-3K, T100HA-C4-GR, T100HA-C4-LB, T100HA-C4-R, T100HA-FU006T, T100HA-FU026T, T100HA-FU040T, T100HA_C-3K, T100T TABLET, T100TA, T100TA-C1-RD (S), T100TA-DH12T-CA, T100TA-DK023H, T100TA-DK3H, T100TA-RH11T-CB, T101HA, T101HA-3D, T101HA-3E, T101HA-3K, T101HA-GR001T, T101HA-GR003T, T101HA-GR004T, T101HA-GR005T, T101HA-GR012T, ASUS [T101HA3D](#) Laptop Battery, T101HA3E, T101HA3K, T101HAGR001T, T101HAGR003T, T101HAGR004T, T101HAGR005T, T101HAGR012T, T101MT, T101MT-EU17-BK, T101MT-EU27-BK, T101MT-EU37-BK, T102HA, T12, T12C, T12Eg, T12Er, T12Fg, T12Jg, T12Kg, T12Mg, T12Ug, t199H, T200TA, T200TA-1A, T200TA-1K, T200TA-1R, T200TA1A, T200TA1K, T200TA1R, T300CHI, T300CHI-1A, T300CHI-2A, T300CHI-2G, T300CHI-F1-DB, T300CHI-FH003H, T300CHI-FH011H, T300CHI-FL005T, T300CHI-FL006H, T300CHI-FL008H, T300CHI-FL016H, T300CHI-FL021H, T300CHI-FL021T, T300CHI-FL040H, T300CHI-FL040P, T300CHI-FL043H, T300CHI-FL043T, T300CHI-FL076H, T300CHI-FL086T, T300CHI-FL097H, T300CHI-FL099T, T300CHI-FL121T, ASUS [T300CHI-FL123T](#) Laptop Battery, T300CHI-FL168T, T300CHI-FL186T, T300CHI-RHM5T04, T300CHI_C, T300CHI_C-1A, T300CHI_C-2A, T300LA, T300LA-BB31T, T300LA-US51T, T300LA4008P, T300LABB31T, T300LAUS51T, T302, T302 BATT, T302 BATT LG-POLY T302CHI-2C, T302 BATT LGPOLY T302CHI2C, T302C, T302CA, T302CHI-2C, T302CHI2C, T303, T303U, T303U Tablet, T303UA, ASUS [T303UA-0053G6200U](#) Laptop Battery, T303UA-3G, T303UA-6200GY, T303UA-DH54T, ASUS [T303UA-DS75T](#) Laptop Battery, T303UA-DS76T, T303UA-GN027T, T303UA-GN028R, T303UA-GN032R, T303UA-GN039R,

T303UA-GN040T, T303UA-GN041R, T303UA-GN043R, T303UA-GN043T, T303UA-GN044R, T303UA-GN045T, T303UA-GN046R, T303UA-GN047R, T303UA-GN050R, T303UA-GN050T, T303UA-GN051R, T303UA-GN052T, T303UA-GN053T, T303UA-GN054T, T303UA-GN060R, T303UA-GN060T, T303UA-GN063T, T303UA-XH74T, T303UA6200, T304UA, T304UA-0123B7500U, T304UA-77DHDSB1, T304UA-BC002R, T304UA-BC003R, T304UA-BC003T, T304UA-BC005R, T304UA-BC005T, T304UA-BC006T, T304UA-BC007T, ASUS [T304UA-BC009R](#) Laptop Battery, T304UA-BC011R, T304UA-BC011T, T304UA-BC028R, T304UA-BC029R, T304UA-DS71T, T304UA-GN042R, T304UA-GN042T, T304UA-GN043R, T304UA-GN048T, T304UA-GN049R, T304UA-GN051T, T304UA-GN052T, T304UA-GN061T, T304UA-XS74T, T305, T305C, T305CA, T305CA-3A, T305CA-3G, T305CA3A, T305CA3G, T90CHI, T91MT-BLK028M, Tablet 4170, Tablet K01H, Taichi 21, TAICHI 31, Taichi 31-CX003H, ASUS [TAICHI21](#) Laptop Battery, Taichi21 Notebook PC, TF101-1B001A, ASUS [TF101-1B002A](#) Laptop Battery, TF101-1B003A, TF101-1B004A, TF101-1B006A, TF101-1B011A, TF101-1B012A, ASUS [TF101-1B017A](#) Laptop Battery, TF101-1B023A, TF101-1B025A, TF101-1B026A, TF101-1B027A, TF101-1B028A, TF101-1B029A, TF101-1B030A, TF101-1B031A, TF101-1B033A, TF101-1B046A, TF101-1B047A, TF101-1B048A, TF101-1B050A, TF101-1B090A, TF101-1B097A, TF101-1B100A, TF101-1B118A, TF101-1B135A, TF101-1B141A, TF101-1B179A, TF101-1B180A, TF101-1B185A, TF101-1B186A, TF101-1B221A, TF101-X1 16GB, TF101G-1B034A, ASUS [TF101G-1B046A](#) Laptop Battery, TF101G-1B047A, TF101G-1B048A, TF101G-1B050A, TF101G-1B060A, TF101G-1B115A, TF103CX - Tablet, ASUS [TF2](#) Laptop Battery, TF201-1B002A, TF201-1B04, TF201-1B047A, TF201-1B087A, TF201-1B088A, TF201-1I020A, TF201-1I046A, TF201-1I076A, TF201-1I086A, TF201-1I102A, TF201-1I103A, TF201-1I103A ASUS, TF201-1I104A, TF201G-1I015A, TF300, TF300T, TF300T keyboard dock, TF300TG, TF303CL, TF303CL 1D, TF303CL 1G, TF501T, TF502T, TF502T 1B, TF600, ASUS [TF600T](#) Laptop Battery, TF600T 1B, TF600T-1B016R, TF600T-1B017R, TF600T1B016R, TF600T1B017R, ASUS [TF600TG 1B](#) Laptop Battery, TF600TG-1B015R, TF600TG-1B016R, TF600TG1B015R, TF600TG1B016R, TF600TL 1B, TF600TL-B1-GR, TF600TLB1GR, TF700T, TF810C-1B059W, TP200S, TP200SA, TP200SA-FV0076TS, TP200SA-FV0108TS, TP200SA-FV0110TS, TP200SA-FV0130T, TP200SA-FV0131T, TP200SA-FV0132T, TP200SA-FV0133T, TP200SA3050, TP201, TP201SA, TP201SA-3K, TP201SA3K, TP202, TP202NA, TP202NA-1K, TP202NA-EH022T, TP203NA, TP203NA-1E, TP203NA-1G, TP203NA-1K, TP300, TP300L, TP300LA, TP300LA-1A, TP300LA-1B, TP300LA-C-1A, TP300LA-C4023H, TP300LA-C4025H, TP300LA-C4032H, TP300LA-C4034H, TP300LA-DW007H, TP300LA-DW009H, TP300LA-DW033H, TP300LA-DW035H, TP300LA-DW044H, TP300LA-DW048H, TP300LA-DW060H, TP300LA-DW067H, TP300LA-DW078H, TP300LA-DW106H, TP300LA-DW159H, TP300LA-DW178H, TP300LA-DW179, TP300LA-DW190H, TP300LA-DW224H, TP300LA-DW229H, TP300LA-DW320T, TP300LA-UB52T, TP300LD, TP300LD-1A, TP300LD-4048H, TP300LD-C4030H, TP300LD-C4031H, TP300LD-DW013H, TP300LD-DW021H, TP300LD-DW094H, TP300LD-DW102D, TP300LJ, TP300LJ-1A, TP300LJ-DW004H, TP300LJ-DW055H, TP300LJ-DW066T, TP300UA, TP300UA-1A, TP300UA-1B, TP300UA-C4011T, TP301, TP301U, TP301UA, TP301UA-1A, TP301UA-1B, TP301UA-2C, ASUS [TP301UA-DW009R](#) Laptop Battery, TP301UA-DW009T, TP301UA-DW066T, TP301UA6200, TP301UA6500, TP301UJ, TP301UJ-1A, TP301UJ-1B, TP301UJ-C4011R, TP301UJ-DW026T, TP301UJ-DW027T, TP370, TP370QL, TP401, TP401CA, TP401NA, TP410UA, TP410UF, TP410UR, TP412FA, TP412FA-DB72T, TP412FA-EC011T, TP412FA-EC013T, TP412FA-EC020T, TP412FA-EC026T, TP412FA-OS31T, TP412FA-SB55T, TP412UA, TP412UA-0061B8130U, TP412UA-1A, TP412UA-1B, TP412UA-AS8202T, TP412UA-DB71T, TP412UA-EC035T, TP412UA-EC036T, TP412UA-EC039T, TP412UA-EC047T, TP412UA-

EC056T, TP412UA-EC058T, TP412UA-EC059T, TP412UA-EC060T, TP412UA-EC075T, TP412UA-EC076T, TP412UA-EC089T, TP412UA-EC090T, TP412UA-EC092T, TP412UA-EC098T, TP412UA-EC101T, ASUS [TP412UA-EC109T](#) Laptop Battery, TP412UA-EC114T, TP412UA-EC115T, TP412UA-EC123T, TP412UA-EC127T, TP412UA-EC139T, TP412UA-EC141T, TP412UA-EC173T, TP412UA-EC207T, ASUS [TP412UA-EC231T](#) Laptop Battery, TP412UA-EC249T, TP412UA-EC305T, TP412UA-EC969T, TP412UA-IH31T, TP412UA-S8130, TP500L, TP500LA, TP500LA-1A, TP500LA-CJ041H, TP500LA-CJ062H, TP500LA-DH51T, TP500LA-DH71T, TP500LA-DN041H, TP500LA-DN170H, TP500LA-UB31T, ASUS [TP500LA1A](#) Laptop Battery, TP500LACJ041H, TP500LACJ062H, TP500LADH51T, TP500LADH71T, TP500LADN041H, TP500LADN170H, TP500LAUB31T, TP500LN, ASUS [TP501](#) Laptop Battery, TP501A, TP501UA, TP501UA-1A, TP501UA-CJ016T, TP501UA-CJ027T, TP501UA-DN023T, TP501UA-DN026T, TP501UB, TP501UB-1A, TP501UB-DN010T, TP501UB-DN033T, TP501UQ, TP501UQ-1A, TP501UQ-CJ019TC, TP501UQ-DN015T, TP501UQ-DN029T, TP501UQ-FZ026, TP501UQ-FZ026T, TP501UQ-UB71T, TP510, TP510UA, TP510UA-1A, ASUS [TP510UF](#) Laptop Battery, TP510UF-1A, TP510UQ, TP510UQ-1A, TP550LA-CJ099H, Transformer TF700, Transformer 3 Pro, Transformer 3 Pro T303UA, Transformer 3 Pro T303UA-0053G6200U, Transformer 3 Pro T303UA-GN050T, Transformer 3 Pro T303UA0053G6200U, Transformer 3 Pro T303UAGN050T, ASUS [Transformer 3 T305CA](#) Laptop Battery, Transformer 3 T305CA-GW002T, Transformer 3 T305CA-GW015T, Transformer 3 T305CAGW002T, Transformer 3 T305CAGW015T, Transformer AIO P1801, Transformer AiO P1801 Tablet PC, Transformer AIO P1801-B037K, Transformer AIO P1801-B038K, Transformer AIO P1801-B039K, Transformer AIO P1801-B040K, Transformer AIO P1801-B041K, ASUS [Transformer AIO P1801-B054K](#) Laptop Battery, Transformer AIO P1801-B062K, Transformer AIO P1801-B068K, Transformer AIO P1801-B073K, Transformer AIO P1801-B074K, Transformer AIO P1801-B122K, Transformer AIO P1801-B134K, Transformer AIO P1801-T, Transformer AIO P1801-T-B003M, Transformer AIO P1801-T-B012M, Transformer AIO P1801-T-B016M, Transformer AIO P1802, Transformer AIO P1802-B003Q, Transformer AIO P1802-B015Q, Transformer AIO P1802-T, Transformer AIO P1802-T-B006M, Transformer Book (T100 Chi) 10.1 Inch Windows 8 tablet, Transformer Book Flip Q302L, Transformer Book Flip TP201, Transformer Book Flip TP300L, Transformer Book Flip TP300LA, Transformer Book Flip TP300LD, Transformer Book Flip TP300LJ, Transformer Book Flip TP500LA, Transformer Book Flip TP500LB, Transformer Book Flip TP500LB-CJ015H, ASUS [Transformer Book Flip TP500LB-DN022H](#) Laptop Battery, Transformer Book Flip TP500LB-DN024H, Transformer Book Flip TP500LB-DS71T-CA, Transformer Book Flip TP500LB5500, Transformer Book Flip TP500LBCJ015H, Transformer Book Flip TP500LBDN022H, Transformer Book Flip TP500LBDN024H, Transformer Book Flip TP500LBDS71TCA, Transformer Book Flip TP500LN, Transformer Book Flip TP500LN-0041A4210U, Transformer Book Flip TP500LN-0051A4510U, Transformer Book Flip TP500LN-CJ035H, Transformer Book Flip TP500LN-CJ104H, Transformer Book Flip TP500LN-CJ132H, Transformer Book Flip TP500LN-CJ142D, Transformer Book Flip TP500LN-DB51T-CA, ASUS [Transformer Book Flip TP500LN-DB71T-CA](#) Laptop Battery, Transformer Book Flip TP500LN-DN057H, Transformer Book Flip TP500LN-DN064H, Transformer Book Flip TP500LN-DN066D, Transformer Book Flip TP500LN-DN066H, Transformer Book Flip TP500LN-DN075H, Transformer Book Flip TP500LN-DN109H, Transformer Book Flip TP500LN-DN119H, Transformer Book Flip TP500LN-DN136H, Transformer Book Flip TP500LN-QB72T, ASUS [Transformer Book Flip TP500LN-QB72T-CB](#) Laptop Battery, Transformer Book Flip TP500LN0051A4510U, Transformer Book Flip TP500LN4510, Transformer Book Flip TP500LNCJ035H, Transformer Book Flip TP500LNCJ104H, Transformer Book Flip TP500LNCJ132H, Transformer Book Flip TP500LNCJ142D, Transformer Book Flip TP500LNDB51TCA, Transformer Book Flip TP500LNDB71TCA, Transformer Book Flip

TP500LNDN057H, Transformer Book Flip TP500LNDN064H, Transformer Book Flip TP500LNDN066D, Transformer Book Flip TP500LNDN066H, Transformer Book Flip TP500LNDN075H, Transformer Book Flip TP500LNDN109H, Transformer Book Flip TP500LNDN119H, Transformer Book Flip TP500LNDN136H, Transformer Book Flip TP500LNQB72T, Transformer Book Flip TP500LNQB72TCB, Transformer Book Flip TP550LA, Transformer Book Flip TP550LD 15.6 Inch, Transformer Book Flipp TP500LN0041A4210U, Transformer Book T100, Transformer Book T100 Chi, Transformer Book T100CHI, Transformer Book T100HA, Transformer Book T100T, Transformer Book T100TA, Transformer Book T100TA-DK002H, Transformer Book T100TA-DK003H, Transformer Book T100TA-DK003P, Transformer Book T100TA-DK005H, ASUS [Transformer Book T100TA-DK005PA](#) Laptop Battery, Transformer Book T100TA-DK007H, Transformer Book T100TA-DK007PA, Transformer Book T100TA-DK026H, Transformer Book T100TA-DK048H, Transformer Book T100TA-DK053H, Transformer Book T100TA3735, Transformer Book T100TA3740, Transformer Book T100TAF, Transformer Book T100TAF-DK001B, Transformer Book T100TAF-DK006B, Transformer Book T100TAF-DK008B, Transformer Book T100TAF-DK024B, Transformer Book T100TAF-DK025B, Transformer Book T100TAL-1K, Transformer Book T100TAL-DK008H, Transformer Book T100TAL-DK008P, Transformer Book T100TAL-DK021H, Transformer Book T100TAL-DK021P, Transformer Book T100TAL1K, Transformer Book T100TALDK008H, Transformer Book T100TALDK008P, Transformer Book T100TALDK021H, Transformer Book T100TALDK021P, Transformer Book T100TAM, Transformer Book T100TAM-DK013B, Transformer Book T100TAM-DK014B, Transformer Book T100TAM-DK016B, Transformer Book T100TAM-DK026B, Transformer Book T100TAM-DK564S, Transformer Book T101TA, Transformer Book T200TA, Transformer Book T200TA-C1-BL, Transformer Book T200TAC1BL, Transformer Book T300, Transformer Book T300CHI, Transformer Book T300FA, Transformer Book T300LA, Transformer Book T300LA-BB31T, Transformer Book T300LABB31T, ASUS [Transformer Book T90 Chi](#) Laptop Battery, Transformer Book TP300LA, Transformer Book TP300LD, ASUS [Transformer Book Trio TX201LA](#) Laptop Battery, Transformer Book Trio TX201LA-CQ012H, Transformer Book Trio TX201LA-CQ013, Transformer Book Trio TX201LACQ012H, Transformer Book Trio TX201LACQ013, Transformer Book TX201LAF, Transformer Book TX300, Transformer Book TX300CA, TRANSFORMER MINI, Transformer Mini T102HA, Transformer Mini T102HA-GR012T, Transformer Mini T102HA-GR014T, Transformer Mini T102HA-GR016T, Transformer Mini T102HA-GR019T, Transformer Mini T102HA-GR020T, Transformer Mini T102HA-GR021T, Transformer Mini T102HA-GR022T, Transformer Mini T102HA-GR035T, Transformer Mini T102HA-GR036T, Transformer Mini T102HA-GR043T, Transformer Mini T102HA-GR046T, Transformer Mini T102HAGR012T, Transformer Mini T102HAGR014T, ASUS [Transformer Mini T102HAGR016T](#) Laptop Battery, Transformer Mini T102HAGR019T, Transformer Mini T102HAGR020T, Transformer Mini T102HAGR021T, Transformer Mini T102HAGR022T, Transformer Mini T102HAGR035T, Transformer Mini T102HAGR036T, Transformer Mini T102HAGR043T, Transformer Mini T102HAGR046T, Transformer Pad Series, Transformer Pad TF103C, Transformer Pad TF103C-1A008A, Transformer Pad TF103C-1A009A, Transformer Pad TF103C-1A010A, Transformer Pad TF103C-1A028A, Transformer Pad TF103C-1A029A, Transformer Pad TF103C-1B010A, Transformer Pad TF103C-1B011A, ASUS [Transformer Pad TF103C-1B030A](#) Laptop Battery, Transformer Pad TF103C-1B040A, Transformer Pad TF103C-1B072A, Transformer Pad TF103C-1B049A, Transformer Pad TF103C-K010, Transformer Pad TF103C-R, Transformer Pad TF103CG, Transformer Pad TF103CG-1A012A, Transformer Pad TF103CG-1A021A, Transformer Pad TF103CG-1A060A, Transformer Pad TF103CG-1B022A, Transformer Pad TF103CG-1B024A, Transformer Pad TF103CG-1B025A, Transformer Pad TF103CG-1B043A, Transformer Pad

TF103CG-1B057A, Transformer Pad TF103CX, Transformer Pad TF103CX-1A010A, Transformer Pad TF103CX-1B013A, Transformer Pad TF103CX-A1-BK, Transformer Pad TF303CL, Transformer Pad TF303CL-1D023A, Transformer Pad TF303CL-1D031A, Transformer Pad TF303CL-1D050A, Transformer Pad TF303CL1D023A, Transformer Pad TF303CL1D031A, Transformer Pad TF303CL1D050A, Transformer Pad TF303K, Transformer Pad TF303K-1B014A, Transformer Pad TF303K-1B021A, Transformer Pad TF303K-1D020A, Transformer Pad TF303K-1D021A, [ASUS Transformer Pad TF303K1B014A](#) Laptop Battery, Transformer Pad TF303K1B021A, Transformer Pad TF303K1D020A, Transformer Pad TF303K1D021A, Transformer Pad TF400, Transformer Pad TF500, Transformer Pad TF500T, Transformer Pad TF502T, Transformer Pad TF700, Transformer Pad TF700T, Transformer Pad TF700T-1B063A, Transformer Pad TF700T-1B130A, Transformer Pad TF700T-1B148A, Transformer Pad TF700T-1B149A, Transformer Pad TF700T-1I143A, Transformer Pad TF701T K00C, Transformer Prime TF201, Transformer Prime TF201-1I014A, Transformer Prime TF201-B1-CG, [ASUS Transformer Prime TF201-B1-GR](#) Laptop Battery, Transformer Prime TF201-C1-CG, Transformer Prime TF201-C1-GR, Transformer Pro T303UA, TRANSFORMER PRO T304UA, Transformer T100, Transformer T100HA, Transformer T100TA, Transformer T101TA, Transformer T300 Chi, Transformer T300-Chi, Transformer T300Chi, Transformer TF101-1B004A, Transformer TF101-1B033A, Transformer TF101-1B180A, Transformer TF101-A1, Transformer TF101G - 1B034A, Transformer TF101G-18047A, Transformer TF101G-1B04, Transformer TF101G-1B03, Transformer TF201, Transformer TF300T, Transformer TF300TG, Transformer TF501T, Transformer TF701T, Transformer TP550LA, Transformer TP550LD, Transformer TX300, TravelMate 281, TravelMate 281 Series, TravelMate 281XC, TravelMate 281XV, TravelMate 283LC, TravelMate 283LCi, TravelMate 283XV, TravelMate 283XVi, TravelMate 636LC, TravelMate 636LCi, TravelMate 636LV, TravelMate 636LVi, TravelMate 636XC, TravelMate 636XCi, TravelMate 636XV, TravelMate 636XVi, [ASUS TUF FX504](#) Laptop Battery, TUF FX504 GE, TUF FX504GE, TUF FX505, TUF FX505GE, TUF FX705, TUF FX705 GM, TUF FX705GM, TUF Gaming FX505, TUF Gaming FX705, TX201 Series, TX201LA, TX300CA DH71, U1, U1, U1 series, U13S881, U1E, U1E, [ASUS U1F](#) Laptop Battery, U1F, U2, U20, U20 Series, U20A, U20A-2P005C, U20A-A1, U20A-B1, U20A-B2, U20A-D1, U20F, U20FT, [ASUS U20G](#) Laptop Battery, U24 Series, U24 Series U24A-PX3230H, U24A Series, U24APX3230H, U24E Series, U24E-PX2430R, U24E-XH71, U24E-XS71, U24EPX2430R, U24EX, U24EX-H71, U24EXH71, U24GI231E, U24GI235E, U24GI245E, U2E, U3, U3, U30, U30 Series, [ASUS U303](#) Laptop Battery, U303L, U303LA, U303LA4030, U303LA5005, U303LA5500, U303LB, U303LB5200, U303LN, U303LN4210, [ASUS U303LN5010](#) Laptop Battery, U303LN5200, U305CA, U305CA6Y30, U305F 13.3 inch, U305FA, U305FA5Y10, U305FA5Y71, U305FA6Y30, U305L, U305LA, [ASUS U305UA](#) Laptop Battery, U305UA6200, U30J, U30JC, U30Jc-1A, U30Jc-A1, [ASUS U30Jc-A2B](#) Laptop Battery, U30Jc-B1, U30Jc-X3K, U30JCB1, U30JT, U30S, U30SD, U31, U31 Series, U3100FAL, U3100FN, U3100UN, U31E, U31F, U31J, U31JC, U31JF, U31JG, U31KB815SD, U31KB815SG, U31KI, U31KI243SD, U31KI245SG, U31S, U31SD, U31SD-RX260V, U31SV, U32, U32 Series, U32U, [ASUS U32U-RX019V](#) Laptop Battery, U33 Series, U33J, U33JC, U33JT, U33X, U35 Series, U35F, U35J, U35JC, U35JG, U35JMB, U36, U36 Series, U36-JC, U36J, U36J Series, U36JC, U36JC Series, U36JC-A1, U36JC-B1, [ASUS U36JC-B2B](#) Laptop Battery, U36JC-NYC2, U36JC0 -NYC, U36JC0-NYC, U36K, U36KI, U36S, U36S Series, U36SD, U36SD-A1, U36SD-DH51, U36sd-rx114v, U36SD-XH71, U36SG, U36SG Series, U36SG-DS51, U36SG-RX074V, U36SG-RX268X, U36SG-XS71, U38DT, U38DT-0021A4555M, U38DT-1A, U38DT-BS81-CB, U38DT-R3001H, U38DT-R3002H, U38DT0021A4555M, U38DT1A, U38DTBS81CB, U38DTR3001H, U38DTR3002H, U38K4555DT, U38N, U38N-0021A4555M, U38N-C4004H, [ASUS U38N-C4009P](#) Laptop Battery, U38N-C4010H, U38N-C4011H, U38N-C4016H, U38N-C40A10, U38N-DS81T,

U38N0021A4555M, U38NC4009P, U38NC4010H, U38NC4011H, U38NC4016H, U38NC40A10, U38NDS81T, U3K, U3S, U3S, U3Sg, U3Sg, U4000U, U4000UQ, U40S, U40S Series, U40SD, U40SD Series, U40SV, U41, U41 Series, ASUS [U4100](#) Laptop Battery, U4100U, ASUS [U4100UA](#) Laptop Battery, U4100UN, U4100UQ, ASUS [U410U](#) Laptop Battery, U410UA, U410UQ, ASUS [U41E](#) Laptop Battery, U41F, U41J, U41JC, U41JF, U41JG, U41S, U41SD, U41SV, U43 Series, U4300, U4300F, U4300FA, U4300FN, U43F, U43J, ASUS [U43j-x1](#) Laptop Battery, U43JC, U44, U44 Series, U44EI233SG, U44EI245SG, U44SG, U45 Series, U4500FA, U4500FB, U45J, U45JC, U45JC-A1, U45JT, U46, U46 Series, U46E, U46E Series, U46J, U46J Series, U46JC, U46JC Series, U46S, U46S Series, U46SD, U46SD Series, U46SV, U46SV Series, U47, U47 Series, U47A, U47A-BGR4, U47A-RGR6, U47A-RHI7N15, U47A-RS51, U47ARF, ASUS [U47ARF-RHI7N15](#) Laptop Battery, U47C, U47V, U47VC, U47VC Series, U47VC-DS51, U48, U48C, U48CA, U48CB, U48CM, U5, U5 Series, U50, U50 Series, U5000, U5000U, U5000UQ, U5000UX, ASUS [U5000UX6200](#) Laptop Battery, U5000UX6500, U5000UX7200, U50A, U50A-RBBML05, U50ARBBML05, U50F, U50F-RBBAG05, U50FRBBAG05, U50G, U50V, U50Vg, U50VG XX022C, U50vg-A1, U50Vg-AM1, U50vg-B1, U50Vg-P8700, U50vg-XX008c, U50vg-XX022c, ASUS [U50vg-XX049c](#) Laptop Battery, U50vg-XX061c, U50vg-XX071c, U50VG-XX103C, U50Vg-XX151C, U50Vg-XX152V, U50Vg-XX152X, U52, U52 Series, U52F, U52F-BBL5, U53 Series, U5300FD, U53F, U53J, U53JC, U56, ASUS [U56 Series](#) Laptop Battery, U56E, U56E Series, U56EL, U56J, U56J Series, U56JC, U56JC Series, U56S, U56SV, U58, ASUS [U58C](#) Laptop Battery, U58CA, U58CB, U58CM, U5A, U5A-1A, U5F, U5F-1A, U6E, U6Ep, U6S, U6S, U6Sg, U6Sg, U6V, U6V, U6Vc, ASUS [U6Vc](#) Laptop Battery, U80, U80 LA21, U80 Series, U80A, U80A-RSTM, U80A-RSTML05, U80E, U80F, U80V, U80v-A1, U80v-B2, U80v-wx016c, U80v-wx020c, U80v-wx051e, U80v-wx054c, U80v-wx070e, U80V-wx091, U81, U81 Series, ASUS [U81A](#) Laptop Battery, U81A, U81A-RBBDRD05, U81A-RX05, U82, U82 Series, U82U, ASUS [U82U Series](#) Laptop Battery, UL20, UL20A, UL20A-A1, UL20G, UL20VT, UL30, UL30 Series, UL30A, UL30A-A1, UL30A-A2, UL30A-A3B, UL30A-QX130X, UL30A-QX131X, UL30A-X1, UL30A-X2, UL30A-X3, UL30A-X4, UL30A-X5, UL30J, ASUS [UL30JT](#) Laptop Battery, UL30V, UL30Vt, UL30VT-X1K, UL50, UL50 Series, UL50A, UL50Ag, UL50AG-A2, UL50Ag-A3B, UL50AT, UL50V, UL50Vg, UL50Vg-A2, UL50VS, UL50VS-A1B, UL50Vt, UL50Vt-A1, UL50Vt-X1, UL50Vt-XX009X, UL50Vt-XX010x, UL80, UL80 Series, UL80A, UL80Ag, UL80Ag-A1, UL80J, UL80J-BBK5, UL80JT, ASUS [UL80V](#) Laptop Battery, UL80VS, UL80VT, UL80Vt-A1, UL80Vt-WX009X, UL80Vt-WX010X, Ultrabook Q501LA, UM462DA, UX21, UX21 Series, ux21 ultra slim, UX21 Ultrabook, UX21 Ultrabook Series, UX21A, UX21A Ultrabook, UX21A Ultrabook Series, UX21E, UX21E Ultrabook Series, UX21E-DH52, UX21E-DH71, UX21E-KX001V, UX21E-KX002V, UX21E-KX004V, UX21E-KX004X, UX21E-KX007V, UX21E-KX008V, UX21E-KX008X, UX21E-KX009V, UX21E-KX010V, UX21E-KX011V, UX21E-KX013v, UX21E-KX013X, UX21E-KX014V, UX21E-KX016V, UX21E-KX020D, UX21E-KX128, UX21e-sh52, UX21EDH52, ASUS [UX21EDH71](#) Laptop Battery, UX21EKX001V, UX21EKX002V, UX21EKX004V, UX21EKX004X, UX21EKX007V, UX21EKX008V, UX21EKX008X, ASUS [UX21EKX009V](#) Laptop Battery, UX21EKX010V, UX21EKX011V, UX21EKX013v, UX21EKX013X, UX21EKX014V, UX21EKX016V, UX21EKX020D, UX21EKX128, UX21esh52, UX21L Series, UX30, UX30-A1, UX30-QX005C, UX30-QX007E, UX30-QX011E, UX30-QX015C, ASUS [UX30-QX087X](#) Laptop Battery, UX3000XN, ASUS [UX301L](#) Laptop Battery, UX301LA, UX301LA-1A, UX301LA-1B, UX301LA-2A, UX301LA-C4003H, UX301LA-C4005H, UX301LA-C4006H, UX301LA-C4013H, UX301LA-C4014H, UX301LA-C4145H, UX301LA-DE002H, UX301LA-DE002P, UX301LA-DE022H, UX301LA-DE141T, UX301LA-DE150H, ASUS [UX301LA-DE150P](#) Laptop Battery, UX301LA-DE150T, UX301LA-DE174P, UX301LA-DE175T, UX301LA-DE176T, UX301LA-DH51T, ASUS [UX301LA-DH71T](#)

Laptop Battery, UX301LA-XH72T, UX301LA4500, UX301UQ, UX302LA, UX302LA-1A, UX302LA-C4003H, UX302LA-C4009H, UX302LA1A, UX302LAC4003H, UX302LAC4009H, UX302LG, ASUS [UX302LG-1A](#) Laptop Battery, UX302LG-C4014H, UX302LG-C4027H, UX302LG1A, UX302LGC4014H, UX302LGC4027H, ASUS [UX303](#) Laptop Battery, UX303L, UX303LA, UX303LA-1A, UX303LA-8A, UX303LA-C4089H, UX303LA-C4145H, UX303LA-C4157H, UX303LA-C4164H, UX303LA-C4167H, UX303LA-C4172H, UX303LA-DB51T, UX303LA-DS51T, UX303LA-DS52T, UX303LA-R0267H, UX303LA-R0476H, UX303LA-R0476P, UX303LA-R4165H, UX303LA-R4286T, UX303LA-R4342H, UX303LA-R5065H, UX303LA-R5076H, UX303LA-R5081H, UX303LA-R5088H, UX303LA-R5093H, UX303LA-R5094H, UX303LA-R5095P, UX303LA-R5096H, UX303LA-R5097H, UX303LA-R5098H, UX303LA-R5105H, ASUS [UX303LA-R5160H](#) Laptop Battery, UX303LA-R5166H, UX303LA-RO262P, UX303LA-RO340H, UX303LA-RO341H, UX303LA-RO467H, UX303LA-RO476H, UX303LA-RO476P, UX303LA-US51T, UX303LA_C-1A, UX303LB, UX303LB-1A, UX303LB-8A, UX303LB-DS71T, UX303LB-DS74T, UX303LB-R4040T, UX303LB-R4059H, UX303LB-R4060H, UX303LB-R4060T, UX303LB-R4061H, UX303LB-R4061T, UX303LB-R4062, UX303LB-R4079H, ASUS [UX303LB-R4080P](#) Laptop Battery, UX303LB-R4131H, UX303LB-R4152D, UX303LB-RO124T, UX303LN, UX303LN-1A, UX303LN-8A, UX303LN-C4123P, UX303LN-C4147H, UX303LN-C4175H, UX303LN-DB71T, UX303LN-DQ044H, UX303LN-DQ109H, UX303LN-DQ111H, UX303LN-DQ112H, UX303LN-DQ124H, UX303LN-DQ148P, UX303LN-DQ162H, ASUS [UX303LN-DQ198H](#) Laptop Battery, UX303LN-DQ206, UX303LN-R4108H, UX303LN-R4139H, UX303LN-R4141H, UX303LN-R4142H, UX303LN-R4197H, ASUS [UX303LN-R4199H](#) Laptop Battery, UX303LN-R4200H, UX303LN-R4290H, UX303LN-R4290P, UX303LN-R4318H, UX303LN-R4359H, UX303LN4510, UX303UA, UX303UA-1A, UX303UA-1B, UX303UA-1C, UX303UA-8A, UX303UA-DH51T, UX303UA-R4027T, UX303UA-R4028T, UX303UA-R4039D, ASUS [UX303UA-R4051E](#) Laptop Battery, UX303UA-R4051T, UX303UA-R4089T, UX303UA-R4129E, UX303UA-R4154T, UX303UA-R4155T, UX303UA-R4364T, UX303UA-R4395T, UX303UA-SB51T-CB, UX303UA-XS54, UX303UA-YS51, UX303UB, UX303UB-1A, UX303UB-1B, UX303UB-1C, ASUS [UX303UB-8A](#) Laptop Battery, UX303UB-DQ004T, UX303UB-DQ028T, UX303UB-DQ158R, UX303UB-R4021T, ASUS [UX303UB-R4044T](#) Laptop Battery, UX303UB-R4100T, UX303UB-R4111T, UX305 Series, ASUS [UX305CA](#) Laptop Battery, UX305CA-1A, UX305CA-1B, UX305CA-1C, UX305CA-2A, UX305CA-2C, UX305CA-3C, UX305f, UX305FA, UX305FA-1A, UX305FA-1B, UX305FA-1C, UX305FA-2A, UX305FA-USM1, UX305L, UX305LA, UX305LA-1A, UX305LA-1AFA, UX305LA-1C, UX305LA-C-1A, UX305LA-C1A, UX305LA1A, UX305LA1AFA, UX305LA1C, UX305LA5200, UX305UA, UX305UA-1A, UX305UA-1C, UX305UA-1D, UX305UA1A, UX305UA1C, UX305UA1D, UX305UAB, UX306UA-Q52S-CB, UX30KA, UX30KU, UX30S, UX30S-SU35NEGGAW, UX31, UX31 Series, UX31 Ultrabook, UX310, UX310UA, UX310UA-1A, UX310UA-1C, UX310UA-FB035T, UX310UA-FB038T, UX310UA-FB097T, UX310UA-FC106R, UX310UA-FC132T, ASUS [UX310UA-FC153T](#) Laptop Battery, UX310UA-GL003T, UX310UA-GL011T, UX310UA-GL085T, UX310UA-GL151T, UX310UA-RB52, UX310UA1A, UX310UA1C, UX310UAFB035T, UX310UAFB038T, UX310UAFB097T, UX310UAFC106R, UX310UAFC132T, UX310UAFC153T, UX310UAGL003T, UX310UAGL011T, UX310UAGL085T, UX310UAGL151T, UX310UARB52, UX310UQ, UX310UQ-1A, UX310UQ-1C, UX310UQ-FC275T, UX310UQ-FC365T, UX310UQ-FC366T, UX310UQ-FC367T, UX310UQ-GL026T, UX310UQ-GL163T, UX310UQ1A, UX310UQ1C, UX31A, UX31A Ultrabook, UX31A-1A, UX31A-2A, UX31A-2D, UX31E, UX31E Ultrabook, UX31E-1A, UX31E-1B, UX31E-1C, UX31E-AY009, UX31E-DH52, UX31E-DH53, UX31E-DH72, UX31e-ma1, UX31e-mt1, UX31E-RSL8, UX31E-RY003V, ASUS [UX31E-RY009V](#) Laptop Battery, UX31E-RY010V, UX31E-RY010X, UX31E-

RY012V, UX31E-RY018X, UX31E-RY024V, UX31E-RY256S, UX31e-sh72, UX31e-xh51, UX31e-xh71, UX31e-xh72, UX32, ASUS [UX32 Series](#) Laptop Battery, UX32A, UX32A-0111A3217U, UX32A-1A, UX32A-BHI3N61, UX32A-BHI5N59, UX32A-DB31, UX32A-DB51, UX32A-R3001V, UX32A-R3007H, ASUS [UX32A-R3007V](#) Laptop Battery, UX32A-R3008H, UX32A-R3013H, UX32A-R3024H, UX32A-R3028H, UX32A-R3028P, UX32A-R3037H, UX32A-R3038H, UX32A-R3058H, UX32A-R43317H, UX32A-RHI5N31, UX32A-XB51, UX32A0111A3217U, UX32ABHI3N61, UX32ABHI5N59, UX32ADB31, UX32ADB51, UX32AR3001V, UX32AR3007H, UX32AR3007V, UX32AR3008H, UX32AR3024H, UX32AR3028H, UX32AR3028P, UX32AR3037H, UX32AR43317H, UX32ARHI5N31, UX32AXB51, UX32K, UX32LA, UX32LA-1A, UX32LA1A, ASUS [UX32LN](#) Laptop Battery, UX32LN-1A, UX32LN-R4053H, UX32LN1A, UX32LNR4053H, UX32V, UX32VA, UX32VD, UX32VD Zenbook, UX32VD-0051A3317U, UX32VD-031A3317U, UX32VD-1A, UX32VD-DB71, UX32VD-DH71, UX32VD-DS72, UX32VD-R3001H, UX32VD-R3014H, UX32VD-R4002H, UX32VD-R4002V, UX32VD-R4002X, ASUS [UX32VD-R4003V](#) Laptop Battery, UX32VD-R4010P, ASUS [UX32VD-R4013H](#) Laptop Battery, UX32VD-R4013V, UX32VD-R43317, UX32VD0051A3317U, UX32VD031A3317U, UX32VD1A, UX32VDDH71, UX32VDDS72, UX32VDR3001H, UX32VDR3014H, UX32VDR4002V, UX32VDR4002X, UX32VDR4003V, UX32VDR4010P, UX32VDR4013H, UX32VDR4013V, UX32VDR43317, UX330CA, UX330CA-1A, UX330CA-1C, UX330CA1A, UX330CA1C, UX330UA, UX330UA-1A, UX330UA-1B, UX330UA-1C, ux330ua-ah54, UX330UA1A, UX330UA1B, ASUS [UX330UA1C](#) Laptop Battery, UX330UAK, UX331FAL, UX331FN, UX331UA, UX331UA-1A, UX331UA-1B, UX331UA-1E, UX331UA1A, ASUS [UX331UA1B](#) Laptop Battery, UX331UA1E, UX331UAL-1C, UX331UAL-1D, UX331UAL1C, UX331UAL1D, UX331UN, UX331UN-1A, UX331UN-1B, UX331UN-1E, UX331UN1A, UX331UN1B, UX331UN1E, UX333, UX333FA, UX333FA-0082B8265U, UX333FA-0092S8265U, UX333FA-0122S8565U, UX333FA-0163R8265U, ASUS [UX333FA-8145](#) Laptop Battery, UX333FA-8265, UX333FA-A3022T, UX333FA-A3023T, UX333FA-A3043T, UX333FA-A3064T, UX333FA-A3065T, UX333FA-A3068T, UX333FA-A3070T, UX333FA-A3085R, UX333FA-A3112R, UX333FA-A3132R, UX333FA-A3132T, UX333FA-A3164R, UX333FA-A4011T, UX333FA-A4016T, UX333FA-A4025T, UX333FA-A4041T, UX333FA-A4046T, UX333FA-A4077T, UX333FA-A4081T, UX333FA-A4115T, UX333FA-A4116T, ASUS [UX333FA-A4118T](#) Laptop Battery, UX333FA-A4136T, UX333FA-A4181T, UX333FA-A4185T, UX333FA-A5801T, UX333FA-A5802T, UX333FA-DH51, UX333FN, UX334, UX334FL, UX334FL-0043B8565U, UX334FL-0063B8265U, UX334FL-0098W8565U, UX334FL-30TH, UX334FL-A4003T, UX334FL-A4005T, ASUS [UX334FL-A4011T](#) Laptop Battery, UX334FL-A4015T, UX334FL-A4017R, UX334FL-A4017T, UX334FL-A4021R, UX334FL-A4021T, UX334FL-A4026T, UX334FL-A4033T, UX334FL-A4040T, UX334FL-A4047T, UX334FL-A4052T, UX3400, UX3400UA, UX3400UQ, UX3490UA, UX360, UX360C, ASUS [UX360CA](#) Laptop Battery, UX360CA-1A, UX360CA-1B, UX360CA-C4008T, UX360CA-C4028T, UX360CA-C4041T, UX360CA-FC060T, UX360CA-UBM1T, UX360CA1A, UX360CA1B, UX360CAC4008T, UX360CAC4028T, UX360CAC4041T, UX360CAFC060T, UX360CAUBM1T, UX360UA, UX360UA C4145T, UX360UA-1B, UX360UA-1C, UX360UA-C4010T, UX360UA1A, UX360UA1B, UX360UA1C, UX360UAC4010T, UX362, UX362FA, UX362FA I7, UX362FA-2B, UX362FA-2G, UX370F, UX370UA, UX370UA LASER LABE, UX370UA-0061A7500U, UX370UA-1A, UX370UA-1B, ASUS [UX370UA-C4058T](#) Laptop Battery, UX370UA-C4059T, UX370UA-C4060T, UX370UA-C4118T, UX370UA-C4124T, UX370UA-C4125T, UX370UA-C4131T, UX370UA-C4136T, UX370UA-C4160T, UX370UA-C4170T, UX370UA-C4178T, UX370UA-C4181T, UX370UA-C4184T, UX370UA-C4185T, UX370UA-C4195T, UX370UA-C4196T, UX370UA-C4197T, UX370UA-C4210T, UX370UA-C4217T, UX370UA-C4241T, UX370UA-C4256T, UX370UA-C4290T,

UX370UA-C4305T, UX370UA-C4308T, UX370UA-C4331T, UX370UA-C4341T, UX370UA-C4347T, UX370UA-C4364T, UX370UA-C4367T, UX370UA-EA294R, UX370UA-EA315R, UX370UA-EA328T, UX370UA-EA346R, UX370UA-EA349T, UX370UA-EA371T, UX370UA-EA373T, ASUS [UX370UA-EA376R](#) Laptop Battery, UX370UAF, UX370UAR, UX370UAR-1B, UX390UA, UX390UA-1A, UX390UA-1B, ASUS [UX390UA-1C](#) Laptop Battery, UX390UA-GS031T, UX390UA-GS032T, UX390UA-GS034T, UX390UA-GS039T, UX390UA-GS041T, UX390UA-GS046T, UX390UA-GS063T, UX390UA1A, UX390UA1B, UX390UA1C, UX390UAGS031T, UX390UAGS032T, UX390UAGS034T, UX390UAGS039T, ASUS [UX390UAGS041T](#) Laptop Battery, UX390UAGS046T, UX390UAGS063T, UX390UAK, UX391, UX391UA, UX391UA-1A, UX391UA-2A, UX391UA-3A, UX391UA-3B, UX392FA, UX392FN, UX392FN-2B, UX410UA, UX410UA-1C, UX410UA-3C, UX410UF, UX410UF-1A, UX410UF-1C, UX410UF-3C, UX410UQ, UX410UQ-1A, UX410UQ-1C, UX410UQ-3C, UX410UQ1A, ASUS [UX410UQ1C](#) Laptop Battery, UX42E3517VS-SL, UX42VS, UX42VS-1A, UX430, UX430 Series, UX430U Series, UX430UA, UX430UA Series, UX430UA-1A, UX430UA-1D, UX430UA-2B, ASUS [UX430UA-2C](#) Laptop Battery, UX430UN, UX430UN-1A, UX430UN-1D, UX430UN-2B, UX430UN-2C, UX430UN-4B, UX430UNR, UX430UQ, UX430UQ Series, UX430UQ-1A, UX430UQ-1D, UX430UQ-2B, UX430UQ-2C, UX430UQ-GV015T, UX430UQGV015T, UX430ura, UX431DA, UX431DA-2B, UX431FA, UX431FA-2B, UX431FA-3B, UX431FA-ES51, UX431FA-ES74, UX431FB, UX431FL, UX431FL-AN024T, ASUS [UX431FN](#) Laptop Battery, UX431FN-0023B8565U, UX433, UX433FA, UX433FA-2B, UX433FA-2S, UX433FA-3B, UX433FA-3S, UX433FN, UX433FN-0032B8565U, UX433FN-0072B8565U, UX433FN-0082B8265U, UX433FN-0092S8265U, UX433FN-0112S8565U, UX433FN-0152B8565U, UX433FN-0162B8265U, UX433FN-0172S8265U, UX433FN-0232S8565U, ASUS [UX433FN-2B](#) Laptop Battery, UX433FN-2S, UX433FN-3B, UX433FN-3S, UX433FN-IH74, UX434DA, UX434FL-78DM5AB1, UX434FL-A5801T, UX434FL-A6002TS, UX434FL-A6007T, UX434FL-A6009R, UX434FL-A6009T, UX434FL-A6012T, UX434FL-A6013T, UX434FL-A6014R, UX434FL-A6015T, UX434FL-A6019R, UX434FL-A6026T, UX434FL-A6058T, UX434FL-A6075T, UX434FL-AI017T, UX434FL-AI018R, UX434FL-AI022R, UX434FL-AI025T, UX434FL-AI034R, UX434FL-AI062T, UX434FL-AI064T, UX434FL-DB77, UX434FL-PURE2X, UX450, UX450F, UX450FD, UX450FDX, UX450FDX-1A, UX460UA, UX460UA-1B, UX461, UX461FA, UX461FA-1A, UX461FA-1C, ASUS [UX461FN](#) Laptop Battery, ASUS [UX461FN-1A](#) Laptop Battery, UX461FN-1C, UX461UA, UX461UA-1A, UX461UA-1C, ASUS [UX461UA-BS5](#) Laptop Battery, UX461UA-E1072T, UX461UA1A, ASUS [UX461UAE1072T](#) Laptop Battery, UX461UN, UX461UN-1A, UX461UN-1C, UX462, UX462D, UX462DA, UX462DA-2G, UX463FA, UX463FA-AI012R, UX463FA-AI014R, UX463FA-AI026T, UX463FA-AI028T, UX463FA-AI038T, UX463FA-AI040R, UX463FL, UX463FL-AI023R, UX463FL-AI023T, UX463FL-AI025R, UX463FL-AI031R, UX463FL-AI041T, UX463FL-AI070T, UX480, UX480F, UX480FD, UX490, UX490 Series, UX490U, UX490U Series, UX490UA, UX490UA Series, UX490UA-BE010T, UX490UA-BE012T, UX490UA-BE029T, UX490UA-BE032T, UX490UA-BE038T, UX490UA-BE043T, UX490UA-BE044T, UX490UA-BE045T, UX490UA-BE106T, UX490UA-BE107R, UX490UA-BE111T, UX490UA-IH74-BL, UX490UA-XS74-BL, UX490UAK, ASUS [UX490UAR](#) Laptop Battery, UX490UAR-BE082T, UX490UAR-BE087R, UX490UAR-BE087T, UX490UAR-BE088R, UX490UAR-BE088T, UX490UAR-BE094T, ASUS [UX490UAR-BE104T](#) Laptop Battery, UX490UAR-BE110T, UX50, UX501, UX501JW, UX501JW-CN245P, UX501JW-CN245R, ASUS [UX501JW-CN245T](#) Laptop Battery, UX501JW-DS71T, UX501JW-FI177H, UX501JW-FI177T, UX501JW-FI218H, UX501JW-FI218T, UX501JW4720, UX501JWCN245P, UX501JWCN245R, UX501JWCN245T, UX501JWDS71T, UX501JWFI177H, UX501JWFI177T, UX501JWFI218H, UX501JWFI218T,

UX501LW, UX501VW, UX501VW-F1020, UX501VW-FJ214T, UX501VW-FY010T, UX501VW-FY057R, ASUS [UX501VW-FY062T](#) Laptop Battery, UX501VW-FY102R, UX501VW-FY144T, UX501VW-FY145T, UX501VWF1020, UX501VWFY010T, UX501VWFY057R, UX501VWFY062T, UX501VWFY102R, UX501VWFY144T, UX501VWFY145T, UX50v, UX50V-RX05, ux50v-xx004c, UX510, UX510UQ-0091A7200U, UX510UQ-0133B7200U, UX510UW, UX510UW-1A, UX510UW-CN044T, UX510UW-CN048T, UX510UW-CN051T, ASUS [UX510UW-CN056T](#) Laptop Battery, UX510UW-CN058T, UX510UW-CN077T, UX510UW-CN114R, UX510UW-CN142T, UX510UW-CN143R, UX510UW-CN216T, UX510UW-DM066T, ASUS [UX510UW-DM088T](#) Laptop Battery, UX510UW-DM099T, UX510UW-DM100R, UX510UW-DM136T, UX510UW-FI046T, UX510UW-FI050T, UX510UW-FI063T, UX510UW-FI074R, UX510UW-FI095T, UX510UW-FI117T, UX510UW-FI140R, ASUS [UX510UW-RB71](#) Laptop Battery, UX510UW1A, UX510UWK, UX510UWRB71, UX510UX, UX510UX-1A, UX510UX-CN020T-BE, UX510UX-CN044T, UX510UX-CN056T, UX510UX-CN085T, UX510UX-CN095T, UX510UX-CN098T, UX510UX-CN108T, UX510UX-CN120T, UX510UX-CN121T, UX510UX-CN130T, UX510UX-CN173T, UX510UX-CN180T, UX510UX-CN188T, UX510UX-CN204T, UX510UX-CN207T, UX510UX-CN209T, UX510UX-CN211T, UX510UX-CN234R, UX510UX-CN246R, UX510UX-CN253T, UX510UX-CN266T, UX510UX-CN280T, UX510UX-CN298T, UX510UX-DM011T, ASUS [UX510UX-DM039T](#) Laptop Battery, UX510UX-DM066T, UX510UX-DM094T, UX510UX-DM095T, UX510UX-DM102T, UX510UX-DM109T, UX510UX-DM163T, UX510UX-DM165T, UX510UX-DM195T, UX510UX-DM197T, UX510UX-DM203T, UX510UX-DM228T, UX510UX-DM229T, UX510UX-DM242T, UX510UX-DM285T, UX510UX-FI143T, UX510UX-FI144T, UX510UX1A, UX510UXCN020TBE, UX510UXCN044T, UX510UXK, UX51V, UX51VZ, UX52, UX52A, UX52S, UX52V, UX52VS, UX52VS-1A, UX52VS-CN021H, UX52VS-CN028H, UX52VS-CN035H, UX52VS-CN036P, UX52VS-CN037H, UX52VS1A, UX52VSCN021H, UX52VSCN028H, UX52VSCN035H, UX52VSCN036P, UX52VSCN037H, UX530, UX530UQ, UX530UX, UX533, UX533FD, ASUS [UX533FD-NS76](#) Laptop Battery, UX534FA, UX534FT, UX534FT-0043B8565U, UX534FT-78D15AB, UX534FT-A7601T, UX534FT-A9002T, UX534FT-A9004T, ASUS [UX534FT-A9009R](#) Laptop Battery, UX534FT-A9011T, UX534FT-A9012T, ASUS [UX534FT-A9012TS](#) Laptop Battery, UX534FT-A9023T, UX534FT-AA024R, UX534FT-AA025R, UX534FT-AA025T, UX534FT-AA028R, UX534FT-AA028T, UX534FT-DB77, UX534FTC, UX550, UX550GD, UX550GD-1C, UX550GD1C, UX550GDX, UX550GDX-1C, UX550GDX1C, UX550GE, UX550GE-1C, UX550GE1C, UX550GEX, UX550GEX-1C, UX550GEX1C, UX550VD, UX550VD-1A, UX550VD-1B, UX550VE, UX550VE-1A, UX550VE-1B, UX560UA, UX560UA-1B, UX560UA1B, UX560UAK, UX560UQ, UX560UQ-1A, UX560UQ-1C, UX560UQ1A, UX560UQ1C, UX560UX, UX560UX-1A, UX560UX-1C, UX560UX1A, UX560UX1C, UX561UA, UX561UA-1A, UX561UA-1B, UX561UA-2G, UX561UA-8G, UX561UA1A, UX561UA1B, UX561UA2G, UX561UA8G, UX561UD, UX561UD-1A, UX561UN, UX561UN-1A, UX561UN-1B, UX561UN1, UX561UN1A, UX562, UX562FA, UX562FA-2G, ASUS [UX562FA-2S](#) Laptop Battery, UX562FA-AC023R, UX562FD, UX562FD-2G, UX562FD-A1008T, UX562FD-A1017T, UX562FD-A1018T, UX562FD-A1039T, UX562FD-A1054T, UX562FD-A1061TS, UX562FD-EZ010T, UX562FD-EZ012T, UX562FD-EZ013T, UX562FD-EZ019T, ASUS [UX562FD-EZ021T](#) Laptop Battery, UX562FD-EZ022T, UX562FD-EZ044R, UX562FD-EZ050R, UX562FD-EZ055R, UX562FD-EZ058T, UX562FD-EZ068R, UX562FD-EZ073T, UX562FD-EZ078T, UX562FD-EZ081T, UX562FD-EZ083T, UX562FDX, UX562FDX-A1005R, ASUS [UX562FDX-A1007R](#) Laptop Battery, UX562FDX-A1008T, UX562FDX-A1016T, UX562FDX-A1030T, UX562FDX-A1035T, UX562FDX-EZ002T, UX562FDX-EZ015T, UX562FDX-EZ023R, UX562FDX-EZ029T, UX562FDX-EZ031T, UX562FDX-EZ040T, UX562FN, UX563FD, UX580, UX580G, UX580GD, UX580GE, V1, V1 Series,

V1J, V1Jp, V1S, V1Sn, V1V, V2, V2J, V2Je, V2S, V405, V405LB, V430FA, V430FN, V430UF, V431FA, V431FL, V451LN, V500C, V500CA-BB31T, V550, V550-CB, V550C, V550CA, V550CB-CJ113H, ASUS [V550CB-SH51T-CB](#) Laptop Battery, V550CBCJ113H, ASUS [V550CM](#) Laptop Battery, V551L, V551LA, V551LA-DH51T, V6, V6000, ASUS [V6000V](#) Laptop Battery, V6000V series, V6J, V6V, V6VA, ViewBook Q301LA-BSI5T17 13.3", Vivo Tab TF6P00T Tablet, VivoBook 14 A412FA, VivoBook 14 F412DA, VivoBook 14 F412FA, VivoBook 14 F412FA-EB019T, VivoBook 14 F412FA-EB025T, VivoBook 14 F412FA-EB089T, VivoBook 14 F412FA-EB133T, VivoBook 14 F412FA-EB134T, VivoBook 14 F412FJ, VivoBook 14 F412FJ-EB084T, VivoBook 14 F412FJ-EB118T, VivoBook 14 F412FJ-EB119T, VivoBook 14 F412UA, ASUS [VivoBook 14 F412UA-BV156T](#) Laptop Battery, ASUS [VivoBook 14 X403FA](#) Laptop Battery, VIVOBOK 14 X403FA-EB021T, VivoBook 14 X411QR, VivoBook 14 X411UA, VivoBook 14 X411UQ, VivoBook 14 X412FA, VivoBook 14 X412FA-EB019T, VIVOBOK 14 X412FA-EB021T, VIVOBOK 14 X412FA-EB025, VIVOBOK 14 X412FA-EB025T, VIVOBOK 14 X412FA-EB057, VIVOBOK 14 X412FA-EB099T, VIVOBOK 14 X412FA-EB235T, Vivobook 14 X412fa-ek177t, Vivobook 14 X412fa-ek186t, Vivobook 14 X412fa-ek230t, Vivobook 14 X412fa-ek268t, ASUS [Vivobook 14 X412fa-ek295t](#) Laptop Battery, Vivobook 14 X412fa-ek314t, Vivobook 14 X412fa-ek401t, VivoBook 14 X412FJ, Vivobook 14 X412FJ-BV201T, Vivobook 14 X412FJ-BV207T, Vivobook 14 X412FJ-BV208T, VivoBook 14 X412FJ-EB023T, VivoBook 14 X412FJ-EB102, VivoBook 14 X412FJ-EK091T, VivoBook 14 X412FJ-EK178T, VivoBook 14 X412FJ-EK215T, VivoBook 14 X412FJ-EK216T, VivoBook 14 X412FL, VivoBook 14 X412FL-EK084T, VIVOBOK 14 X412FL-EK085T, VivoBook 14 X412FL-EK086T, VivoBook 14 X412UA, VivoBook 14 X412UB, VivoBook 14 X412UF, VivoBook 14 X420UA, VivoBook 14 X420UA-BV083T, ASUS [VivoBook 14 X420UA-BV124T](#) Laptop Battery, VivoBook 14 X420UA-BV143T, VivoBook 14 X420UA-CBI5A, VivoBook 14 X420UA-EB184T, VivoBook 14 X420UA-EK019T, VivoBook 14 X420UA-EK050T, VivoBook 14 X420UA-EK059T, VivoBook 14 X420UA-EK073T, VivoBook 14 X420UA-EK112T, VivoBook 14 X420UA-EK127T, VivoBook 14 X420UA-EV075T, ASUS [VivoBook 14 X442U](#) Laptop Battery, VivoBook 15 F505, VivoBook 15 F505ZA, VivoBook 15 F505ZA-BQ112T, VivoBook 15 F505ZA-BQ160T, VivoBook 15 F510UF, VivoBook 15 F510UF-BQ274T, VivoBook 15 F510UF-BQ349T, VivoBook 15 F510UF-BR683R, ASUS [VivoBook 15 F510UF-EJ252T](#) Laptop Battery, VivoBook 15 F510UF-EJ309T, VivoBook 15 F510UF-EJ524T, VivoBook 15 F510UF-EJ579T, VivoBook 15 F510UR, VivoBook 15 F510UR-EJ342T, VivoBook 15 F512FA, VivoBook 15 F512FA-BQ067T, VivoBook 15 F512FA-BQ145T, VivoBook 15 F512FA-BQ148T, VivoBook 15 F512FA-BQ150R, VivoBook 15 F512UA, VivoBook 15 F512UA-BQ251T, VivoBook 15 F512UB, VivoBook 15 F512UB-BQ039T, VivoBook 15 K570UD, VivoBook 15 K570UD-DM009T, VivoBook 15 K570UD-DM276T, VivoBook 15 K570UD-DS74, VivoBook 15 K570UD-ES54, VivoBook 15 K570UD-ES76, VivoBook 15 S510UN, VivoBook 15 S510UN-BQ149T, VivoBook 15 S510UN-BQ256T, VivoBook 15 S510UN-BQ299T, VivoBook 15 S510UN-BQH46T, VivoBook 15 S510UN-BR128, VivoBook 15 X505, VivoBook 15 X505BA, VivoBook 15 X505BA-BR016T, ASUS [VivoBook 15 X505BA-RB94](#) Laptop Battery, VivoBook 15 X505BP, VivoBook 15 X505BP-BR007T, VivoBook 15 X505BP-BR013T, VivoBook 15 X505ZA, VivoBook 15 X505ZA-BQ072T, VivoBook 15 X505ZA-BQ117T, VivoBook 15 X505ZA-BQ4040T, VivoBook 15 X505ZA-BQ404T, VivoBook 15 X505ZA-EJ618T, VivoBook 15 X510, VivoBook 15 X510U, VivoBook 15 X510UA, VivoBook 15 X510UA-BQ364T, VivoBook 15 X510UA-BR305T, VivoBook 15 X510UA-EJ698T, VivoBook 15 X510UA-EJ706T, ASUS [VivoBook 15 X510UA-EJ707T](#) Laptop Battery, VivoBook 15 X510UA-EJ708T, VivoBook 15 X510UA-EJ714T, VivoBook 15 X510UF, VivoBook 15 X510UF-BQ002T, VivoBook 15 X510UN, VivoBook 15 X510UQ, VivoBook 15 X510UQ-BQ359T, VivoBook 15 X510UQ-BQ534T, VivoBook 15 X510UQ-BQ743T, VivoBook 15 X510UR, VivoBook 15 X510UR-3B,

ASUS [VivoBook 15 X510UR-BQ118T](#) Laptop Battery, VivoBook 15 X510UR-BR107T, VivoBook 15 X512DA, VIVOBOK 15 X512DA-EJ271T, VIVOBOK 15 X512DA-EJ312T, ASUS [VIVOBOK 15 X512DK](#) Laptop Battery, VIVOBOK 15 X512DK-EJ036, VIVOBOK 15 X512DK-EJ045, VivoBook 15 X512FA, VivoBook 15 X512FA-BQ062T, VivoBook 15 X512FA-BQ063T, VivoBook 15 X512FA-BQ064T, VivoBook 15 X512FA-BQ067T, VivoBook 15 X512FA-EJ134T, VivoBook 15 X512FA-EJ135T, VivoBook 15 X512FA-EJ136T, VivoBook 15 X512FB, VivoBook 15 X512FB-EJ016T, VIVOBOK 15 X512FJ, VIVOBOK 15 X512FJ-EJ046T, ASUS [VIVOBOK 15 X512FJ-EJ167T](#) Laptop Battery, VIVOBOK 15 X512FL, VIVOBOK 15 X512FL-0241G8565U, VIVOBOK 15 X512FL-0348B8265U, VIVOBOK 15 X512FL-0398S8265U, VivoBook 15 X512FL-BQ060, VivoBook 15 X512FL-BQ122T, VivoBook 15 X512FL-BQ259T, VivoBook 15 X512FL-BQ260T, VivoBook 15 X512FL-BQ261T, VivoBook 15 X512FL-BQ262T, VivoBook 15 X512FL-BQ263T, VIVOBOK 15 X512FL-BQ363, VIVOBOK 15 X512FL-EJ158T, VIVOBOK 15 X512FL-EJ159T, VIVOBOK 15 X512FL-EJ160T, VIVOBOK 15 X512FL-EJ161T, VIVOBOK 15 X512FL-EJ197T, VIVOBOK 15 X512FL-EJ201T, VIVOBOK 15 X512FL-EJ202T, VIVOBOK 15 X512FL-EJ205T, VIVOBOK 15 X512FL-EJ207T, VIVOBOK 15 X512FL-EJ372T, VivoBook 15 X512UA, VivoBook 15 X512UA-EJ243T, VivoBook 15 X512UB, VivoBook 15 X512UB-BR010T, ASUS [VivoBook 15 X512UF](#) Laptop Battery, VivoBook 15 X512UF-BQ135T, VivoBook 15 X512UF-EJ041T, ASUS [VivoBook 15 X542BA](#) Laptop Battery, VivoBook 17 X712FA, ASUS [VivoBook 17 X712FB](#) Laptop Battery, VivoBook 4000, VivoBook 4000 MX555 Series, VivoBook 4000 V555L, VivoBook A551LB, VivoBook A551LB-XX134H, Vivobook A551LB-XX233H, VivoBook A551LB-XX234H, Vivobook A551LB-XX317H, VivoBook E12 E203NA, VivoBook E12 E203NA-FD020TS, VivoBook E12 E203NA-FD021T, ASUS [VivoBook E12 E203NA-FD021TS](#) Laptop Battery, VivoBook E12 E203NA-FD026T, VivoBook E12 E203NA-FD029T, Vivobook E12 E203NA-FD029TS, VivoBook E12 E203NA-FD048T, VivoBook E12 E203NA-FD084T, Vivobook E12 E203NA-FD087T, VivoBook E12 E203NA-FD088T, Vivobook E12 E203NA-FD108TS, VivoBook E12 E203NA-FD109TS, VivoBook E12 E203NAFD020TS, VivoBook E12 E203NAFD021T, ASUS [VivoBook E12 E203NAFD021TS](#) Laptop Battery, VivoBook E12 E203NAFD026T, VivoBook E12 E203NAFD029T, Vivobook E12 E203NAFD029TS, VivoBook E12 E203NAFD084T, Vivobook E12 E203NAFD087T, VivoBook E12 E203NAFD088T, Vivobook E12 E203NAFD108TS, VivoBook E12 E203NAFD109TS, VivoBook E12 E203NAH, VivoBook E12 E203NAH-FD009T, VivoBook E12 E203NAH-FD013T, VivoBook E12 E203NAH-FD019T, VivoBook E12 E203NAH-FD057T, VivoBook E12 E203NAH-FD059T, VivoBook E12 E203NAH-FD060T, VivoBook E12 E203NAH-FD060TS, VivoBook E12 E203NAH-FD075T, VivoBook E12 E203NAHFD009T, VivoBook E12 E203NAHFD013T, VivoBook E12 E203NAHFD019T, VivoBook E12 E203NAHFD057T, VivoBook E12 E203NAHFD059T, VivoBook E12 E203NAHFD060T, VivoBook E12 E203NAHFD060TS, VivoBook E12 E203NAHFD075T, VivoBook E200HA, VivoBook E200HA-1A, VivoBook E200HA-1B, VivoBook E200HA-1E, VivoBook E200HA-1G, VivoBook E200HA1A, VivoBook E200HA1B, VivoBook E200HA1E, VivoBook E200HA1G, VivoBook E203MA, VivoBook E203MA-FD004TS, VivoBook E203MAFD004TS, Vivobook E203NA-FD026T, ASUS [VivoBook E402NA](#) Laptop Battery, VivoBook E403NA, VivoBook F200CA, VivoBook F505, VivoBook F505BA, VivoBook F505BA-BR036T, VivoBook F505BA-BR037T, VivoBook F505BA-BR038T, VivoBook F505BA-BR067T, VivoBook F510UA, VivoBook F510UA-AH50, VivoBook F510UA-AH51, Vivobook F510UA-AH55, VivoBook F510UF-BQ697T, VivoBook F541NA, VivoBook F541NA-GQ050T, VivoBook F541NA-GQ052T, ASUS [VivoBook F541NA-GQ054T](#) Laptop Battery, VivoBook F541NA-GQ384T, VivoBook F541NA-GQ386T, VivoBook F541NA-GQD33T, VivoBook F541NA-GQD64T, VivoBook F541UV, VivoBook F541UV-DM890T, VivoBook F541UV-XO242T, VivoBook F541UV-XX149T, VivoBook F541UV-

XX339T, VivoBook F555BA, VivoBook F555BA-DM176T, VivoBook F555UA, VivoBook F555UA-XX030T, VivoBook F555UA-XX066T, Vivobook F556UQ, Vivobook F556UQ-DM1011T, Vivobook F556UQ-DM1209, Vivobook F556UQ-DM1237, Vivobook F556UQ-DM1289, ASUS [Vivobook F556UQ-DM233D](#) Laptop Battery, Vivobook F556UQ-DM627D, Vivobook F556UQ-DM705T, Vivobook F556UQ-DM736T, Vivobook F556UQ-DM739, Vivobook F556UQ-DM831T, Vivobook F556UQ-XO1086T, Vivobook F556UQ-XO137T, Vivobook F556UQ-XO139T, Vivobook F556UQ-XO528D, Vivobook F556UQ-XO626D, Vivobook F556UQ-XO628D, Vivobook F556UR, Vivobook F556UR-XO037T, Vivobook F556UR-XO038T, Vivobook F556UR-XO039T, VivoBook F751NA-TY015T, VivoBook F751NA-TY017T, VivoBook F751NA-TY024, VivoBook Flip 12 TP202NA, VivoBook Flip 12 TP202NA-DH01T, VivoBook Flip 12 TP202NA-EH001T, VivoBook Flip 12 TP202NA-EH008T, VivoBook Flip 12 TP202NA-EH012TS, VivoBook Flip 12 TP202NA-EH015T, VivoBook Flip 12 TP202NA-EH088TS, VivoBook Flip 12 TP203NA, VivoBook Flip 12 TP203NA-BP025T, VivoBook Flip 12 TP203NA-BP027TS, VivoBook Flip 12 TP203NA-BP029T, VivoBook Flip 12 TP203NA-BP034TS, VivoBook Flip 12 TP203NA-BP051T, VivoBook Flip 12 TP203NA-BP055TS, VivoBook Flip 12 TP203NA-BP063T, VivoBook Flip 14 TP410UA, VivoBook Flip 14 TP410UA-EC229T, VivoBook Flip 14 TP410UA-EC235T, VivoBook Flip 14 TP410UA-EC242T, ASUS [VivoBook Flip 14 TP410UA-EC243T](#) Laptop Battery, VivoBook Flip 14 TP410UA-EC245T, VivoBook Flip 14 TP410UA-EC334T, VivoBook Flip 14 TP410UA-EC338T, VivoBook Flip 14 TP410UA-EC405T, VivoBook Flip 14 TP410UA-EC407T, VivoBook Flip 14 TP410UA-EC410T, VivoBook Flip 14 TP410UA-EC541T, VivoBook Flip 14 TP410UF, VivoBook Flip 14 TP410UF-EC003T, VivoBook Flip 14 TP410UR, VivoBook Flip 14 TP410UR-EC065T, VivoBook Flip 14 TP410UR-EC073T, VivoBook Flip 14 TP410UR-EC084T, VivoBook Flip 14 TP410UR-EC089T, VivoBook Flip 14 TP412FA, VivoBook Flip 14 TP412FA-EC010T, VivoBook Flip 14 TP412FA-EC035T, VivoBook Flip 14 TP412FA-EC131T, VivoBook Flip 14 TP412FA-EC134T, ASUS [VivoBook Flip 14 TP412FA-EC226R](#) Laptop Battery, VivoBook Flip 14 TP412FA-EC924T, VivoBook Flip 14 TP412UA, VivoBook Flip 14 TP412UA-DB21T, VivoBook Flip 14 TP412UA-DB31T, VivoBook Flip 14 TP412UA-DB51T, VivoBook Flip 14 TP412UA-DB71T, VivoBook Flip 14 TP412UA-EC034T, VivoBook Flip 14 TP412UA-EC036T, VivoBook Flip 14 TP412UA-EC039T, VivoBook Flip 14 TP412UA-EC047T, VivoBook Flip 14 TP412UA-EC053R, VivoBook Flip 14 TP412UA-EC053T, VivoBook Flip 14 TP412UA-EC055T, VivoBook Flip 14 TP412UA-EC056T, VivoBook Flip 14 TP412UA-EC057T, VivoBook Flip 14 TP412UA-EC059T, VivoBook Flip 14 TP412UA-EC069R, VivoBook Flip 14 TP412UA-EC069T, VivoBook Flip 14 TP412UA-EC072T, VivoBook Flip 14 TP412UA-EC076T, VivoBook Flip 14 TP412UA-EC090T, VivoBook Flip 14 TP412UA-EC093T, VivoBook Flip 14 TP412UA-EC113T, VivoBook Flip 14 TP412UA-EC115T, VivoBook Flip 14 TP412UA-EC123T, ASUS [VivoBook Flip 14 TP412UA-EC123TS](#) Laptop Battery, VivoBook Flip 14 TP412UA-EC130T, VivoBook Flip 14 TP412UA-EC226T, VivoBook Flip 14 TP412UA-EC231T, VivoBook Flip 14 TP412UA-EC244T, VivoBook Flip 14 TP412UA-EC298R, VivoBook Flip 14 TP412UA-EC305T, VivoBook Flip 14 TP412UA-EC312T, VivoBook Flip 14 TP412UA-EC969T, VivoBook Flip 14 TP412UA-IH31T, VivoBook Flip 14 TP412UA-S8130, VivoBook Flip 14 TP412UA-XB51T, VivoBook Flip 14TP412UA-EC140T, VivoBook Flip 15 TP510UA, VivoBook Flip 15 TP510UA-E8066T, VivoBook Flip 15 TP510UA-E8073T, VivoBook Flip 15 TP510UA-E8077T, VivoBook Flip 15 TP510UQ, VivoBook Flip 15 TP510UQ-E8033T, VivoBook Flip 15 TP510UQ-E8034T, VivoBook Flip F510UQ, Vivobook Flip TP202NA, VivoBook Flip TP202NA-EH007T, VivoBook Flip TP202NA-OB04T, VivoBook Flip TP301UA, VivoBook Flip TP301UJ, Vivobook Flip TP401N, VivoBook Flip TP501, ASUS [VivoBook Flip TP501UA](#) Laptop Battery, VivoBook Flip TP501UB, VivoBook Flip TP501UQ, VivoBook K551LB-XX164D, VivoBook K551LB-XX171H, VivoBook K551LB-XX202D,

VivoBook K551LB-XX210H, VivoBook K551LB-XX252D, VivoBook K551LB-XX258D, VivoBook K556UA-DM108T, ASUS [VivoBook K556UA-DM146T](#) Laptop Battery, VivoBook K556UA-DM956T, VivoBook K556UA-Q72-CB, VivoBook K556UA-WH51, VivoBook K556UA-XO552T, VivoBook K556UA-XX603T, VivoBook K556UA-XX606T, VivoBook Max R541UA, VivoBook Max X441, VivoBook Max X441B, ASUS [VivoBook Max X441BA](#) Laptop Battery, ASUS [VivoBook Max X441N](#) Laptop Battery, VivoBook Max X441NC, VivoBook Max X441U, VivoBook Max X441UA, VivoBook Max X441UR, VivoBook Max X441UV, VivoBook Max X541N, VivoBook Max X541NA-YS01, VivoBook Max X541SA, VivoBook Max X541UA, VivoBook Max X541UA-DM007D, VivoBook Max X541UA-DM015T, VivoBook Max X541UA-DM1499T, VivoBook Max X541UA-DM1930T, VivoBook Max X541UA-DM2090T, VivoBook Max X541UA-DM233T, VivoBook Max X541UA-DM594T, VivoBook Max X541UA-DM917T, VivoBook Max X541UA-DM993T, VivoBook Max X541UA-GQ1025T, VivoBook Max X541UA-GQ1026T, VivoBook Max X541UA-GQ1027T, VivoBook Max X541UA-GQ1094T, VivoBook Max X541UA-GQ1246T, VivoBook Max X541UA-GQ1248T, VivoBook Max X541UA-GQ1859T, VivoBook Max X541UA-GQ2085T, VivoBook Max X541UA-GQ2086T, VivoBook Max X541UA-GQ2087T, VivoBook Max X541UA-GQ2088T, VivoBook Max X541UA-GQ2089T, VivoBook Max X541UA-GQ2091T, VivoBook Max X541UA-GQ871T, VivoBook Max X541UA-GQ916D, VivoBook Max X541UA-WB51, VivoBook Max X541UA-XO112D, VIVOBOK N752VX-GC190T, VivoBook Pro 15 N580VD, VivoBook Pro 15 N580VD-DM027T, VivoBook Pro 15 N580VD-DM028T, VivoBook Pro 15 N580VD-DM039T, VivoBook Pro 15 N580VD-DM651T, VivoBook Pro 15 N580VD-FI024T, VivoBook Pro 15 N580VD-FI033T, ASUS [VivoBook Pro 15 N580VD-FI506T](#) Laptop Battery, VivoBook Pro 15 N580VD-FY246T, VivoBook Pro 15 N580VD-FY252T, VivoBook Pro 15 N580VD-FY255T, VivoBook Pro 15 N580VD-FY256T, VivoBook Pro N552VW, VivoBook Pro N552VW-DS79, VivoBook Pro N552VW-FI035T, VivoBook Pro N552VW-FI040T, VivoBook Pro N552VW-FI056T, VivoBook Pro N552VW-FI058T, VivoBook Pro N552VW-FI101T, VivoBook Pro N552VW-FI136T, VivoBook Pro N552VW-FI223T, VivoBook Pro N552VW-FI266T, VivoBook Pro N552VW-FW026T, VivoBook Pro N552VW-FY058T, VivoBook Pro N552VW-FY083T, VivoBook Pro N552VW-FY094T, VivoBook Pro N552VW-FY217T, VivoBook Pro N552VW-FY271T, VivoBook Pro N552VW-FY382T, VivoBook Pro N552VW-XS76, VivoBook Pro N552VX, VivoBook Pro N552VX-FI018T, VivoBook Pro N552VX-FY012T, VivoBook Pro N552VX-FY017T, VivoBook Pro N552VX-FY026T, VivoBook Pro N552VX-FY071T, VivoBook Pro N552VX-FY103T, ASUS [VivoBook Pro N552VX-FY104T](#) Laptop Battery, VivoBook Pro N552VX-FY105T, VivoBook Pro N552VX-FY137T, VivoBook Pro N552VX-FY200T, VivoBook Pro N552VX-FY291T, VivoBook Pro N552VX-FY382T, ASUS [VivoBook Pro N752VX](#) Laptop Battery, VivoBook Pro N752VX-GC049T, VivoBook Pro N752VX-GC087T, VivoBook Pro N752VX-GC089T, VivoBook Pro N752VX-GC094T, VivoBook Pro N752VX-GC116T, VivoBook Pro N752VX-GC131T, VivoBook Pro N752VX-GC138T, VivoBook Pro N752VX-GC139T, VivoBook Pro N752VX-GC189T, VivoBook Pro N752VXGC049T, VivoBook Pro N752VXGC087T, VivoBook Pro N752VXGC089T, VivoBook Pro N752VXGC094T, VivoBook Pro N752VXGC116T, VivoBook Pro N752VXGC131T, VivoBook Pro N752VXGC138T, VivoBook Pro N752VXGC139T, VivoBook Pro N752VXGC189T, ASUS [vivobook q200e](#) Laptop Battery, VivoBook Q301L, VivoBook Q301LA-BHI5T0, Vivobook R570ZD, Vivobook R570ZD-DM107, Vivobook S S431FA-EB131T, VivoBook S X510, VivoBook S X510U, VivoBook S X510UA, VivoBook S X510UF, VivoBook S X510UQ, VivoBook S13 S330 Series, VivoBook S13 S330U Series, VivoBook S13 S330UA, VivoBook S13 S330UA-EY034T, VivoBook S13 S330UN Series, VivoBook S14 S406UA, VivoBook S14 S406UA-BM012T, VivoBook S14 S406UA-BM013T, VivoBook S14 S406UA-BM174T, VivoBook S14 S406UA-BM248T, VivoBook S14 S406UA-BV021T, VivoBook S14 S406UA-BV023T, VivoBook S14 S406UA-BV026T, VivoBook S14 S406UA-

BV027T, VIVOBOK S14 S410UA, VivoBook S14 S410UA-EB046T, VivoBook S14 S410UA-EB832T, VivoBook S14 S410UF, VivoBook S14 S410UF-BV035T, VivoBook S14 S410UF-BV104T, VivoBook S14 S410UF-BV105T, VivoBook S14 S410UF-EB003T, Vivobook S14 S410UF-EB004T, VivoBook S14 S410UF-EB023T, VivoBook S14 S410UF-EB076T, VivoBook S14 S410UF-EB077T, VivoBook S14 S410UF-EB078T, VivoBook S14 S410UF-EB080T, VivoBook S14 S410UF-EB128T, VivoBook S14 S410UF-EB129T, VivoBook S14 S410UF-EB159T, VivoBook S14 S410UF-EB215T, VivoBook S14 S410UF-EB270T, VivoBook S14 S410UF-EB271T, VivoBook S14 S410UN, VIVOBOK S14 S410UN-AX8211T, VIVOBOK S14 S410UN-EB015T, VIVOBOK S14 S410UN-EB037T, VIVOBOK S14 S410UN-EB055T, VIVOBOK S14 S410UN-EB057T, VIVOBOK S14 S410UN-EB067T, VIVOBOK S14 S410UN-EB075T, VIVOBOK S14 S410UN-EB085T, VIVOBOK S14 S410UN-EB116T, VIVOBOK S14 S410UN-EB121T, VivoBook S14 S410UN-EB123T, VIVOBOK S14 S410UN-EB143T, VIVOBOK S14 S410UN-EB146TS, VIVOBOK S14 S410UN-EB154T, VIVOBOK S14 S410UN-EB158T, VIVOBOK S14 S410UN-EB177T, VIVOBOK S14 S410UN-EB192T, VIVOBOK S14 S410UN-EB194T, VIVOBOK S14 S410UN-EB210T, VivoBook S14 S410UN-EB229T, VIVOBOK S14 S410UN-EB240T, VIVOBOK S14 S410UN-EB292T, VIVOBOK S14 S410UN-EB952T, VIVOBOK S14 S410UN-NS74, VivoBook S14 S410UQ, VIVOBOK S14 S410UQ-BV081T, VIVOBOK S14 S410UQ-BV086T, VIVOBOK S14 S410UQ-BV106T, VIVOBOK S14 S410UQ-EB056T, VIVOBOK S14 S410UQ-EB059T, VIVOBOK S14 S410UQ-EB061T, VIVOBOK S14 S410UQ-EB067T, VIVOBOK S14 S410UQ-EB072T, ASUS [VIVOBOK S14 S410UQ-NH74](#) Laptop Battery, VivoBook S14 S430FA, VivoBook S14 S430FA-EB003T, VivoBook S14 S430FA-EB007T, VivoBook S14 S430FA-EB020T, Vivobook S14 S430FA-EB021T, VivoBook S14 S430FA-EB057T, VivoBook S14 S430FA-EB061R, VivoBook S14 S430FA-EB062R, VivoBook S14 S430FA-EB101T, VivoBook S14 S430FA-EB102T, VivoBook S14 S430FA-EB116T, ASUS [VivoBook S14 S430FA-EB140T](#) Laptop Battery, VivoBook S14 S430FA-EB144T, VivoBook S14 S430FA-EB145T, VivoBook S14 S430FA-EB149T, VivoBook S14 S430FA-EB150T, VivoBook S14 S430FA-EB186T, VivoBook S14 S430FA-EB187T, VivoBook S14 S430FA-EB218T, VivoBook S14 S430FA-EB238T, VivoBook S14 S430FA-EB239T, VivoBook S14 S430FA-EB242T, VivoBook S14 S430FA-EB243T, VivoBook S14 S430FA-EB244T, VivoBook S14 S430FA-EB245T, VivoBook S14 S430FA-EB246T, VivoBook S14 S430FA-EK365T, VivoBook S14 S430FA-EK445T, VivoBook S14 S430FN, VIVOBOK S14 S430FN-EB010T, VIVOBOK S14 S430FN-EB032T, VIVOBOK S14 S430FN-EB041T, VIVOBOK S14 S430FN-EB055T, VIVOBOK S14 S430FN-EB081T, VIVOBOK S14 S430FN-EB129T, VivoBook S14 S430FN-EB136T, VIVOBOK S14 S430FN-EK164T, VivoBook S14 S430UA, VivoBook S14 S430UA-BV315T, VivoBook S14 S430UA-EB009T, VivoBook S14 S430UA-EB011T, VivoBook S14 S430UA-EB015T, VivoBook S14 S430UA-EB033T, VivoBook S14 S430UA-EB034T, VivoBook S14 S430UA-EB059T, VivoBook S14 S430UA-EB062T, VivoBook S14 S430UA-EB078T, VivoBook S14 S430UA-EB081T, VivoBook S14 S430UA-EB085T, VivoBook S14 S430UA-EB086T, VivoBook S14 S430UA-EB159T, VivoBook S14 S430UA-EB160T, VivoBook S14 S430UA-EB169T, VivoBook S14 S430UA-EB185T, VivoBook S14 S430UA-EB219T, VivoBook S14 S430UA-EB221T, VivoBook S14 S430UA-EB222T, VivoBook S14 S430UA-EB223T, VivoBook S14 S430UA-EB224T, VivoBook S14 S430UA-EB877T, VivoBook S14 S430UA-EB953T, VivoBook S14 S430UA-EB954T, VivoBook S14 S430UF, VivoBook S14 S430UF-EB001T, VivoBook S14 S430UF-EB008T, VivoBook S14 S430UF-EB011T, VivoBook S14 S430UF-EB012T, VivoBook S14 S430UF-EB014T, ASUS [VivoBook S14 S430UF-EB015T](#) Laptop Battery, VivoBook S14 S430UF-EB016T, VivoBook S14 S430UF-EB017T, VivoBook S14 S430UF-EB042T, VivoBook S14 S430UF-EB043T, VivoBook S14 S430UF-EB843T, VivoBook S14 S430UF-EB846T, VivoBook S14 S430UN, VivoBook S14 S430UN-EB011T, VivoBook S14 S430UN-EB051T, VivoBook

S14 S431FA, VivoBook S14 S431FA-EB045, VivoBook S14 S431FL-AM028T, VIVOBOK S14 S431FL-AM034T, Vivobook S14 S431FL-AM035T, Vivobook S14 S431FL-AM037T, Vivobook S14 S431FL-AM038T, ASUS [VivoBook S14 S431FL-AM039T](#) Laptop Battery, ASUS [VivoBook S14 S431FL-AM040T](#) Laptop Battery, VivoBook S14 S431FL-AM041T, VivoBook S14 S431FL-AM042T, VivoBook S14 S431FL-AM043T, VivoBook S14 S431FL-EB061, VivoBook S14 S432FA, VivoBook S14 S432FA-EB001T, VivoBook S14 S432FA-EB003T, Vivobook S14 S432FA-EB008T, VivoBook S14 S432FA-EB025T, VivoBook S14 X430UF, VivoBook S14 X430UN, VivoBook S15 F510, VIVOBOK S15 S501UA-BR083T, VIVOBOK S15 S501UA-BR1391T, VIVOBOK S15 S501UA-EJ1201T, VIVOBOK S15 S501UA-EJ1288T, VIVOBOK S15 S501UA-EJ1347T, VIVOBOK S15 S501UA-EJ627T, VIVOBOK S15 S501UA-EJ644T, VIVOBOK S15 S501UA-EJ645T, VIVOBOK S15 S501UA-EJ763T, VIVOBOK S15 S501UF-EJ151T, ASUS [VIVOBOK S15 S501UF-EJ181T](#) Laptop Battery, VIVOBOK S15 S501UF-EJ282T, VIVOBOK S15 S501UF-EJ591T, VIVOBOK S15 S501UR-BR165T, VIVOBOK S15 S501UR-EJ294T, VivoBook S15 S510, VivoBook S15 S510UA, VivoBook S15 S510UA-BQ113T, VivoBook S15 S510UA-BQ149T, VivoBook S15 S510UA-BQ156T, VivoBook S15 S510UA-BQ265T, VivoBook S15 S510UA-BQ514T, VivoBook S15 S510UA-BQ521T, ASUS [VivoBook S15 S510UA-BQ643T](#) Laptop Battery, VivoBook S15 S510UA-BQB63T, VivoBook S15 S510UA-BQR24T, VivoBook S15 S510UA-BR152T, VivoBook S15 S510UA-BR153T, VivoBook S15 S510UA-BR154T, VivoBook S15 S510UA-BR155T, VivoBook S15 S510UA-BR409T, VivoBook S15 S510UA-BR641T, ASUS [VivoBook S15 S510UF](#) Laptop Battery, VIVOBOK S15 S510UF-BQ089T, VivoBook S15 S510UF-BQ193T, VivoBook S15 S510UF-BQA36T, VivoBook S15 S510UQ, VivoBook S15 S510UQ-BQ165T, VivoBook S15 S510UQ-BQ178T, VivoBook S15 S510UQ-BQ181T, VivoBook S15 S510UQ-BQ182T, VivoBook S15 S510UQ-BQ183T, VivoBook S15 S510UQ-BQ184T, Vivobook S15 S510UQ-BQ189T, VivoBook S15 S510UQ-BQ495T, VivoBook S15 S510UQ-BQ556T, VivoBook S15 S510UQ-BQ591T, VivoBook S15 S510UQ-BQ600T, VivoBook S15 S510UQ-BQ647T, VivoBook S15 S510UQ-BQ702T, VivoBook S15 S510UQ-BQ746T, VivoBook S15 S510UQ-BQA36T, VivoBook S15 S510UQ-BQR24T, VivoBook S15 S510UQ-BR180T, VivoBook S15 S510UR, VivoBook S15 S510UR-BQ101T, ASUS [VivoBook S15 S510UR-BQ193T](#) Laptop Battery, ASUS [VivoBook S15 S510UR-BQ194T](#) Laptop Battery, VIVOBOK S15 S510UR-BQ271T, VivoBook S15 S530, VivoBook S15 S530 Series, VivoBook S15 S530U Series, VivoBook S15 S530UA, VivoBook S15 S530UN, VivoBook S15 S530UN-BQ097T, VivoBook S15 S532FL, ASUS [VivoBook S15 S532FL-BN035T](#) Laptop Battery, VivoBook S15 S532FL-BN120T, VivoBook S15 S532FL-BQ003T, Vivobook S15 S532FL-BQ006T, VivoBook S15 S532FL-BQ028T, VivoBook S15 S532FL-BQ049T, VivoBook S15 S532FL-DB77, VivoBook S15 S532FL-EB71, VivoBook S15 X510UN, VivoBook S15 X510UN-EJ425T, VivoBook S15 X510UN-EJ526T, VivoBook S15 X510UN-EJ527T, ASUS [VivoBook S200](#) Laptop Battery, VivoBook S200E, VivoBook S200L3217E, VivoBook S200L987E, VivoBook S301LA, VivoBook S301LP, VivoBook S330 Series, VivoBook S330U Series, VivoBook S330UN Series, VivoBook S400E3317CA, VIVOBOK S410UA, VivoBook S410UQ-NH74, VivoBook S410UQNH74, VivoBook S430FA-EB128T, Vivobook S431FA-EB130T, VivoBook S451, ASUS [VivoBook S451LA](#) Laptop Battery, VivoBook S451LB, VivoBook S451LN, VivoBook S451LN-CA004H, VivoBook S451LN-CA009H, VivoBook S451LN-CA020H, VivoBook S451LN-CA021H, VivoBook S451LN-CA032H, VivoBook S451LN-CA036H, VivoBook S451LN-CA132H, VivoBook S451LN-CA159H, VivoBook S451LN-CA160H, VivoBook S451LNCA004H, VivoBook S451LNCA009H, VivoBook S451LNCA020H, VivoBook S451LNCA021H, VivoBook S451LNCA032H, VivoBook S451LNCA036H, VivoBook S451LNCA132H, VivoBook S451LNCA159H, ASUS [VivoBook S451LNCA160H](#) Laptop Battery, VivoBook S500CA, VIVOBOK S501UA-EJ646T, VivoBook S510NA, VivoBook S510NA-BQ149T, VivoBook S510UA-BR223T, VivoBook S530 Series, VivoBook

S530U Series, VivoBook S530UN Series, vivobook s550, VivoBook S550C, VivoBook S550CA, VivoBook S550CM, VivoBook S551, VIVOBOK S551LB-CJ026H, VIVOBOK S551LB-CJ045H, VIVOBOK S551LB-CJ081H, VIVOBOK S551LC, Vivobook S551ln, VivoBook S551LN-1A, VIVOBOK SERIES, VivoBook U38N Series, VivoBook U38N-C4004H, VivoBook U38NC4004H, VivoBook V451LA, VIVOBOK V451LA SERIES, VivoBook V451LA-DS51T, VivoBook V451LADS51T, VivoBook V551L, ASUS [VivoBook V551LA](#) Laptop Battery, VivoBook V551LA-DH51T, VivoBook V551LA-DS71T, VivoBook V551LB, VivoBook V551LB-DB71T, VivoBook V551LB-SH71T, VivoBook X200CA, VivoBook X201, VivoBook X201E, VivoBook X202E, VivoBook X202E-CT006H, VivoBook X202E-CT009H, VivoBook X202E-CT142H, VivoBook X202E-CT143H, VivoBook X202E-DH31T, VivoBook X202ECT006H, VivoBook X202ECT009H, VivoBook X202ECT142H, VivoBook X202ECT143H, VivoBook X202EDH31T, VivoBook X411UA, VivoBook X411UA-BV221T, VivoBook X411UA-EB1126R, VivoBook X411UA-EB250T, VivoBook X411UA-EB920T, VivoBook X411UA-GA070, VivoBook X411UF, VivoBook X411UF-BV070T, VivoBook X411UF-EB250T, VivoBook X411UN, VivoBook X411UQ, VivoBook X411UQ-BV082T, VivoBook X441, VivoBook X441B, VivoBook X441BA, VivoBook X441N, VivoBook X441NC, VivoBook X441U, VivoBook X441UA, VivoBook X441UR, VivoBook X441UV, Vivobook X442UA, Vivobook X442UF, Vivobook X442UN, Vivobook X442UQ, Vivobook X442UR, VivoBook X510, VivoBook X510U, VivoBook X510UA, VivoBook X510UF, VivoBook X510UQ, VivoBook X512UB-EJ079, VivoBook X540MA, VivoBook X540MA-DM278T, VivoBook X540MA-GQ323T, VivoBook X540NA, VivoBook X540NA-GQ129T, VivoBook X540NA-GQ150T, VivoBook X540UP, VivoBook X552u, VivoBook X555BA, VivoBook X555BA-XO006D, VivoBook X555BP, VivoBook X555BP-DM257T, VivoBook X555BP-XO007D, VivoBook X555DA, VivoBook X555DA-WS11, VivoBook X555LA, VivoBook X555LA-XX046H, VivoBook X555LA-XX092H, VivoBook X555LA-XX152H, VivoBook X555LA-XX2276T, VivoBook X555LA-XX521D, VivoBook X555LA-XX546H, VivoBook X555LB-DM137H, VivoBook X555LB-DM252H, VivoBook X555LB-XO060D, VivoBook X555LB-XO122H, VivoBook X555LB-XO238H, VivoBook X555LB-XO248H, VivoBook X555LB-XO275H, VivoBook X555LB-XO316H, VivoBook X555LD, VivoBook X555LD-XO067H, VivoBook X555LD-XO080H, VivoBook X555LD-XX087H, ASUS [VivoBook X555LD-XX283H](#) Laptop Battery, VivoBook X555LD-XX326H, VivoBook X555LF, VivoBook X555LF-XO063H, VivoBook X555LJ, ASUS [VivoBook X555LJ-XO133H](#) Laptop Battery, VivoBook X555LJ-XO198H, VivoBook X555LJ-XX060H, VivoBook X555LJ-XX110H, VivoBook X555LJ-XX112H, VivoBook X555LJ-XX118H, VivoBook X555LJ-XX131D, VivoBook X555LJ-XX145H, VivoBook X555LJ-XX196H, VivoBook X555LJ-XX228H, VivoBook X555LJ-XX230H, VivoBook X555LJ-XX353H, VivoBook X555LJ-XX389H, VivoBook X555LJ-XX392H, VivoBook X555LJ-XX394H, VivoBook X555LJ-XX397H, VivoBook X555LJ-XX995T, VivoBook X555LN-DM197H, VivoBook X555LN-DM497H, VivoBook X555LN-X0112H, VivoBook X555LN-X0275H, VivoBook X555LN-XO031D, ASUS [VivoBook X555LN-XO113H](#) Laptop Battery, VivoBook X555LN-XO275H, VivoBook X555LN-XO470H, VivoBook X555LN-XO500D, VivoBook X555LP, VivoBook X555LP-XO060H, VivoBook X555QA, VivoBook X555SJ, VivoBook X555UA, VivoBook X555UA-XX030T, VivoBook X555UA-XX124T, VivoBook X555UJ-XO112T, ASUS [VivoBook X555UJ-XX073T](#) Laptop Battery, VivoBook X555YA, VivoBook X555YA-XO010T, VivoBook X555YI, VivoBook X555YI-XO028D, VivoBook X555YI-XX054T, VivoBook X556UA, VivoBook X556UA-DM898T, VivoBook X556UA-XO974T, VivoBook X556UB, VivoBook X556UB-XX013T, ASUS [VivoBook X556UB-XX030T](#) Laptop Battery, ASUS [VivoBook X556UB-XX039T](#) Laptop Battery, VivoBook X556UF, VivoBook X556UQ, VivoBook X556UQ-DM1039T, VivoBook X556UQ-DM1256T, VivoBook X556UQ-DM1258T, VivoBook X556UQ-DM1259P, VivoBook X556UQ-DM1269T, VivoBook X556UQ-DM523, VivoBook X556UQ-DM762T,

VivoBook X556UQ-X01258T, VivoBook X556UQ-XO075T, VivoBook X556UQ-XO076T, VivoBook X556UQ-XO1268T, VivoBook X556UQ-XO760D, VivoBook X556UQ-XO916T, VivoBook X556UR, VivoBook X556UR-0031C6200U, VivoBook X556UR-DM396T, VivoBook X556UR-DM402T, VivoBook X556UV, VivoBook X556UV-XO006T, VivoBook X556UV-XO007T, VivoBook X560UD, VivoBook X751BP, VivoBook X751BP-TY029T, VivoBook X751BP-TY048T, VivoBook X751BPTY048T, VivoBook X751LA-DB31-CA, VivoBook X751LA-XS51, VivoBook X751LAV-TY118H, VivoBook X751LAV-TY175H, VivoBook X751LAV-TY327H, VivoBook X751LAV-TY361H, VivoBook X751LAV-TY513T, VivoBook X751LD, VivoBook X751LD-TY069D, VivoBook X751LD-TY123H, VivoBook X751LDV-T4132H, VivoBook X751LDV-T6154H, ASUS [VivoBook X751LDV-T6255H](#) Laptop Battery, ASUS [VivoBook X751LDV-TY195H](#) Laptop Battery, VivoBook X751LDV-TY261H, VivoBook X751LDV-TY266H, VivoBook X751LDV-TY418H, VivoBook X751LJ-T4042H, VivoBook X751LJ-TY005H, VivoBook X751LJ-TY036H, VivoBook X751LJ-TY053H, VivoBook X751LJ-TY092H, VivoBook X751LJ-TY194D, VivoBook X751LK, VivoBook X751LK-T4009H, VivoBook X751LK-T4152H, VivoBook X751LK-TY011H, VivoBook X751LN, VivoBook X751LN-TY008H, ASUS [VivoBook X751LN-TY033H](#) Laptop Battery, VivoBook X751LN-TY040H, VivoBook X751LN-TY100H, VivoBook X751LN-TY124H, VivoBook X751LN-TY4046H, VivoBook X751LX-T4012D, VivoBook X751LX-T4048H, VivoBook X751LX-TY014D, VivoBook X751MA-TY037H, VivoBook X751MA-TY047H, VivoBook X751MA-TY058H, VivoBook X751MA-TY118H, VivoBook X751MA-TY148H, VivoBook X751MA-TY158T, VivoBook X751MD, VivoBook X751MD-TY020H, VivoBook X751MD-TY023H, VivoBook X751MD-TY040H, VivoBook X751MJ, VivoBook X751MJ-TY005H, VivoBook X751NA-TY001, VivoBook X751NA-TY003T, VivoBook X751NA-TY006T, VivoBook X751NA-TY014T, VivoBook X751NA-TY044T, VivoBook X751NA-TY072, VivoBook X751NV-TY002T, VivoBook X751NV-TY012T, VivoBook X751SJ, VivoBook X751SJ-TY010T, VivoBook X751SV, VivoBook15 X510QR, VM400C, VM410L, VM510, ASUS [VM510L](#) Laptop Battery, VM590, VM590L, VM590Z, VM591UA, VM591UB, VM591UF, VM591UJ, VM591UQ, VM591UR, VM591UV, VX1, VX1-Lamborghini, VX2-Lamborghini, VX2S, VX2S-Lamborghini, VX2Sn-Lamborghini, W1, W1000, W1000G, W1000Ga, W1000Gc, ASUS [W1000N](#) Laptop Battery, W1000Na, W1000V, W1G, W1Ga, W1Gc, W1N, W1Na, W1V, W2000, W2000J, W2000V, W2J, ASUS [W2Jb](#) Laptop Battery, W2Jc, W2P, W2Pb, W2Pc, W2V, W2VB, W2Vc, W2W, W3000, W3000A, W3000V, W3A, W3AW3J, W3J, W3N, W3V, W3Z, W409L, W5, W5000A, W518L, W519, W519L, W5600A, W5A, W5A Series, W5F, W5F Series, W5Fe, W5Fm, W6, W6A, W6F, W6Fp, W6K, W7, W7 Series, W7F, W7J, W7S, W7Sg, W90, W90V, W90VN, ASUS [W90VP](#) Laptop Battery, W90vp-a1, W90vp-a2, W90vp-x1, W90vp-x2, X Pro U5800GE, X102B, X102BA-BH41T, X102BA-DF1200, X102BA-HA41002F, X20, X20 Series, X200MA, X200MA-KX085D, X201E, X201E-1A, X201E-1B, X201E-6D, X201E-6E, X201E1A, X201E1B, X201E3217E, X201E6D, X201E6E, X201E987E, X202E-3E, X202E-3J, X202E-3K, X202E3E, X202E3J, X202E3K, X205, X205C, X205TA-1A, X205TA-1B, X205TA-1G, X205TA-1R, X206HA EEEBOOK, X20E, X20S, X24E, X301, X301 Series, X301A, X301A Series, X301A-1A, X301A-1B, X301A1 SERIES, X301KB815A, X301KI235A, ASUS [X301U](#) Laptop Battery, X301U Series, X302L, X302LA-FN033H, X302LA-FN049H, X302LA-FN052H, X302LA-FN097H, X302LA-R4101, X302LAFN033H, ASUS [X302LAFN049H](#) Laptop Battery, X302LAFN052H, X302LAFN097H, X302LAR4101, X302LJ, X302LJ-FN016H, X302LJ-FN017H, X302LJ-FN027H, X302LJ-FN037H, X302LJ-FN050H, X302LJ-R4036H, ASUS [X302LJ-R4073](#) Laptop Battery, X302LJFN016H, X302LJFN017H, X302LJFN027H, X302LJFN037H, X302LJFN050H, X302LJR4036H, X302LJR4073, X31E-RY029V, X35, X35 Series, X35F, X35F Series, X35J, X35J Series, X35JG, X35JG Series, X35KB80SD, X35KB815SG, X35KB95SD, X35S, X35S Series, X35SD, X35SD Series, X400MA, X401, X401 Series, X401A,

X401A Series, X401A-1A, X401A-1B, X401A-1C, X401A-1D, X401A-RBL4, X401A-RGN4, X401A-RPK4, X401A-WX032, ASUS [X401A-WX051D](#) Laptop Battery, X401A-WX052D, X401A-WX053D, X401A-WX054, X401A-WX055D, X401A-WX074S, X401A-WX074V, X401A-WX089V, X401A-WX092R, X401A-WX115V, X401A-WX128V, X401A-WX134R, X401A1 SERIES, X401E1000A, X401EB82A, X401EC60U, X401EE45U, X401EI235A, X401EI237A, X401U, X401U Series, X401U-1A, X401U-1B, X401U-BE20602Z, X401U-EBL4, X401U-RBLA, X401U-WX008V, X401U-WX009, ASUS [X401U-WX011D](#) Laptop Battery, X401U-WX017S, X401U-WX025V, X401U-WX030D, X401U-WX031V, X401U-WX032V, X401U-WX050R, X401U-WX060H, X403FA, X403FA-2C, X403FA-2S, X403FA-EB011T, X403FA-EB021T, X403FA-EB036T, X403FA-EB101T, X403FA-EB121T, X403FA-EB123T, X403FA-EB126T, X403FA-EB139T, X403FA-EB198, X403FA-EB210R, X403FA-EB210T, X403FA-H522D, X405UA, X405UQ, X405UR, X407MA, X407MA-1B, X407MA-1C, X407MA-BV02T, X407MA-BV03T, ASUS [X407MA1B](#) Laptop Battery, X407MA1C, X407MABV02T, X407MABV03T, X407UA, X407UA-1B, X407UA-1C, X407UA-BV013T, X407UA-BV108R, X407UA-BV111T, X407UA1B, X407UA1C, X407UABV013T, X407UABV108R, X407UABV111T, X407UB, X407UB-1B, X407UB-1C, X407UB-BV062T, X407UB1B, ASUS [X407UB1C](#) Laptop Battery, X407UBBV062T, X407UF-1B, X407UF-1C, X407UF1B, X407UF1C, X410, X411QA, X411QA-3B, X411QA-BV042T, X411QA-EB060T, X411QA-EK026T, X411QA-EK033T, X411QR, X411UA, X411UA-1A, X411UA-1B, X411UA-3B, X411UA-3C, X411UA-3F, X411UA-BV1176T, X411UA-BV1177T, X411UA-BV149T, X411UA-BV185T, X411UA-BV207T, X411UA-BV221T, X411UA-BV258T, X411UA-BV331, X411UA-BV332T, X411UA-BV360T, X411UA-BV495T, X411UA-BV527, X411UA-BV528T, X411UA-BV572, X411UA-BV581T, X411UA-BV582, X411UA-BV584T, X411UA-BV586T, X411UA-BV643T, X411UA-BV644, X411UA-BV926T, X411UA-BV933, X411UA-BV934, X411UA-EB1126R, X411UA-EB243, X411UA-EB419T, X411UA-EB680T, X411UA-EB694R, X411UA-EB808T, X411UA-EB920T, X411UA-GA070, X411UF, X411UF-1A, X411UF-1B, X411UF-3B, X411UF-3C, X411UF-BV042T, X411UF-BV070T, X411UF-BV149T, X411UF-BV164T, X411UF-BV253, X411UF-EB062, X411UF-EB092T, X411UF-EB093T, X411UF-EB107T, X411UF-EB108T, X411UF-EB155T, X411UF-EB250T, X411UF-EB285T, ASUS [X411UN](#) Laptop Battery, X411UN-1A, X411UN-1B, X411UN-3B, X411UN-3C, X411UN-3F, X411UN-BV118T, X411UN-EB111T, X411UN-EB118T, X411UN-EB160, X411UN-EB161, X411UN-EB162T, X411UN-EB184T, X411UN-EB185T, X411UN-EB195T, X411UN-EB196T, X411UN-EB217T, X411UN-EB218, X411UQ, X411UQ-1A, X411UQ-1B, X411UQ-3B, X411UQ-3C, X411UQ-3F, X411UQ-BV082T, X411UQ-EB089, X411UQ-EB091, X411UQ-EB093, X412FA, X412FA-1G, X412FA-8B, X412FA-8S, X412FJ, X412FJ-EK091T, X412UA, X412UA-1G, ASUS [X412UA-8S](#) Laptop Battery, X412UB, X412UB-1G, X412UB-8B, X412UF, X420fa-58bhdsp1, X420FA-EK013T, X420fa-ek037t, X420FA-EK040T, X420FA-EK051T, X420FA-EK083T, X420UA, X420UA-8S, ASUS [X430FN](#) Laptop Battery, X430UF-1A, X430UF-1E, ASUS [X430UN-1A](#) Laptop Battery, X430UN-1E, X431FL, X432FA, X432FA-2S, X43B, X43B, X43BR, X43BY, X43BY, X43E, X43E, X43EC60BR-SL, X43EC60BRSL, X43EC60U-SL, X43EC60USL, X43EE35BYSL, X43EE45BR-SL, X43EE45BRSL, X43J, X43J, X43JE, X43JE, X43JF, X43JF, X43JR, X43JR, X43JX, X43JX, X43S, X43S, X43SA, X43SD, ASUS [X43SJ](#) Laptop Battery, X43SJ, X43SR, X43SR, X43SV, X43SV, X43T, X43T, ASUS [X43TA](#) Laptop Battery, X43U, X43U, X43V, X44, X441B, X441BA, X441N, X441NC, X441NC4200, X441SA, X441SA-1A, X441SA-1C, X441SA-3F, X441SA-3G, X441SA-3H, X441SA-BX002D, X441SA-WX001D, X441SA-WX022T, X441SA-WX034D, X441SA-WX035T, X441SA-WX048D, X441SA1A, X441SA1C, X441SA3F, X441SA3G, X441SA3H, ASUS [X441SABX002D](#) Laptop Battery, X441SAWX001D, X441SAWX022T, X441SAWX034D, X441SAWX035T, X441SAWX048D, X441SC, X441SC-1A, X441SC-1C, X441SC-3G, X441SC-

WX005T, ASUS [X441SC-WX018D](#) Laptop Battery, X441SC1A, X441SC1C, X441SC3G, X441SCC, X441SCWX005T, X441SCWX018D, X441UA, X441UA-1A, X441UA-1C, X441UA-3F, X441UA-3G, X441UA-3H, X441UA-WX016D, X441UA-WX030D, X441UA-WX031D, X441UA-WX055D, X441UA1A, X441UA1C, X441UA3F, X441UA3G, X441UA3H, X441UAWX016D, X441UAWX030D, X441UAWX031D, ASUS [X441UAWX055D](#) Laptop Battery, X441uv, X441UV Serie, X441UV-1A, X441UV-1C, X441UV-3F, X441UV-3G, X441UV-WX009D, X441UV-WX017D, X441UV-WX020D, X441UV-WX021D, X441UV-WX023D, X441UV1A, X441UV1C, X441UV3F, X441UV3G, X441UVWX009D, X441UVWX017D, X441UVWX020D, X441UVWX021D, X441UVWX023D, X442UA-1B, X442UA-1C, X442UA-3F, X442UA-3G, X442UA-FA015T, X442UA-FA016T, X442UA-FA022T, ASUS [X442UA-FA054T](#) Laptop Battery, X442UA-FA061R, X442UA-FA069R, X442UA-FA070T, X442UA-FA085, X442UA-FA100R, X442UA-FA103T, X442UA-FA111R, X442UA-FA142R, X442UA-FA165T, ASUS [X442UA-FA185R](#) Laptop Battery, X442UA-FA192, X442UA-FA193, X442UA-FA265T, X442UA-FA317R, X442UA-GA022, X442UA-GA061R, X442UA-GA103, X442UA-GA139T, X442UA1B, X442UA1C, X442UA3F, X442UA3G, X442UAFA015T, X442UAFA016T, X442UAFA022T, X442UAFA054T, X442UAFA061R, X442UAFA069R, X442UAFA070T, X442UAFA085, X442UAFA100R, X442UAFA103T, X442UAFA111R, X442UAFA142R, X442UAFA165T, X442UAFA185R, X442UAFA192, X442UAFA193, X442UAFA265T, X442UAFA317R, X442UAGA022, X442UAGA061R, X442UAGA103, X442UAGA139T, X442UF-1B, ASUS [X442UF-1C](#) Laptop Battery, X442UF-3F, X442UF-3G, X442UF-FA, X442UF-FA001T, X442UF-FA002T, X442UF-FA003T, X442UF-FA004T, X442UF-FA005T, X442UF-FA006T, ASUS [X442UF-FA057T](#) Laptop Battery, X442UF1B, X442UF1C, X442UF3F, X442UF3G, X442UFFA, X442UFFA001T, X442UFFA002T, X442UFFA003T, X442UFFA004T, X442UFFA005T, X442UFFA006T, X442UFFA057T, X442UN-1B, X442UN-AH8203T, X442UN-FA028T, X442UN-FA031T, X442UN1B, X442UNAH8203T, X442UNFA028T, X442UNFA031T, X442UQ-1A, X442UQ-1B, X442UQ-1C, ASUS [X442UQ-FA005T](#) Laptop Battery, X442UQ-FA006T, X442UQ-FA023T, X442UQ-FA050T, X442UQ-FA053T, X442UQ-FA058T, X442UQ-GA034T, X442UQ1A, X442UQ1B, X442UQ1C, X442UQFA005T, X442UQFA006T, X442UQFA023T, X442UQFA050T, X442UQFA053T, X442UQFA058T, X442UQGA034T, X442UR-1B, X442UR-1C, X442UR-3G, X442UR-FA023T, ASUS [X442UR-FA049T](#) Laptop Battery, X442UR-FA050T, X442UR-FA051T, X442UR-FA058T, X442UR-GA020, X442UR-GA022, X442UR-GA028T, X442UR-GA029T, X442UR-GA061T, X442UR-GA071T, X442UR1B, X442UR1C, X442UR3G, X442URFA023T, X442URFA049T, X442URFA050T, X442URFA051T, X442URFA058T, X442URGA020, X442URGA022, X442URGA028T, X442URGA029T, X442URGA061T, X442URGA071T, X44C, X44H, X44HBBR4, X44HO, X44HR, X44HY, X44L, X44LY, ASUS [X450](#) Laptop Battery, X450 Series, X450C, X450CA, X450CA-1A, X450CA-1B, X450CA-1C, X450CA-3D, X450CA-3E, X450CA-3F, X450CA-3G, X450CA-9A, X450CA-CA122H, X450CA-WX003D, X450CA-WX008H, X450CA-WX092H, X450CA-WX109D, ASUS [X450CA-WX110D](#) Laptop Battery, X450CA-WX137D, X450CC, X450CC-1A, X450CC-1B, X450CC-1C, X450CC-3D, X450CC-3E, X450CC-3F, X450CC-3G, X450CC-9A, X450CC-CA179H, X450CC-WX007D, X450CC-WX009H, X450CC-WX016H, X450CC-WX037D, X450CC-WX049H, X450CC-WX064H, X450CC-WX142D, X450CC-WX143D, X450CP, ASUS [X450CP-7K](#) Laptop Battery, X450CP-7L, X450E, X450E3337CC, X450EA-7K, X450EA-7L, X450EP, X450EP-7K, X450J, X450J Series, X450JB-0023D4200H, X450JF, X450JF Series, X450JF-WX023H, X450JN, X450JN-WX004D, X450JN-WX005H, X450JN-WX016H, X450LB-007H, X450LB-WX007H, X450LB-WX012H, X450LB-WX019H, ASUS [X450LB-WX023H](#) Laptop Battery, X450LC-1AWX, X450LC-BRA-WX063H, X450LC-WX012H, X450LC-WX014D, X450LC-WX035D, X450LC-WX035H, X450LC-

WX037H, X450LC-WX070D, X450LC-WX117D, X450LD-CA224H, X450LD-WX007H, X450LD-WX025D, X450LD-WX029D, X450LD-WX032D, X450LD-WX083D, X450LD-WX084H, X450LD-WX085H, ASUS [X450LDV](#) Laptop Battery, X450LN-WX003H, X450LN-WX025D, X450LN-WX026D, X450LN-WX031H, X450LNV, X450V, X451 Series, X451-VX036H, X451C, X451C Series, X451CA, X451CA Series, X451CA-0033G2117U, X451CA-1007U, X451CA-1AV, X451CA-BRAL-VX051H, X451CA-MN3-WHI, X451CA-MN4-WHI, X451CA-MN5-WHI, X451CA-VX007H, X451CA-VX008H, X451CA-VX012H, X451CA-VX013H, X451CA-VX023D, X451CA-VX025D, X451CA-VX026D, X451CA-VX026H, X451CA-VX028H, X451CA-VX032D, X451CA-VX034H, X451CA-VX036D, X451CA-VX036H, X451CA-VX037D, X451CA-VX038D, X451CA-VX039D, X451CA-VX039H, X451CA-VX050H, X451CA-VX051H, X451CA-VX052H, X451CA-VX065D, X451CA-VX066D, X451CA-VX067D, X451CA-VX069D, X451CA-VX078D, X451CA-VX091D, X451CA-VX092H, X451CA-VX100H, X451CA-VX103H, X451CA-VX104H, X451CA-VX106H, X451CA-VX114D, X451CA-VX125H, X451CA-VX126D, X451CA-VX127D, X451CA-VX140D, X451CA-VX148D, X451CA-VX149D, X451CA-VX155H, X451CA-VX172H, X451CA-VX182D, X451CA-WX066D, X451CA-WX067D, X451CA-WX102D, X451CA-WX125D, X451CA-WX148D, X451CA-WX149D, X451MA-MM2-H-WHI, X451MA-VX006H, X451MA-VX008H, X451MA-VX014D, X451MA-VX027H, X451MA-VX029H, X451MA-VX030H, X451MA-VX048D, X451MA-VX051D, X451MA-VX053D, X451MA-VX054D, X451MA-VX085H, X451MA-VX086B, X451MA-VX103H, X451MA-VX117H, X451MA-VX118H, X451MAV-BING-VX282B, X451MAV-VX108D, X451MAV-VX109H, X451MAV-VX148B, X451MAV-VX282B, X452, X452V, X452VP, X453, X454 series, X455, X455DG, X455DG-1A, X455DG1A, X455LA, X455LA-1A, X455LA-1B, X455LA-3C, ASUS [X455LA-3D](#) Laptop Battery, X455LA-3E, X455LA-3F, X455LA-3G, X455LA-3H, ASUS [X455LA-4030U](#) Laptop Battery, X455LA-7K, X455LA-7L, X455LA-7M, X455LA-7N, X455LA-WX002D, X455LA-WX005H, X455LA-WX040H, X455LA-WX053D, X455LA-WX053H, X455LA-WX054H, X455LA-WX058D, X455LA-WX058H, X455LA-WX063D, X455LA-WX078H, X455LA-WX080D, X455LA-WX081D, X455LA-WX082D, X455LA-WX086, X455LA-WX213H, X455LA1A, X455LA1B, X455LA3C, X455LA3D, X455LA3E, X455LA3F, X455LA3G, X455LA3H, X455LA4030U, X455LA7K, X455LA7L, X455LA7M, X455LA7N, X455LAWX002D, ASUS [X455LAWX005H](#) Laptop Battery, X455LAWX040H, X455LAWX053D, X455LAWX053H, X455LAWX054H, X455LAWX058D, X455LAWX058H, X455LAWX063D, X455LAWX078H, X455LAWX080D, X455LAWX081D, X455LAWX082D, X455LAWX086, X455LAWX213H, X455LB, X455LD, X455LD-1A, X455LD-1B, X455LD-3D, X455LD-3E, X455LD-3F, X455LD-3G, X455LD-3H, X455LD-7K, X455LD-7L, X455LD-WX006H, X455LD-WX012H, X455LD-WX013H, X455LD-WX022H, X455LD1A, X455LD1B, X455LD3D, X455LD3E, X455LD3F, ASUS [X455LD3G](#) Laptop Battery, X455LD3H, X455LD7K, X455LD7L, X455LDWX006H, X455LDWX012H, X455LDWX013H, X455LDWX022H, X455LF, X455LF-1A, X455LF-1B, ASUS [X455LF-3C](#) Laptop Battery, X455LF-3D, X455LF-3E, X455LF-3F, X455LF-3G, X455LF-3H, X455LF1A, X455LF1B, X455LF3C, X455LF3D, X455LF3E, X455LF3F, X455LF3G, X455LF3H, X455LJ, X455LJ-1A, X455LJ-1B, X455LJ-3C, X455LJ-3D, ASUS [X455LJ-3E](#) Laptop Battery, X455LJ-3F, X455LJ-3G, X455LJ-3H, X455LJ-7K, X455LJ-7L, X455LJ-7M, X455LJ-7N, X455LJ1A, X455LJ1B, X455LJ3C, X455LJ3D, X455LJ3E, X455LJ3F, X455LJ3G, X455LJ3H, X455LJ7K, X455LJ7L, X455LJ7M, X455LJ7N, ASUS [X455LN](#) Laptop Battery, X456, X456UA, X456UA-1A, X456UA-1B, X456UA-1C, X456UA-3G, X456UA1A, X456UA1B, X456UA1C, X456UA3G, X456UB, X456UB-1A, X456UB-1B, X456UB-1C, ASUS [X456UB1A](#) Laptop Battery, X456UB1B, X456UB1C, X456UF, X456UF-1A, X456UF-1B, X456UF-1C, X456UF-3F, X456UF1A, X456UF1B, X456UF1C, X456UF3F, X456UJ, X456UJ-1A, X456UJ-1B, X456UJ-1C, X456UJ-3F, X456UJ-3G, X456UJ1A, X456UJ1B, ASUS

[X456UJ1C](#) Laptop Battery, X456UJ3F, X456UJ3G, X456UQ, X456UQ-1A, X456UQ-1B, X456UQ-1C, X456UQ-3F, X456UQ-3G, X456UQ1A, X456UQ1B, X456UQ1C, X456UQ3F, X456UQ3G, X456UR, X456UR-1A, X456UR-1B, X456UR-1C, X456UR-3F, X456UR-3G, X456UR1A, X456UR1B, X456UR1C, X456UR3F, X456UR3G, X456UV, X456UV-1A, X456UV-1B, X456UV-1C, X456UV-3F, X456UV-3G, X456UV1A, ASUS [X456UV1B](#) Laptop Battery, X456UV1C, X456UV3F, X456UV3G, X5 Series, X50, X50 series, X501, X501 Series, X501A, X501A Series, X501A-1A, X501A-1B, X501A-1D, X501A-XX006V, X501A-XX010V, X501A-XX016V, X501A-XX020V, X501A-XX024V, X501A-XX036V, X501A-XX047S, X501A-XX047V, ASUS [X501A-XX065V](#) Laptop Battery, ASUS [X501A-XX090D](#) Laptop Battery, X501A-XX092D, X501A-XX104V, X501A-XX117S, X501E SX013V, X501U, X501U Series, X501U-1A, X501U-1B, X501U-XX022V, X501U-XX023D, X501U-XX027, X501U-XX030V, X501U-XX034V, X501U-XX039V, X501U-XX049V, X501X1000A, X501XB815A, X501XB82A, X501XC60U, X501XE218U, X501XE45U, X501XI235A, X504LA, X505BA, X505BA-1A, X505BA-1B, X505BA-1C, X505BA-3F, X505BA-3G, X505BP, X505BP-1A, X505BP-1B, X505BP-1C, X505BP-3F, X505BP-3G, X505ZA, X507LA-1B, X507LA-1C, X507LA1B, X507LA1C, X507MA, X507MA-1B, X507MA-1C, X507MA-AS5001T, ASUS [X507MA-BR059T](#) Laptop Battery, X507MA-BR072T, X507MA-EJ012T, X507MA1B, X507MA1C, X507MAAS5001T, X507MABR059T, X507MABR072T, X507MAEJ012T, X507UA, X507UA-1B, X507UA-1C, X507UA-BQ046T, X507UA-BQ072T, X507UA-BQ168T, X507UA-BQ168T15, X507UA-BQ169T, ASUS [X507UA-BR046T](#) Laptop Battery, X507UA-BR220T, X507UA1B, X507UA1C, X507UABQ046T, X507UABQ072T, X507UABQ168T, X507UABQ168T15, X507UABQ169T, X507UABR046T, X507UABR220T, X507UB, X507UB-1B, X507UB-1C, X507UB-EJ043, X507UB-EJ045, X507UB-EJ048, X507UB1B, X507UB1C, X507UBEJ043, X507UBEJ045, X507UBEJ048, X507UF, X507UF-1B, X507UF-1C, X507UF1B, X507UF1C, X50M, X50R, X50SL, X50V, X50VL, X510, X510QA, X510QA-BR017T, X510QA-BR095T, X510QA-EJ041T, X510QA-EJ042T, X510QA-EJ141T, X510QR, X510U, X510UA, X510UA-1A, X510UA-1B, ASUS [X510UA-3B](#) Laptop Battery, X510UA-3C, X510UA-3F, X510UA-3G, X510UA-AH7101E, X510UA-BB51-CB, X510UA-BQ094, X510UA-BQ095, X510UA-BQ1001T, X510UA-BQ175, X510UA-BQ319, X510UA-BQ320, X510UA-BQ321, ASUS [X510UA-BQ321T](#) Laptop Battery, X510UA-BQ323, X510UA-BQ327, X510UA-BQ437, X510UA-BQ439T, X510UA-BQ444, X510UA-BQ488T, X510UA-BQ490T, X510UA-BQ493T, X510UA-BQ573T, X510UA-BQ715T, X510UA-BQ912, X510UA-BQ913, X510UA-BQ914, X510UA-BQ963, X510UA-BR081, X510UA-BR1112T, X510UA-BR1160T, ASUS [X510UA-BR1528](#) Laptop Battery, X510UA-BR483T, X510UA-BR484T, X510UA-BR485T, X510UA-BR517T, X510UA-BR519, X510UA-BR539T, X510UA-BR540T, X510UA-BR554T, X510UA-BR578T, X510UA-BR650T, X510UA-BR666T, X510UA-BR667T, X510UA-BR709T, X510UA-BR929T, X510UA-EJ1070T, X510UA-EJ1223T, X510UA-EJ1227T, X510UA-EJ1235T, X510UA-EJ1405T, X510UA-EJ592T, ASUS [X510UA-EJ624](#) Laptop Battery, X510UA-EJ625T, X510UA-EJ695, X510UA-EJ745T, ASUS [X510UA-EJ747T](#) Laptop Battery, X510UA-EJ748, X510UA-EJ748T, X510UA-EJ750T, X510UA-EJ770T, X510UA-EJ796T, X510UA-EJ908, X510UA-EJ927T, X510UF, X510UF-1A, X510UF-1B, X510UF-3B, X510UF-3C, X510UF-3F, X510UF-3G, X510UN-1A, X510UN-1B, X510UQ, X510UQ-1A, X510UQ-1B, X510UQ-3B, X510UQ-3C, X510UQ-3F, X510UQ-3G, X510UR-1A, X510UR-1B, X510UR-3B, X510UR-3C, X510UR-3F, X510UR-3G, X510UR-BR107T, X512, X512C, X512DA, X512da-ej039t, X512da-ej040t, X512da-ej139t, X512da-ej140t, X512da-ej141t, X512da-ej142t, X512da-ej313t, X512da-ej314t, X512DK, X512FA, X512FA-1G, X512FA-8B, X512FA-8S, X512FB, X512FB-1G, X512FB-8S, X512FF, X512FJ, X512FL, X512UA, X512UA-1G, X512UA-8B, X512UA-8S, X512UB, X512UB-1G, X512UB-8S, X512UB-BR059T, X512UB-EJ020, X512UB-EJ085, X512UF, X512UF-1G, X512UF-8B, X512UF-8S, X51C, X51H, X51L, ASUS [X51Q](#) Laptop Battery,

X51R, X51RL, X52, X52 Series, X522V, X52DE, ASUS [X52DR](#) Laptop Battery, X52F, X52JB, X52JC, X52JE, X52JG, X52JK, X52JR, X52N, X52S, X532FA, X532FL, X53B, X53BE, X53BR, X53BY, X53E-RH31, X53E-RH51, X53E-RH71, X53E-RH92, X53E-XR1, ASUS [X53E-XR2](#) Laptop Battery, X53EE35BY-SL, X53EE35BYSL, X53ERH31, X53ERH51, X53ERH52, X53ERH71, X53ERH92, X53EXR1, X53EXR2, X53EXR3, X53K F3KA, X53KA, X53KE, X53L, X53S, X53SA, X53SC, X53SD, X53SE, X53SJ, X53SK, X53SM, X53SV, X53SV, X53SV-MH71, X53SV-RH51, X53SV-RH52, X53SV-RH71, X53SV-SX097V, X53SV-SX097V, X53SV-SX111V, X53SV-SX117V, X53SV-SX132V, X53SV-SX173V, X53SV-SX179V, X53SV-SX200V, X53SV-SX213V, ASUS [X53SV-SX214V](#) Laptop Battery, X53SV-SX214V, X53SV-SX218V, X53SV-SX231V, X53SV-SX246, X53SV-SX246, X53SV-SX296V, X53SV-SX311V, ASUS [X53SV-SX311V](#) Laptop Battery, X53SV-TH71, X53SV-TH71, X53SVMH71, X53SVRH51, X53SVRH52, X53SVRH71, X53SVSX097V, X53SVSX111V, X53SVSX117V, X53SVSX132V, X53SVSX173V, X53SVSX179V, X53SVSX200V, X53SVSX213V, ASUS [X53SVSX214V](#) Laptop Battery, X53SVSX218V, X53SVSX231V, X53SVSX246, ASUS [X53SVSX296V](#) Laptop Battery, X53SVTH71, X53T, X53TA, X53TA Series, X53TA Series, X53TK, X53U, X53U-RH11, X53U-RH21, X53U-XR1, X53U-XR2, X53URH11, X53URH21, X53UXR1, X53UXR2, X53XC60U-SL, X53XC60USL, X53XE35BY-SL, X53XE35BYSL, X53XE45BR-SL, X53XE45BRSL, X53XE45BY-SL, X53XE45BYSL, X53XI233SJ-SL, X53XI233SJ-SL, X53XI233SJSL, X53Z, X54, X540L, X540LA, X540LA-1A, X540LA-1C, X540LA-3F, X540LA-3G, X540LA-3H, X540LA-DM022, X540LA-DM1082, X540LA-DM1115, X540LA-DM1155, X540LA-DM1155T, X540LA-DM1255, X540LA-DM1260, X540LA-DM1289, X540LA-DM1327, X540LA-DM1444, X540LA-XX002T, X540LA-XX003T, X540LA-XX004T, ASUS [X540LA-XX010T](#) Laptop Battery, X540LA-XX013T, X540LA-XX036T, X540LA-XX265T, X540LA-XX289, X540LA-XX315D, X540LA-XX360T, X540LA-XX439D, X540LA-XX440D, X540LA-XX440T, X540LA-XX441D, X540LA-XX487, X540LA-XX532T, X540LA-XX533T, ASUS [X540LA-XX538T](#) Laptop Battery, X540LA-XX641T, X540LA-XX677T, X540LA-XX736, X540LA-XX774D, X540LA-XX813T, X540LA-XX821, X540LA-XX821T, X540LA-XX972D, X540LA-XX972T, X540LA-XX988T, X540LA-XX990T, X540LJ, X540LJ-1A, X540LJ-1C, X540LJ-3F, X540LJ-3G, X540LJ-3H, X540LJ-XX001D, X540LJ-XX001T, X540LJ-XX002D, X540LJ-XX014T, X540LJ-XX015D, X540LJ-XX015T, X540LJ-XX044T, X540LJ-XX136D, X540LJ-XX137T, X540LJ-XX250T, X540LJ-XX315D, X540LJ-XX316D, X540LJ-XX318T, X540LJ-XX403D, X540LJ-XX404D, X540LJ-XX451D, X540LJ-XX513T, X540LJ-XX550D, X540LJ-XX550T, X540LJ-XX569D, X540LJ-XX569T, ASUS [X540LJ-XX584D](#) Laptop Battery, X540LJ-XX600D, X540LJ-XX608D, X540LJ-XX609D, X540LJ-XX611D, X540LJ-XX661T, X540LJ-XX755T, X540LJ-XX757T, X540LJ-XX758T, X540LJ-XX827T, X540LJ-XX853, X540MA, X540NA-DM009, X540NA-DM037, X540NA-DM083, X540NA-DM159, X540NA-DM181T, X540NA-DM184, X540NA-DM208, X540NA-DM236, X540NA-GO034, X540NA-GQ004, X540NA-GQ017T, X540NA-GQ044, X540NA-GQ052T, X540NA-GQ063T, X540NA-GQ093T, X540NA-GQ139T, X540NA-GQ171T, X540NA-GQ247C, X540NV, X540NV-0021AN4200, X540NV-DM028, X540NV-DM032, X540NV-DM037, X540NV-DM073, ASUS [X540NV-GQ001](#) Laptop Battery, X540NV-GQ002T, X540NV-GQ004, X540NV-GQ006, X540NV-GQ015, X540NV-GQ051, X540S, X540SA, X540SA-1A, X540SA-1C, X540SA-3F X540SA-XX012T, X540SA-3G, X540SA-3H, X540sa-DM286T, X540sa-DM290, X540sa-DM669D, X540SA-XX004D, X540SA-XX014D, X540SA-XX020T, X540SA-XX024T, X540SA-XX041D, ASUS [X540SA-XX041T](#) Laptop Battery, X540SA-XX062T, X540SA-XX081T, X540SA-XX085T, X540SA-XX095T, X540SA-XX108T, X540SA-XX109D, X540SA-XX158T, X540SA-XX166D, X540SA-XX166T, X540SA-XX178D, X540SA-XX210T, X540SA-XX223D, X540SA-XX236D, X540SA-XX311D, X540SA-XX345T, X540SA-XX366D, X540SA-XX383T, X540SA-XX384D, X540SA-XX400T,

X540SA-XX401D, X540SA-XX411D, X540SA-XX443T, ASUS [X540SA-XX511T](#) Laptop Battery, ASUS [X540SA-XX565T](#) Laptop Battery, X540SA-XX652T, X540SA-XX666T, X540SA-XX771T, X540SC, X540SC-1A, ASUS [X540SC-1C](#) Laptop Battery, X540SC-3F, X540SC-3G, X540SC-3H, X540SC-XX010D, X540SC-XX029D, X540SC-XX033T, X540SC-XX034T, X540SC-XX040T, X540SC-XX073T, X540SC-XX107T, X540U, X540UA-1A, X540UA-DB51, X540UA-DB52, X540UA-DB71, X540UA-DM029, X540UA-DM031, ASUS [X540UA-DM038T](#) Laptop Battery, X540UA-DM1130, X540UA-DM1138, X540UA-DM120, X540UA-DM186, X540UA-DM250, X540UA-DM260, X540UA-DM413, ASUS [X540UA-DM437](#) Laptop Battery, X540UA-DM563, X540UA-DM564, X540UA-DM597, X540UA-DM626, X540UA-DM664, X540UA-DM746, ASUS [X540UA-DM891](#) Laptop Battery, X540UA-DM895, X540UA-DM910, X540UA-GQ010, X540UA-GQ057T, X540UA-GQ058, X540UA-GQ074, X540UA-GQ075, X540UA-GQ170, X540UA-GQ198T, X540UA-GQ221, X540UA-GQ284, X540UA-GQ396, X540UA-GQ584, X540UA-GQ683, X540UA-GQ688, X540UA-GQ704, X540UA-GQ884, X540UA-GQ903, X540UA-GQ957, X540UB, X540UB-1C, X540UB-DM015, X540UB-DM022, X540UB-DM024T, X540UB-DM032, X540UB-DM048, X540UB-DM104, X540UB-DM148, X540UB-DM196, X540UB-DM227, X540UB-DM229, X540UB-DM233, X540UB-DM249, X540UB-DM262, X540UB-DM330, X540UB-DM342, X540UB-DM350, X540UB-DM438, X540UB-DM489, X540UB-DM505, X540UB-DM547, X540UB-DM548, X540UB-DM549, X540UB-DM678, X540UB-DM717, X540UB-DM718, X540UB-GQ002, X540UB-GQ011T, X540UB-GQ026, X540UB-GQ041, X540UB-GQ063, X540UB-GQ064, X540UB-GQ331, ASUS [X540UB-GQ335](#) Laptop Battery, X540UB-GQ344, X540UB-GQ351, X540UB-GQ493, X540UB-GQ522, X540UP-1C, X540UP-3F, X540UP-GO035D, X540UP-GO059T, X540UP-GO072D, X540UP-GO072T, X540UP-GO086D, ASUS [X540UP-GO106D](#) Laptop Battery, X540UP-GO142D, X540UP-GO175T, X540UP-GO200T, X540UP-XX020T, X540UP-XX027T, X540UP-XX039T, ASUS [X540UP-XX117D](#) Laptop Battery, X540UP-XX117T, X540UP-XX234T, X540UP-XX235T, X540UV-DM021T, X540UV-DM022, ASUS [X540UV-DM023](#) Laptop Battery, X540UV-DM216, ASUS [X540UV-GQ005](#) Laptop Battery, X540UV-GQ006, X540UV-GQ008, X540UV-GQ009, X540UV-GQ207, X540YA-1A, X540YA-1C, X540YA-3F, X540LA-XX021T, X540YA-BX102T, X540YA-DB02, X540YA-DM085T, X540YA-DM122T, X540YA-DM133D, X540YA-DM320D, X540YA-DM336T, X540YA-DM344T, X540YA-DM369D, X540YA-DM451T, X540YA-DM624D, X540YA-DM660D, X540YA-DM686T, X540YA-DM801D, X540YA-DM805D, X540YA-E1-6010, X540YA-RS21-CB, X540YA-XO033T, X540YA-XO047T, X540YA-XO068T, X540YA-XO104D, X540YA-XO106T, X540YA-XO107D, X540YA-XO185D, X540YA-XO290T, X540YA-XO498D, X540YA-XO534D, X540YA-XO534T, X540YA-XO648D, X540YA-XO648T, X540YA-XO688D, X540YA-XO751T, X540YA-XO754D, X540YA-XO811D, X540YA-XX006D, X540YA-XX052T, X540YA-XX187D, X540YA-XX252T, X540YA-XX501T, X540YA-XX530T, X541, x541n, X541NA, X541NA-1A, X541NA-1C, X541NA-3F, X541NA-3G, X541NA-3H, X541NA-YS01, X541NC, X541NC-1A, X541NC-1C, X541NC-3F, X541NC-3G, X541NC-3H, X541NC-DM061, X541NC-DM121, X541NC-GO001T, X541NC-GQ063, X541NC3450, X541S, X541SA, X541SA-1A, X541SA-1C, X541SA-3F, X541SA-3G, X541SA-3H, X541SA-PD0703X, X541SA-XO041D, X541SA-XO287T, X541SA1A, X541SA1C, X541SA3F, X541SA3G, X541SA3H, X541SC, X541SC X541U, X541SC-1A, X541SC-1C, X541SC-3F, X541SC-3G, X541SC-3H, X541SC1A, X541SC1C, X541U, X541UA, X541UA-1A, X541UA-1C, ASUS [X541UA-3F](#) Laptop Battery, X541UA-3G, X541UA-3H, X541UA-DH51, X541UA-DM396T, X541UA-GQ1026T, X541UA-GQ1316T, X541UA-GQ871D, X541UA-GQ871T, X541UA-GQ95, X541UA-XX532T, X541UA1A, X541UA1C, ASUS [X541UA3G](#) Laptop Battery, X541UADM396T, ASUS [X541UAGQ95](#) Laptop Battery, X541UAXX532T, X541UJ, X541UJ-1A, X541UJ-1C, X541UJ-3F, ASUS [X541UJ-3G](#) Laptop Battery, X541UJ-3H, X541UV, X541UV-1A,

X541UV-1C, X541UV-3F, X541UV-3G, X541UV-3H, ASUS [X541UV-DM1134T](#) Laptop Battery, X541UV-DM1135T, X541UV-DM594T, X541UV1A, X541UV1C, X541UV3F, X541UV3G, X54c, X54c, X54C-BB31-CB, X54C-BBK11, X54C-BBK11, X54C-BBK22, X54C-BBK22, ASUS [X54C-BBK3](#) Laptop Battery, X54C-S0129D, X54C-SX034V, X54C-SX034V, X54C-SX102V, X54C-SX292V, X54C-SX292V, X54CBB31CB, X54CBBK3, X54CS0129D, X54CSX102V, X54F, X54F, X54H, X54H-BD1BH, X54H-BD3MA, X54H-BD3MA, X54H-SO166V, X54H-SO166V, X54HB, X54HBD1BH, X54HBD3MA, X54HR, X54HR-SX196V, X54HR-SX196V, X54HRSX196V, X54HY, X54HY SERIES, X54HY SERIES, X54HY-SX032V, X54HYSX032V, X54K, X54K, X54L, X54L-BBK2, X54L-BBK4, X54LB, X54LBBK2, X54LBBK4, X54LY, X54XB815HR, X54XB815HR, X54XB95HR-SL, X54XI2328HR-SL, X54XI235HR, X550, x550 Series, X550A, X550B, X550C, X550C I7, X550C-CJ441H, X550CA, x550ca-cj296h, X550CA-WB51, X550CA-XO086H, X550CA-XO113H, X550CA-XO266H, X550CA-XX101H, X550CA-XX194D, X550CA-XX249H, X550CA-XX258D, X550CA-XX322H, X550CA-XX417H, X550CA-XX545D, X550CA-XX635H, X550CA-XX647H, X550CA-XX877H, X550CA-XX957H, X550CA-XX985H, X550CC, X550CC-X3337U, X550CC-XO072H, X550CC-XO073H, X550CC-XO824H, X550CC-XX, X550CC-XX085H, X550D, X550DP, X550DP-XX006H, X550DP-XX046D, X550DP-XX075D, X550DP-XX106H, X550DP-XX158B, X550DP5550-SL, X550EA, X550EA-CJ027H, X550EA-CJ172H, X550EA-MM1, X550EA-MS1, X550EA/AB, X550IK, X550IK-BX001T, X550IK-DM033, X550IK-DM049T, X550IK-GO037T, X550IU-0043J9830P, X550IU-BX001D, X550IU-BX002D, X550IU-DM007D, X550IU-DM087T, X550IU-GO098T, X550J, X550JD4200, X550JD4710, X550JF-1B, X550JF-MS71, X550JK, X550JX, ASUS [X550JX-DM009T](#) Laptop Battery, X550JX-DM244T, ASUS [X550L](#) Laptop Battery, X550L DV-XX506H, ASUS [X550LA](#) Laptop Battery, X550LB, X550LC, X550LD4010, X550LM, X550LN, X550LN-XO033H, X550V, X550VB, X550VB-XX047H, X550VC, X550VX, X550VX-1A, X550VX-1B, X550VX-3H, X550VX-3J, X550VX-DM080T, X550VX-DM097T, X550VX-DM113T, X550VX-DM235T, X550VX-XX067D, X550VX-XX147D, ASUS [X550WA](#) Laptop Battery, X550X1007CC-SL, X550X2117CC-SL, ASUS [X550X311VC-SL](#) Laptop Battery, X550X3217CC-SL, X550X3337CC-SL, X550X401LC-SL, X550X42LC-SL, X550XI323VC-SL, X550ZA, X550ZA-SA100603E, X550ZA-WH11, ASUS [X550ZE-DM004H](#) Laptop Battery, X550ZE-DM048D, X550ZE-DM194T, X550ZE-XX025H, X550ZE-XX047D, X550ZE-XX057D, X550ZE-XX066H, X550ZE-XX216T, X551, X551 Series, X551C, X551C Series, X551CA, X551CA Series, X551CA-0051A2117U, X551CA-BH91-CB, X551CA-DH21, X551CA-DH31-CA, X551CA-FH91-CB, X551CA-QS31-CB, X551CA-QSP2-CB, X551CA-SI30403X, X551CA-SX010D, X551CA-SX011D, X551CA-SX012D, X551CA-SX012H, X551CA-SX013D, X551CA-SX013P, X551CA-SX014D, X551CA-SX014H, X551CA-SX016D, X551CA-SX018D, X551CA-SX019H, X551CA-SX021H, X551CA-SX022H, X551CA-SX024D, X551CA-SX024D-W7, X551CA-SX024H, X551CA-SX026D, X551CA-SX029B, X551CA-SX029D, X551CA-SX029H, ASUS [X551CA-SX030D](#) Laptop Battery, X551CA-SX030H, X551CA-SX032D, X551CA-SX043D, X551CA-SX047H, X551CA-SX062H, X551CA-SX073D, ASUS [X551CA-SX074H](#) Laptop Battery, ASUS [X551CA-SX075D](#) Laptop Battery, ASUS [X551CA-SX077D](#) Laptop Battery, X551CA-SX078D, X551CA-SX079H, X551CA-SX086H, X551CA-SX090H, X551CA-SX103H-BE, X551CA-SX118H, X551CA-SX119H, X551CA-SX130D, X551CA-SX137D, X551CA-SX138H, X551CA-SX143D, X551CA-SX144D, X551CA-SX149D, X551CA-SX149H, X551CA-SX150H, X551CA-SX153H, X551CA-SX153H-BE, X551CA-SX155D, X551CA-SX155H, X551CA-SX155R, X551CA-SX156H, X551CA-SX175H, X551CA-SX198H, X551CA-SX201H, ASUS [X551CA-SX206H](#) Laptop Battery, X551CA-SX207H, X551CA-SX220D, X551CA-SX222H, X551CA-SX237H, X551CA-SX291H, X551CA-SX292H, X551CA-XH31, X551M, X551MA, X551MA-BING-SX373B, X551MA-BING-SX391B, X551MA-BING-SX950B, X551MA-SX018D, ASUS [X551MA-SX020H](#)

Laptop Battery, X551MA-SX021D, X551MA-SX021H, X551MA-SX023D, X551MA-SX023H, X551MA-SX024D, X551MA-SX026D, X551MA-SX026H, X551MA-SX035H, X551MA-SX048H, X551MA-SX056D, X551MA-SX057D, X551MA-SX066D, X551MA-SX088D, X551MA-SX090D, X551MA-SX103D, X551MA-SX131D, X551MA-SX132D, X551MA-SX150D, X551MA-SX159H, X551MA-SX163H, X551MA-SX171H, X551MA-SX206H, X551MA-SX207H, X551MA-VX043D, ASUS [X551MAV](#) Laptop Battery, X551MAV-BING-SX1016B, X551MAV-BING-SX1017B, X551MAV-BING-SX364B, X551MAV-BING-SX386B, X551MAV-BING-SX391B, X551MAV-BING-SX966B, X551MAV-BING-SX970B, X551MAV-BING-SX993B, X551MAV-RCLN06, X551MAV-SX1011H, X551MAV-SX251D, X551MAV-SX299H, X551MAV-SX300D, X551MAV-SX300H, X551MAV-SX303D, X551MAV-SX305D, X551MAV-SX327D, X551MAV-SX350D, X551MAV-SX353D, X551MAV-SX368B, X551MAV-SX385B, X551MAV-SX386B, X551MAV-SX942H, X551MAV-SX962B, X551MAV-SX970H, X551MAVRCLN06, X552c, X552E, X552EA, X552EP, X552LA, X552LD, X552LDV, X552MD, X552MD-SX064H, X552VL, X552W, ASUS [X552WA](#) Laptop Battery, X552WE, X553M, X553MA, X554, X554L, X555, X5550C, X555BA-BX901D, X555BA-RH91, X555BA-XO202T, ASUS [X555BA-XX019T](#) Laptop Battery, X555BP-BX901D, X555BP-BX921T, X555BP-XX022D, X555BP-XX101T, X555BP-XX246T, X555DA-AS11, X555DA-SS10, X555DA-US11, X555DG-XO052, X555DG-XO091T, ASUS [X555DG-XX027D](#) Laptop Battery, X555DG-XX033T, X555DG-XX133T, X555L, X555LA, X555LA-1A, X555LA-1B, X555LA-3C, X555LA-3D, X555LA-3E, ASUS [X555LA-3F](#) Laptop Battery, X555LA-3G, X555LA-3H, X555LA-7K, X555LA-7L, X555LA-DB71, X555LA-SI30202G, X555LA-XX036H, X555LA-XX046H, X555LA-XX053D, X555LA-XX060H, X555LA-XX092H, X555LA-XX152D, X555LA-XX152H, X555LA-XX2129T, X555LA-XX2276T, X555LA-XX2717T, X555LA-XX521D, X555LA-XX521H, X555LA-XX546H, X555LB, X555LB-1A, ASUS [X555LB-1B](#) Laptop Battery, X555LB-3C, X555LB-3D, X555LB-3E, X555LB-3F, X555LB-3G, X555LB-3H, X555LB-DM137H, X555LB-DM223H, X555LB-DM252H, X555LB-XO017H, X555LB-XO040H, X555LB-XO040HH, X555LB-XO060D, X555LB-XO101H, X555LB-XO122H, X555LB-XO141D, X555LB-XO190H, X555LB-XO238D, X555LB-XO238H, X555LB-XO246H, X555LB-XO247H, X555LB-XO248H, ASUS [X555LB-XO275H](#) Laptop Battery, X555LB-XO294D, X555LB-XO316H, X555LB-XO359H, X555LB-XX002T, X555LB-XX127T, X555LD, X555LD-1A, X555LD-1B, X555LD-3C, X555LD-3D, X555LD-3E, X555LD-3F, X555LD-3G, X555LD-3H, X555LD-7K, X555LD-7L, X555LD-XO034H, X555LD-XO052H, X555LD-XO067H, X555LD-XO069H, X555LD-XO078H, X555LD-XO080H, X555LD-XO338H, X555LD-XO412H, X555LD-XO549H, X555LD-XX062H, X555LD-XX087H, X555LD-XX167H, ASUS [X555LD-XX221H](#) Laptop Battery, X555LD-XX283H, X555LD-XX325H, X555LD-XX326H, X555LD-XX717H, X555LD4010, X555LD4030, X555LD4210, X555LF, X555LF-1A, X555LF-1B, X555LF-3C, X555LF-3D, X555LF-3E, X555LF-3F, X555LF-3G, X555LF-3H, X555LF-XO052H, X555LF-XO063H, X555LF-XO075H, X555LF-XO147H, X555LF-XO188T, X555LF-XO282T, X555LF-XO393D, X555LF-XX245T, ASUS [X555LI](#) Laptop Battery, X555LI-1A, X555LI-1B, X555LI-7K, X555LJ, X555LJ-1A, X555LJ-2A, X555LJ-2B, X555LJ-3C, X555LJ-3D, X555LJ-3E, X555LJ-3F, X555LJ-3G, X555LJ-3H, X555LJ-7K, X555LJ-7L, X555LN, X555LN-1A, X555LN-1B, X555LN-3C, X555LN-3D, ASUS [X555LN-3E](#) Laptop Battery, X555LN-3F, X555LN-3G, X555LN-3H, X555LN-DM176H, X555LN-DM197H, X555LN-DM473H, X555LN-DM497H, X555LN-XO002D, X555LN-XO004D, X555LN-XO029H, X555LN-XO031D, X555LN-XO034H, X555LN-XO062H, X555LN-XO112H, ASUS [X555LN-XO115H](#) Laptop Battery, ASUS [X555LN-XO126H](#) Laptop Battery, X555LN-XO244H, X555LN-XO246H, X555LN-XO252D, X555LN-XO420H, X555LN-XX026H, X555LN-XX058D, X555LN-XX308D, X555LP, X555LP-1A, X555LP-1B, X555LP-7K, X555QA-BH10, X555QA-BH12, X555QA-DH12, X555QA-DM2019T, X555QG-BX121D, X555QG-BX221D, X555QG-DM015T,

X555QG-DM039D, X555QG-DM093T, X555QG-DM116T, X555QG-DM130T, X555QG-DM206D, X555QG-DM242, X555QG-DM253T, X555QG-DM278D, X555QG-DM397T, X555QG-XO052T, X555QG-XO164T, X555QG-XO299T, X555QG-XO308T, X555QG-XX058T, X555QG-XX068T, X555QG-XX111T, X555QG-XX157T, X555QG-XX262T, X555QG-XX283T, X555QG-XX385T, X555QG-XX423T, X555SJ-XO001D, X555SJ-XO011T, X555SJ-XO020D, X555UA, X555UA-1A, X555UA-1B, X555UA-3E, X555UA-3F, X555UA-3G, X555UA-DM062T, X555UA-XO073T, X555UA-XO136T, X555UA-XO220D, X555UA-XX030T, X555UA-XX039T, ASUS [X555UA-XX066T](#) Laptop Battery, X555UA-XX124T, X555UB, X555UB-1A, X555UB-1B, X555UB-3C, X555UB-3E, X555UB-3F, X555UB-3G, X555UB-3H, X555UB-3I, X555UB-3J, X555UB-DM106T, X555UB-NS71, X555UB-XO064D, X555UB-XO064T, X555UB-XO105T, X555UB-XO138T, X555UB-XO139T, X555UB-XX018T, X555UB-XX077T, X555UB-XX299T, X555UF, X555UF-1B, ASUS [X555UF-3E](#) Laptop Battery, X555UF-3F, X555UF-3G, X555UF-XO013T, X555UJ, X555UJ-1A, X555UJ-1B, X555UJ-3E, X555UJ-3F, X555UJ-3G, X555UJ-XO112T, X555UJ-XO113T, X555UJ-XX073T, X555UJ-XX124T, X555UQ, X555UQ-3C, X555UQ-3I, X555UQ-3J, X555UQ-XO075T, X555UQ-XX305T, X555YA, ASUS [X555YA-1B](#) Laptop Battery, X555YA-7K, X555YA-7L, X555YA-DB84Q, X555YA-XO010D, X555YA-XO010T, X555YA-XO015T, X555YA-XX008T, X555YA-XX069D, X555YA-XX088, X555YA-XX114T, X555YI, X555YI-7K, X555YI-7L, X555YI-XO014D, X555YI-XO014T, X555YI-XO028D, X555YI-XO103T, X555YI-XX022D, X555YI-XX054T, X555YI-XX057T, X555YI-XX108D, X555YI-XX135, X555YI-XX163, X556, X556U, X556UA, X556UA-1A, X556UA-1B, X556UA-1C, X556UA-3G, X556UA-XO607T, X556UB, ASUS [X556UB-1B](#) Laptop Battery, X556UB-1C, X556UB-3F, X556UB-3G, X556UB-XX039T, X556UF, X556UF-1A, X556UF-1B, X556UF-1C, X556UF-3F, X556UF-3G, X556UJ, X556UJ-1A, X556UJ-1C, X556UJ-3G, X556UJ-XO015T, X556UQ, X556UQ-1A, ASUS [X556UQ-1B](#) Laptop Battery, X556UQ-1C, X556UQ-3F, X556UQ-3G, X556UQ-DM866T, X556UQ-XO076T, X556UR, X556UR-1A, X556UR-1B, X556UR-1C, X556UR-3F, X556UR-3G, X556UV, X556UV-1A, X556UV-1B, X556UV-1C, X556UV-3F, X556UV-3G, X55LM9H, X55Sa Series, X55Sr Series, X55Sv Series, X55U, X56, X562FD-2G, X56s, X56SN, X56TR, X56VERIES, ASUS [X56VR](#) Laptop Battery, X57, X570, X570UD, X570UD-1B, X570UD-DM159T, X570UD-DM297T, X570UD-E4006T, X570UD-E4022T, X570UD-E4305T, X570ZD, X570ZD-1B, X570ZD-DM209T, X57VC, X58, X580GD, X580GD-1A, X580GD-1B, X580GD-9A, X580VD, X580VD-1A, X580VD-1B, X580VD-9A, X580VD-9B, X580VN, X580VN-1A, X580VN-1B, X58C, X58L, X58LE, X59, X59SL, ASUS [X5AEC](#) Laptop Battery, X5C, X5C Series, X5CQ, X5D, X5D Series, X5DAB, X5DAD, X5DAF, X5DC, X5DI, X5DID, X5DIE, X5DIJ, X5DIJ-SX039c, X5DIL, X5DIN, X5DIN-SX183V, X5DIN-SX031C, ASUS [X5DIP](#) Laptop Battery, X5E, X5E Series, x5ea, X5EAC, X5EAE, X5J, X5J SERIES, X5JIJ, X5LD, X5LDA, X5LJ, X5LJT, X5LJU, X5LJV, X61, X61 Series, X61GX, X61S, X61Sf, X61SL, X61SV, ASUS [X61W](#) Laptop Battery, X61Z, X65, X65 Series, X66IC, X70 Series, X705NA, X705NC, ASUS [X705UA](#) Laptop Battery, X705UV, X70AB, X70AC, X70AD, X70AF, X70E, X70F, X70I Series, X70IC, X70IC Series, X70ID Series, X70IJ, X70IJ Series, X70IL, X70IL Series, X70IO, X70IO Series, X70IS Series, X70Kr, X70L, X70Se, X70Sr, X70Z, X71, X71 Series, X712FA, X712FB, X712FB-AU115T, X71A, X71Q, X71S, X71SL, X71SL-C1, X71sr, X71T, X71TL, X71TP, X71V, X71VM, ASUS [X71VN](#) Laptop Battery, X72, X72 Series, X72D, X72DR, X72F, X72F-XR4, X72F-XR5, X72J, X72JK, X72JR, X72JT, X72V, X72VM, X72VN, X72VR, X73 Series, X73B Series, X73BR, X73BY, X73E, X73S, X73SD, X73SJ, ASUS [X73SL](#) Laptop Battery, X73SM, X73SV, X73T, X73TA, X73TK, X750J, X750JA, X750JA-3C, X750JA-DB71, X750JA-TH71, X750JA-TY003H, X750JA-TY006H, X750JA-TY007H, X750JA3C, X750JADB71, ASUS [X750JATY003H](#) Laptop Battery, X750JATY006H, X750JATY007H, X750JB, X750JB-3C, X750JB-DB71, X750JB-TY002H, X750JB-TY005D, X750JB-TY008H, X750JB-

TY011H, X750JB-TY030H, X750JB-TY033H, X750JB3C, X750JBDB71, X750JBTY002H, X750JBTY008H, X750JN, X750JN-3C, X750JN-TY002H, X750JN-TY008H, X750JN-TY009D, X750JN-TY027H, X750JN-TY031H, X750JN-TY033D, X750JN-TY035H, X750JN-TY038D, X750JN-TY041H, X750JN-TY050H, X750JN3C, X750JNTY002H, X750JNTY008H, X750JNTY009D, X750JNTY027H, X750JNTY031H, X750JNTY033D, X750JNTY035H, ASUS [X750JNTY038D](#) Laptop Battery, X750JNTY041H, X750JNTY050H, X750LA, X750LA-3C, X750LA-TY004H, X750LA-TY007H, X750LA-TY011D, X750LA-TY012D, X750LA-TY025D, X750LA-TY026H, ASUS [X750LA-TY030H](#) Laptop Battery, X750LA3C, X750LATY004H, X750LATY007H, X750LATY011D, X750LATY012D, X750LATY025D, X750LATY026H, X750LATY030H, X750LB, X750LB-1B, X750LB-3C, X750LB-T4017H, X750LB-T4028H, X750LB-TY003H, X750LB-TY009H, X750LB-TY010H, X750LB-TY039H, X750LB1B, X750LB3C, X750LBT4017H, X750LBT4028H, X750LBTY003H, ASUS [X750LBTY009H](#) Laptop Battery, X750LBTY010H, X750LBTY039H, X750LN, X750LN-3C, X750LN-T4036H, X750LN-T4039H, X750LN-T4077D, X750LN-T4083H, X750LN-T4136H, X750LN-T4137H, X750LN-T4138H, ASUS [X750LN-T4165D](#) Laptop Battery, X750LN-TY009H, X750LN-TY010H, X750LN-TY011H, X750LN-TY012H, X750LN-TY015H, X750LN-TY018H, X750LN-TY019H, X750LN-TY020H-BE, X750LN-TY025H, X750LN-TY028H, X750LN-TY029H, X750LN-TY040H, ASUS [X750LN-TY063H](#) Laptop Battery, X750LN-TY082H, X750LN-TY132H, X750LN-TY134H, X750LN3C, X750LNT4036H, X750LNT4039H, X750LNT4077D, X750LNT4083H, X750LNT4136H, X750LNT4137H, X750LNT4138H, X750LNT4165D, X750LNTY009H, X750LNTY010H, X750LNTY011H, X750LNTY012H, X750LNTY015H, X750LNTY019H, X750LNTY025H, X750LNTY028H, X750LNTY029H, X750LNTY040H, X750LNTY063H, X750LNTY082H, X750LNTY132H, X750LNTY134H, X751BA, X751BP, ASUS [X751BP-1A](#) Laptop Battery, X751BP-1B, X751BP-TY001T, X751BP-TY029T, X751BP-TY032T, X751BP-TY033T, ASUS [X751BP-TY036T](#) Laptop Battery, X751BP-TY048T, X751BP-TY106, X751BP1A, X751BP1B, X751BPTY001T, X751BPTY029T, X751BPTY032T, X751BPTY048T, X751L, X751LA, X751LA-1A, X751LA-1B, ASUS [X751LA-3C](#) Laptop Battery, X751LA-DB31-CA, X751LA-TY012H, X751LA-XS51, X751LA1A, X751LA1B, X751LA3C, X751LADB31CA, X751LATY012H, X751LAV, X751LAV-TY057H, X751LAV-TY058H, X751LAV-TY062H, X751LAV-TY106H, X751LAV-TY118H, X751LAV-TY138H, X751LAV-TY175H, X751LAVTY057H, X751LAVTY058H, X751LAVTY062H, X751LAVTY106H, X751LAVTY118H, ASUS [X751LAVTY138H](#) Laptop Battery, X751LAVTY175H, X751LAXS51, X751LB, X751LB-1A, X751LB-3A, X751LB-TY013H, X751LB-TY014H, X751LB-TY139T, X751LB-TY140D, X751LB-TY201T, X751LB-TY229D, X751LB-TY238T, X751LD, X751LD-9A, X751LD-TY082H, X751LDTY082H, ASUS [X751LDV](#) Laptop Battery, X751LDV-TY152H, X751LDVTY152H, X751LJ, X751LJ-1B, X751LJ-TY032T, X751LJ-TY096H, X751LJ-TY145H, ASUS [X751LJ-TY171T](#) Laptop Battery, X751LJ-TY193T, X751LJ-TY240T, X751LJ-TY262T, X751LJ-TY324T, X751LJ-TY401T, X751LJ-TY443T, X751LK, X751LK-1A, X751LK-3C, X751LN, X751LN-1B, X751LX, X751MA, X751MA-1A, X751MA-9A, X751MD, X751MD-1B, X751MJ, X751MJ-1B, x751n, ASUS [X751NA](#) Laptop Battery, X751NA-1B, X751NV-1B, X751NV-TY006T, x751s, X751SA-MS91-CA, X751SA-TY025D, X751SA-TY027D, X751SA-TY068T, X751SA-TY101T, X751SA-TY124D, X751SA-TY128T, X751SA-TY157T, X751SJ-1B, X751SJ-TY023T, X751SV, X751SV-1B, X751SV-TY002T, X751SV-TY008T, X751SV-TY009T, X751YI-1B, X751YI-TY036T, X751YI-TY145T, X756, X756UA, X756UB, X756UJ, X756UQ, X756UV, X756UW, X756UX, X75VD, X77 Series, X77-JV TY063V, X77-TY003V, X77-TY018V, X77J, X77JA, X77JA-TY006V, X77JG, X77JO, X77JQ, X77JQ-TY014V, X77JQ-TY072V, X77JV, X77JV-TY050V, ASUS [X77JV-TY051V](#) Laptop Battery, X77JV-TY052V, X77JV-TY101V, X77VG, X77VG-TY017V, X77VG-TY056V, X77VG-TY085V,

X77VN, X77VN-TY026V, X77VN-TY027V, X7BJF, X7BJN, X7BJQ, X7BS, X7BSN, X7BSV, X8, X8 Series, X80, X80 Series, X80A, X80H, X80Le, X80N, X80Z, X82, X82 Series, X82S, X83 Series, X83V, X83VB, X83VB-X2, X83VBX2, X83VM-X1, X83VMX1, X84, X84 SERIES, X84C, X84EB815HR-SL, X84EB815HRSL, X84EB82HR-SL, X84EB82HRSL, X84EB94HR-SL, X84EB94HRSL, ASUS [X84EB95HR-SL](#) Laptop Battery, X84EB95HRSL, X84EB95LY-SL, X84EB95LYSL, X84EB96HR-SL, X84EB96HRSL, X84EI233HR-SL, X84EI233HRSL, X84EI233LY-SL, X84EI233LYSL, ASUS [X84EI235HR-SL](#) Laptop Battery, X84EI235HRSL, X84EI235HY-SL, X84EI235HYSL, ASUS [X84EI235LY-SL](#) Laptop Battery, X84EI235LYSL, X84H, X84HO, X84HR, X84HY, X84L, X84L SERIES, X84LY, X84S, X84SL, X85, X85 Series, X85C, X85L, X85S, X85SE, X87 Series, X87Q, X88V, X8A Series, X8AAB, X8AAD, X8AAF, X8AC, X8AID, X8AIE, X8AIJ, X8AIL, X8AIN, X8AIN-021ACOT6570, X8AIN-VX084C, X8AIP, X8B, X8B Series, X8BJT, X8BVT, X8D, X8D SERIES, X8DIJ, X8E SERIES, X8EJQ, X8EJV, X8F SERIES, X8FF, X8FJC, X8LY, X93SM, X93SM-YZ018V, X93SM-YZ055V, X93SM-YZ057V, X93SM-YZ064V, ASUS [X93SM-YZ065V](#) Laptop Battery, X93SM-YZ087V, X93SM-YZ092V, X93SM-YZ094V, X93SM-YZ121V, X93SM-YZ129V, X93SM-YZ145V, X93SV, X93SV-YZ112V, X93SV-YZ132V, X93SV-YZ145V, X93SV-YZ147V, X93SV-YZ154V, X93SV-YZ182V, X93SV-YZ183V, X93SV-YZ220V, X93SV-YZ221V-BE, X93SV-YZ224V, X93SV-YZ227V, X93SV-YZ228V, X93SV-YZ235V, ASUS [X93SV-YZ260V](#) Laptop Battery, Y4100FA, Y4100UA, Y4100UB, Y481, ASUS [Y481CA](#) Laptop Battery, Y481CC, Y481E3337CC-SL, Y481V, Y481VC, Y482, Y482CP, Y482E, Y482EA, Y482EP, Y483L, Y483LD, Y5100DA, Y5100DK, Y581, Y581C Series, Y581CA Series, Y581CC Series, Y581L Series, Y581LA Series, Y581LB Series, Y581LC Series, Y582, Y582C, Y582CL, Y583, Y583L, Y583LD, Y58LD, YME571KL-1A044A, YME571KL1A044A, YX570, YX570U, ASUS [YX570UD](#) Laptop Battery, YX570UD8250, YX570ZD, Z0170CG 1A, ASUS [Z0310CX 1A](#) Laptop Battery, Z170C 1A, Z170C 1B, ASUS [Z170C 1C](#) Laptop Battery, Z170C 1L, Z170CG 1A, Z170CG 1B, Z170CG 1L, Z170MG 1A, Z170MG 1B, Z300C 1A, Z300C 1B, Z300C 1L, Z300CG 1A, Z300CG 1L, Z300CL 1A, Z300CL 1B, Z300CL 1L, Z300CL-1A DOCK, Z300CL-1L DOCK, Z300CL1A DOCK, Z300CL1L DOCK, Z300CT 1A, Z300CX 1A, Z300CX 1B, Z300CX 1L, Z300CXG 1A, Z300CXG 1B, Z300CXG 1L, Z33, Z33AE, Z35, Z35F, Z35H, Z35L, Z37, Z37 Series, Z370C 1A, Z370C 1B, Z370C 1L, Z370CG 1A, Z370CG 1B, Z370CG 1L, Z370KL 1A, Z370KL 1B, Z370KL 1L, Z37A, Z37A, Z37E, ASUS [Z37EP](#) Laptop Battery, Z37EP, Z37K, Z37S, Z37SP, Z37SP, Z37V, Z37V, Z380C, Z380C 1A, Z380C 1B, Z380C 1L, Z380CX, Z380CX 1A, Z380CX 1B, Z380CX 1L, Z380KL, ASUS [Z380KL 1A](#) Laptop Battery, Z380KL 1B, Z380KL 1L, Z380KL LASER LABEL, Z380KNL, Z380KNL 6A, Z380M, Z380M 6A, Z380M 6B, Z380M 6L, Z450, Z450LA, Z450LA-1B, Z450LA-3I, Z450LA-WX002T, Z450LA-WX006T, Z450LA-WX007T, Z450LA-WX008T, Z450LA-WX009T, Z450LA-WX010T, Z450UA, Z450UA-1B, ASUS [Z450UA-3I](#) Laptop Battery, Z450UA-WX001T, ASUS [Z450UA-WX002T](#) Laptop Battery, Z450UA-WX003T, Z450UA-WX004T, Z500M, Z53, Z53 Series, ASUS [Z53J](#) Laptop Battery, Z53Jc, Z53T, Z550, Z550MA, Z550MA-1A, Z550MA-3G, Z550MA-XX004T, Z550MA-XX005T, Z550SA, Z550SA-1A, Z550SA-3G, Z550SA-XX001T, Z550SA-XX002T, Z580C, Z580C 1A, Z580C 1B, Z580CA, Z580CA 1A, Z580CA 1B, Z62, Z62E, Z62F, Z62FM, Z62H, Z62HA, Z62J, Z62JM, ASUS [Z65R](#) Laptop Battery, Z7, Z70, Z70 Series, Z7000, Z7000A, Z7000N, Z7000NE, Z7000V, Z7000VA, Z70A, Z70N, Z70NE, Z70V, Z70VA, Z71, ASUS [Z7100](#) Laptop Battery, Z7100A, Z7100N, Z7100NE, Z7100V, Z7100Vp, Z71A, Z71N, Z71NE, Z71V, Z71Vp, Z8050CA 1B, Z84, Z84F, Z84FM, Z84JC, Z84JP, Z84JV, Z91, Z91 Series, Z9100, Z9100 Series, Z9100E, Z9100ER, Z9100G, Z9100L, Z9100N, Z91E, Z91ER, Z91G, ASUS [Z91L](#) Laptop Battery, Z91N, Z92 Series, Z9200Vc, Z92J, Z92Jc, Z92R, Z92T, Z92V, Z92Vc, Z92Vm, Z94, Z94, Z9400, Z9400RP, Z9400RP, Z94L, Z94L, Z94RP, Z94RP, Z96, Z96, Z96 Series, ASUS [Z96AR](#) Laptop Battery, Z96F, Z96FM, Z96H, Z96HM, Z96J, Z96J,

Z96JF, Z96JH, Z96JM, ASUS [Z96JP](#) Laptop Battery, Z96JS, Z96S, Z96SP, Z97, Z97 series, Z97V, Z99, Z99 Series, ASUS [Z99DC](#) Laptop Battery, Z99E, Z99Fm, Z99H, Z99HE, Z99J, Z99JA, Z99Jc, Z99JE, Z99JM, Z99Jn, Z99Jr, Z99LE, Z99M, Z99N, Z99Sc, Z99SE, Z99SG, Z99SR, Z99TC, Z9T, zen ux21e/08v, ZenBook 13 U3300FN, ZenBook 13 UX331U, Zenbook 13 UX331UA, Zenbook 13 UX331UA-EG013T, Zenbook 13 UX331UAEG013T, Zenbook 13 UX331UN, ZenBook 13 UX331UN-EG002T, Zenbook 13 UX331UN-EG006T, Zenbook 13 UX331UN-EG008T, ASUS [ZenBook 13 UX331UN-EG119T](#) Laptop Battery, ZenBook 13 UX331UNEG002T, Zenbook 13 UX331UNEG006T, Zenbook 13 UX331UNEG008T, ZenBook 13 UX331UNEG119T, ZenBook 13 UX333, Zenbook 13 UX333FA, ZenBook 13 UX333FN, ZenBook 13 UX334FL, Zenbook 14 UX431FA, ZenBook 14 UX431FA-AM018R, Zenbook 14 UX431FA-AM018T, ZenBook 14 UX431FA-AM020T, ZenBook 14 UX431FA-AM021T, ZenBook 14 UX431FA-AM022R, ZenBook 14 UX431FA-AM022T, ZenBook 14 UX431FA-AM025T, Zenbook 14 UX431FA-AM033T, Zenbook 14 UX431FA-AM043T, ZenBook 14 UX431FA-AM055T, ZenBook 14 UX431FA-AM853T, Zenbook 14 UX431FA-AN001T, Zenbook 14 UX431FA-AN004T, ZenBook 14 UX431FA-AN006T, Zenbook 14 UX431FA-AN012T, ZenBook 14 UX431FA-AN013T, Zenbook 14 UX431FA-AN015R, ZenBook 14 UX431FA-AN016T, ZenBook 14 UX431FA-AN051, ZenBook 14 UX431FL-AN002T, ZenBook 14 UX431FL-AN012T, ZENBOOK 14 UX431FL-AN018T, Zenbook 14 UX431FN, Zenbook 14 UX431FN-AN002T, ZenBook 14 UX433, ZenBook 14 UX433F, ZenBook 14 UX433FA, ZenBook 14 UX433FA-A5045R, ZenBook 14 UX433FA-A5045T, ZenBook 14 UX433FA-A5046R, ZenBook 14 UX433FA-A5047R, ZenBook 14 UX433FA-A5054T, ZenBook 14 UX433FA-A5070T, ZenBook 14 UX433FA-A5082T, ZenBook 14 UX433FA-A5090T, ZenBook 14 UX433FA-A5104R, ZenBook 14 UX433FA-A5128T, ZenBook 14 UX433FA-A5133T, ZenBook 14 UX433FA-A5143T, ZenBook 14 UX433FA-A5155R, ZenBook 14 UX433FA-A5155T, ASUS [ZenBook 14 UX433FA-A5156T](#) Laptop Battery, ZenBook 14 UX433FA-A5187R, ZenBook 14 UX433FA-A5188R, ZenBook 14 UX433FA-A5854T, ZenBook 14 UX433FA-A5941T, Zenbook 14 UX433FA-A6018T, ZenBook 14 UX433FA-A6019R, ZenBook 14 UX433FA-A6024T, ZenBook 14 UX433FA-A6025T, ZenBook 14 UX433FA-A6043T, ZenBook 14 UX433FA-A6101T, ZenBook 14 UX433FA-A6102T, ZenBook 14 UX433FA-A6116T, ZenBook 14 UX433FA-A6148R, ZenBook 14 UX433FA-A6688T, ZenBook 14 UX433FA-DH74, ZenBook 14 UX433FA-XH54, Zenbook 14 UX433FN, Zenbook 14 UX433FN-A5001T, ZENBOOK 14 UX433FN-A5021R, ZENBOOK 14 UX433FN-A5021T, ZENBOOK 14 UX433FN-A5028TS, ZENBOOK 14 UX433FN-A5037T, ZENBOOK 14 UX433FN-A5042T, ZENBOOK 14 UX433FN-A5044T, Zenbook 14 UX433FN-A5048T, Zenbook 14 UX433FN-A5050T, ZENBOOK 14 UX433FN-A5072T, ZENBOOK 14 UX433FN-A5079T, ZENBOOK 14 UX433FN-A5080T, ZENBOOK 14 UX433FN-A5084T, ZENBOOK 14 UX433FN-A5085T, ZENBOOK 14 UX433FN-A5104R, Zenbook 14 UX433FN-A5104T, ZENBOOK 14 UX433FN-A5110R, Zenbook 14 UX433FN-A6014T, Zenbook 14 UX433FN-A6023T, Zenbook 14 UX433FN-A6024T, ZENBOOK 14 UX433FN-A6032T, Zenbook 14 UX433FN-A6034T, ZENBOOK 14 UX433FN-A6039T, ZENBOOK 14 UX433FN-A6052T, Zenbook 14 UX433FN-A6074T, ZENBOOK 14 UX433FN-A6090T, Zenbook 14 UX433FN-A6094T, ZENBOOK 14 UX433FN-A6096T, ASUS [Zenbook 14 UX433FN-A6106T](#) Laptop Battery, ZENBOOK 14 UX433FN-A6108T, ZENBOOK 14 UX433FN-A6113T, ZENBOOK 14 UX433FN-A6123T, ZENBOOK 14 UX433FN-A6125T, ASUS [ZENBOOK 14 UX433FN-A6145T](#) Laptop Battery, ZENBOOK 14 UX433FN-A6157T, Zenbook 14 UX433FN-A6532T, Zenbook 14 UX433FN-A6782T, ZENBOOK 14 UX433FN-BP8201T, ZENBOOK 14 UX433FN-BP8505T, ASUS [ZenBook 14 UX434](#) Laptop Battery, ZenBook 14 UX434FL, ZenBook 15, ZenBook 15 UX533, ZenBook 15 UX533FD, Zenbook 15 UX533FD-0042B8565U, Zenbook 15 UX533FD-0052B8265U, Zenbook 15 UX533FD-A7601T, Zenbook 15 UX533FD-A8046T, ZenBook 15 UX533FD-A8047T, ZenBook 15 UX533FD-A8067T, ZenBook 15 UX533FD-A8068T,

ZenBook 15 UX533FD-A8089T, Zenbook 15 UX533FD-A8102T, Zenbook 15 UX533FD-A8105R, ZenBook 15 UX533FD-A8107T, ZenBook 15 UX533FD-A8109R, ZenBook 15 UX533FD-A8112T, ZenBook 15 UX533FD-A8136R, Zenbook 15 UX533FD-A9027T, ZenBook 15 UX533FD-A9028T, ASUS [Zenbook 15 UX533FD-A9030T](#) Laptop Battery, Zenbook 15 UX533FD-A9082T, ZenBook 15 UX533FD-A9083T, ZenBook 15 UX533FD-A9094T, ZenBook 15 UX533FD-A9100T, ZenBook 15 UX533FD-BP8505T, ZenBook 15 UX533FD-DH74, Zenbook 15 UX533FN, Zenbook 15 UX533FN-A8021T, ZENBOOK 15 UX534FA, ZENBOOK 15 UX534FA-A8038T, ZENBOOK 15 UX534FA-AA008T, ZENBOOK 15 UX534FT, ZENBOOK 15 UX534FT-A9014T, ZENBOOK 15 UX534FT-AA044R, ZENBOOK 15 UX534FT-DB77, ZenBook 15 UX534FTC, ZenBook 15 UX534FTC-A8078R, ZenBook 15 UX534FTC-A8110T, ZenBook 15 UX534FTC-A8125T, ZenBook 15 UX534FTC-A8145T, ZenBook 15 UX534FTC-A8184R, ZenBook 15 UX534FTC-A8210T, ZenBook 15 UX534FTC-AA052T, ZenBook 15 UX534FTC-AA064R, Zenbook 15 UX534FTC-AA092R, ZenBook 15 UX534FTC-AA249T, ZenBook 15 UX534FTC-BH74, ZenBook 15 UX534FTC-XH77, Zenbook 3, ZENBOOK 3 DELUXE UX3490UA, ZENBOOK 3 DELUXE UX3490UA-7R8512, ZENBOOK 3 DELUXE UX3490UA-BE011T, ZENBOOK 3 DELUXE UX3490UA-BE020T, ZENBOOK 3 DELUXE UX3490UA-BE025R, ZENBOOK 3 DELUXE UX3490UA-BE025T, ZENBOOK 3 DELUXE UX3490UA-BE027T, ZENBOOK 3 DELUXE UX3490UA-BE028T, ZENBOOK 3 DELUXE UX3490UA-BE041T, ZENBOOK 3 DELUXE UX3490UA-BE081R, ZENBOOK 3 DELUXE UX3490UA-BE133T, ZenBook 3 Deluxe UX490 Series, ZenBook 3 Deluxe UX490U Series, ASUS [ZenBook 3 Deluxe UX490UA Series](#) Laptop Battery, ZenBook 3 Deluxe UX490UA-BE009T, ZenBook 3 Deluxe UX490UA-BE023T, ZenBook 3 Deluxe UX490UA-BE032R, ZenBook 3 Deluxe UX490UA-BE048T, ZenBook 3 Deluxe UX490UA-BE049R, ZenBook 3 Deluxe UX490UA-BE053R, ZenBook 3 UX390, Zenbook 3 UX390UA-GS041T, Zenbook 3 UX390UAGS041T, ZenBook Edition 30 UX334FL, ZenBook Flip 13 UX362, ZenBook Flip 13 UX362FA, ZenBook Flip 14, ZenBook Flip 14 UM462DA, ZenBook Flip 14 UM462DA-AI012T, Zenbook Flip 14 UM462DA-AI014T, Zenbook Flip 14 UM462DA-AI015T, Zenbook Flip 14 UM462DA-AI022T, ZenBook Flip 14 UM462DA-AI023T, Zenbook Flip 14 UM462DA-AI024T, Zenbook Flip 14 UM462DA-AI027T, Zenbook Flip 14 UM462DA-AI028T, ASUS [ZenBook Flip 14 UM462DA-AI030R](#) Laptop Battery, ZenBook Flip 14 UM462DA-AI030T, ZENBOOK FLIP 14 UM462DA-AI031T, ZenBook Flip 14 UM462DA-AI033T, ZenBook Flip 14 UM462DA-AI035R, ZenBook Flip 14 UM462DA-AI037T, Zenbook Flip 14 UM462DA-AI038T, Zenbook Flip 14 UM462DA-AI046T, ZenBook Flip 14 UM462DA-AI047T, ZENBOOK FLIP 14 UM462DA-AI048T, ZenBook Flip 14 UM462DA-AI053T, ZenBook Flip 14 UM462DA-AI071T, ZenBook Flip 14 UM462DA-AI084T, Zenbook Flip 14 UM462DA-AI091T, ZenBook Flip 14 UM462DA-AI093R, ZENBOOK FLIP 14 UM462DA-AI501TS, Zenbook Flip 14 UM462DA-AM045T, ZenBook Flip 14 UX461, Zenbook Flip 14 UX461FA, Zenbook Flip 14 UX461FA-E1094T, ZenBook Flip 14 UX461FN, ZenBook Flip 14 UX461FN-DH74T, ZENBOOK FLIP 14 UX461FN-E1029T, ZenBook Flip 14 UX461FN-E1053T, ZenBook Flip 14 UX461FN-E1068T, ZenBook Flip 14 UX461UA, ZenBook Flip 14 UX461UA-E1022T, ZenBook Flip 14 UX461UA-E1072T, ZenBook Flip 14 UX461UA-E1077T, ZenBook Flip 14 UX461UA-M00540, ZenBook Flip 14 UX461UAE1022T, ZenBook Flip 14 UX461UAE1077T, ZenBook Flip 14 UX461UAM00540, ZenBook Flip 14 UX461UN-DS74T, ZenBook Flip 14 UX461UN-E1007T, ZenBook Flip 14 UX461UN-PRO, Zenbook Flip 14 UX462DA, ZenBook Flip 14 UX462DA-AI016T, Zenbook Flip 14 UX462DA-AI022T, Zenbook Flip 14 UX462DA-AI040T, ZenBook Flip 14 UX463FA, Zenbook Flip 14 UX463FA-AI011TB, ZenBook Flip 14 UX463FA-AI027T, ASUS [ZenBook Flip 14 UX463FA-AI032R](#) Laptop Battery, ZenBook Flip 14 UX463FL, ZenBook Flip 14 UX463FL-AI055R, ZenBook Flip 14 UX463FL-AI057T, ZenBook Flip 14 UX463FL-AI073R, ZenBook Flip 14 UX463FL-AI075R, ZenBook Flip 15, ZenBook Flip 15 UX561UD,

ZenBook Flip 15 UX562, ZenBook Flip 15 UX562FA, ZenBook Flip 15 UX562FA-AC025R, ZenBook Flip 15 UX562FA-AC033T, ZenBook Flip 15 UX562FA-AC034T, ZenBook Flip 15 UX562FA-AC040T, ASUS [ZenBook Flip 15 UX562FD](#) Laptop Battery, Zenbook Flip 15 UX562FD-A1003T, ZenBook Flip 15 UX562FD-A1004T, ZenBook Flip 15 UX562FD-A1011T, ZENBOOK FLIP 15 UX562FD-EZ077T, ZENBOOK FLIP 15 UX562FD-EZ078T, ZENBOOK FLIP 15 UX562FD-EZ081T, ZENBOOK FLIP 15 UX562FDX, ZenBook Flip 15 UX562FN, ZenBook Flip 15 UX563FD-A1015T, ZenBook Flip 15 UX563FD-A1025R, ZenBook Flip 15 UX563FD-A1027T, ZenBook Flip 15 UX563FD-A1045T, ZenBook Flip 15 UX563FD-EZ043T, ZenBook Flip 15 UX563FD-EZ050T, ZenBook Flip 15 UX563FD-EZ056T, ZenBook Flip 15 UX563FD-EZ057T, ZenBook Flip S UX370U, ZenBook Flip S UX370UA, ZenBook Flip S UX370UA-C4061T, ZenBook Flip S UX370UA-C4072T, ZenBook Flip S UX370UA-C4093T, ASUS [ZenBook Flip S UX370UA-C4104T](#) Laptop Battery, ZenBook Flip S UX370UA-C4129T, ZenBook Flip S UX370UA-C4137T, ZenBook Flip S UX370UA-C4198T, ZenBook Flip S UX370UA-C4201T, ZenBook Flip S UX370UA-C4202T, ZenBook Flip S UX370UA-C4219T, ZenBook Flip S UX370UA-C4220T, ZenBook Flip S UX370UA-C4221T, ZenBook Flip S UX370UA-C4222T, ZenBook Flip S UX370UA-C4227T, ZenBook Flip S UX370UA-XB74T-BL, ZenBook Flip S UX370UA-XH74T-BL, ASUS [ZenBook Flip UX360](#) Laptop Battery, ZenBook Flip UX360CA, ZenBook Flip UX360CA-C4008T, ZenBook Flip UX360CA-C4018T, ZenBook Flip UX360CA-C4019T, ZenBook Flip UX360CA-C4020T, ZenBook Flip UX360CA-C4021T, ZenBook Flip UX360CA-C4028T, ZenBook Flip UX360CA-C4179T, ZenBook Flip UX360CA-C4181T, ZenBook Flip UX360CA-C4183T, ZenBook Flip UX360CA-C4184T, ZenBook Flip UX360CA-C4215T, ASUS [ZenBook Flip UX360CA-C4227T](#) Laptop Battery, ZenBook Flip UX360CA-C4231T, ZenBook Flip UX360CA-C4232T, ZenBook Flip UX360CA-DQ198T, ZenBook Flip UX360CA-DQ230T, ZenBook Flip UX360CAC4008T, Zenbook Flip UX360UA-1A, Zenbook Flip UX360UA-C4010T, Zenbook Flip UX360UA-C4026T, Zenbook Flip UX360UA-C4122T, Zenbook Flip UX360UA-C4154T, ASUS [Zenbook Flip UX360UA-C4159T](#) Laptop Battery, Zenbook Flip UX360UA-C4160T, Zenbook Flip UX360UA-C4164T, Zenbook Flip UX360UA-DQ119T, Zenbook Flip UX360UAC4010T, Zenbook Flip UX360UAC4026T, Zenbook Flip UX360UAC4122T, Zenbook Flip UX360UAC4154T, Zenbook Flip UX360UAC4159T, Zenbook Flip UX360UAC4160T, Zenbook Flip UX360UAC4164T, Zenbook Flip UX360UADQ119T, Zenbook Flip UX360UAK-BB283T, Zenbook Flip UX360UAK-BB284T, Zenbook Flip UX360UAK-BB285T, Zenbook Flip UX360UAK-BB295T, Zenbook Flip UX360UAK-BB351T, Zenbook Flip UX360UAK-BB352T, ASUS [Zenbook Flip UX360UAK-BB354T](#) Laptop Battery, Zenbook Flip UX360UAK-BB356T, Zenbook Flip UX360UAK-BB415T, Zenbook Flip UX360UAK-C4203T, Zenbook Flip UX360UAK-C4221T, Zenbook Flip UX360UAKBB283T, Zenbook Flip UX360UAKBB284T, Zenbook Flip UX360UAKBB285T, Zenbook Flip UX360UAKBB295T, Zenbook Flip UX360UAKBB351T, Zenbook Flip UX360UAKBB352T, Zenbook Flip UX360UAKBB354T, Zenbook Flip UX360UAKBB356T, Zenbook Flip UX360UAKBB415T, Zenbook Flip UX360UAKC4203T, Zenbook Flip UX360UAKC4221T, Zenbook Flip UX362, ZenBook Flip UX362FA, Zenbook Flip UX390UA, ZenBook Flip UX461UA-DS51T, ZenBook Flip UX461UA-E1009T, ZenBook Flip UX461UA-E1012R, ZenBook Flip UX461UA-E1012T, ZenBook Flip UX461UA-E1013T, ZenBook Flip UX461UA-E1014T, ZenBook Flip UX461UA-E1017R, ZenBook Flip UX461UA-E1020T, ZenBook Flip UX461UA-E1022T, ZenBook Flip UX461UA-E1029T, ZenBook Flip UX461UA-E1030T, ZenBook Flip UX461UA-E1087R, ZenBook Flip UX461UA-E1087T, ZenBook Flip UX461UA-E1091T, ZenBook Flip UX461UA-E1102T, ZenBook Flip UX461UA-E1108T, ZenBook Flip UX461UA-E1117T, ZenBook Flip UX461UA-E1126T, ZenBook Flip UX461UA-E1127T, ZenBook Flip UX461UA-E1147T, ZenBook Flip UX461UA-E1155T, ZenBook Flip UX461UA-E1174T, ZenBook Flip UX461UA-E1179, ZenBook Flip UX461UA-IB74T, ZenBook Flip UX461UA-

Q52SP-CB, ZenBook Flip UX461UAE1012R, ZenBook Flip UX461UAE1091T, ZenBook Flip UX461UN-BO702T, ZenBook Flip UX461UN-BO703T, ZenBook Flip UX461UN-E1006T, ZenBook Flip UX461UN-E1008T, ZenBook Flip UX461UN-E1016T, ZenBook Flip UX461UN-E1020T, ZenBook Flip UX461UN-E1021T, ZenBook Flip UX461UN-E1022T, ZenBook Flip UX461UN-E1026T, ASUS [ZenBook Flip UX461UN-E1030R](#) Laptop Battery, ZenBook Flip UX461UN-E1031T, ZenBook Flip UX461UN-E1033T, ZenBook Flip UX461UN-E1042R, ZenBook Flip UX461UN-E1044T, ZenBook Flip UX461UN-E1051T, Zenbook Flip UX560, ZenBook Flip UX560UA, ZenBook Flip UX560UA-FZ014T, ZenBook Flip UX560UA-FZ015T, ZenBook Flip UX560UA-FZ016T, ZenBook Flip UX560UA-FZ017T, ZenBook Flip UX560UA-FZ018T, ZenBook Flip UX560UA-FZ019T, ZenBook Flip UX560UA-FZ020T, ZenBook Flip UX560UA-FZ021T, ZenBook Flip UX560UQ, ZenBook Flip UX560UQ-FZ018R, ZenBook Flip UX560UQ-FZ033T, ZenBook Flip UX560UX, ZenBook Flip UX560UX-FJ020R, ZenBook Flip UX560UX-FZ017T, ZenBook Flip UX560UX-FZ021T, ZenBook Flip UX560UX-FZ022T, ZenBook Flip UX560UX-FZ025T, Zenbook Flip UX561UA, ZenBook Flip UX561UA-BO003T, ZenBook Flip UX561UABO003T, ZenBook Flip UX561UD, ZenBook Flip UX561UD-BO027R, ZenBook Flip UX561UD-E2019T, ZenBook Flip UX561UD-E2026R, ASUS [ZenBook Flip UX561UN](#) Laptop Battery, ZenBook Flip UX561UN-BO006T, ZenBook Flip UX561UN-BO011T, ZenBook Flip UX561UN-BO012T, ZenBook Flip UX561UNBO006T, ZenBook Flip UX561UNBO011T, ZenBook Flip UX561UNBO012T, Zenbook Infinity UX301LA, Zenbook Infinity UX301LA Ultrabook, Zenbook NX500 Series, ZenBook NX500J, ZenBook NX500JK, Zenbook NX500JK-DR018H, Zenbook NX500JKDR018H, Zenbook Prime UX301LA, Zenbook Prime UX32A, ZenBook Pro 14 UX450, ZenBook Pro 14 UX450F, ZenBook Pro 14 UX450FD, ZenBook Pro 14 UX480, ZenBook Pro 14 UX480F, ZenBook Pro 14 UX480FD, ZenBook Pro 15 UX550GD, ZenBook Pro 15 UX550GD-BN007R, ZenBook Pro 15 UX550GD-BN011T, ZenBook Pro 15 UX550GD-BN017R, ZenBook Pro 15 UX550GD-BN017T, ZenBook Pro 15 UX550GD-BN018R, ASUS [ZenBook Pro 15 UX550GD-BN019R](#) Laptop Battery, ZenBook Pro 15 UX550GD-BN019T, ASUS [ZenBook Pro 15 UX550GD-BN023T](#) Laptop Battery, ZenBook Pro 15 UX550GD-BN025T, ZenBook Pro 15 UX550GD-BN027T, ZenBook Pro 15 UX550GD-BN038R, ZenBook Pro 15 UX550GD-BN048R, ZenBook Pro 15 UX550GD-E2040T, ZenBook Pro 15 UX550GD-E2041T, ZenBook Pro 15 UX550GDBN007R, ZenBook Pro 15 UX550GDBN011T, ZenBook Pro 15 UX550GDBN017R, ZenBook Pro 15 UX550GDBN017T, ZenBook Pro 15 UX550GDBN018R, ZenBook Pro 15 UX550GDBN019R, ZenBook Pro 15 UX550GDBN019T, ZenBook Pro 15 UX550GDBN023T, ZenBook Pro 15 UX550GDBN025T, ZenBook Pro 15 UX550GDBN027T, ZenBook Pro 15 UX550GDBN038R, ZenBook Pro 15 UX550GDBN048R, ZenBook Pro 15 UX550GDE2040T, ZenBook Pro 15 UX550GDE2041T, ZenBook Pro 15 UX550GE, ZenBook Pro 15 UX550GE-78DT5AB1, ZenBook Pro 15 UX550GE-78DT5AB2, ZenBook Pro 15 UX550GE-BN001R, ZenBook Pro 15 UX550GE-BN005R, ZenBook Pro 15 UX550GE-BN005T, ZenBook Pro 15 UX550GE-BN015T, ASUS [ZenBook Pro 15 UX550GE-BN022T](#) Laptop Battery, ZenBook Pro 15 UX550GE-BN024R, ZenBook Pro 15 UX550GE-BN026R, ZenBook Pro 15 UX550GE-E2004R, ZenBook Pro 15 UX550GE-E2019T, ZenBook Pro 15 UX550GE-E2037T, ZenBook Pro 15 UX550GE-E2040T, ZenBook Pro 15 UX550GE-XB71T, ZenBook Pro 15 UX550GE78DT5AB1, ZenBook Pro 15 UX550GE78DT5AB2, ZenBook Pro 15 UX550GEBN001R, ZenBook Pro 15 UX550GEBN005R, ZenBook Pro 15 UX550GEBN005T, ZenBook Pro 15 UX550GEBN015T, ZenBook Pro 15 UX550GEBN022T, ZenBook Pro 15 UX550GEBN024R, ZenBook Pro 15 UX550GEBN026R, ZenBook Pro 15 UX550GEE2004R, ZenBook Pro 15 UX550GEE2019T, ZenBook Pro 15 UX550GEE2037T, ZenBook Pro 15 UX550GEE2040T, ZenBook Pro 15 UX550GEXB71T, ASUS [ZenBook Pro 15 UX580](#) Laptop Battery, ZenBook Pro 15 UX580G, ZenBook Pro 15 UX580GD, ASUS [ZenBook Pro 15](#)

[UX580GE](#) Laptop Battery, Zenbook Pro BX510UX, Zenbook Pro U5500, ASUS [ZenBook Pro UX450](#) Laptop Battery, ZenBook Pro UX450F, ZenBook Pro UX450FD, ZenBook Pro UX480, ZenBook Pro UX480F, ZenBook Pro UX480FD, ZenBook Pro UX501, ZenBook Pro UX501JW-4720, ZenBook Pro UX501JW4720, Zenbook Pro UX501VW, Zenbook Pro UX501VW-DS71T, Zenbook Pro UX501VW-FJ044T, Zenbook Pro UX501VW-FJ098T, Zenbook Pro UX501VWDS71T, Zenbook Pro UX501VWFJ044T, Zenbook Pro UX501VWFJ098T, ZenBook Pro UX550, Zenbook Pro UX550VD, Zenbook Pro UX550VD-BN007R, Zenbook Pro UX550VD-BN009T, Zenbook Pro UX550VD-BN010T, Zenbook Pro UX550VD-BN014R, Zenbook Pro UX550VD-BN020T, Zenbook Pro UX550VD-BN032T, Zenbook Pro UX550VD-BN045T, Zenbook Pro UX550VD-BN068T, Zenbook Pro UX550VD-BN078R, Zenbook Pro UX550VD-BN081R, Zenbook Pro UX550VD-BN081T, Zenbook Pro UX550VD-BN082R, Zenbook Pro UX550VD-BN082T, Zenbook Pro UX550VD-BN084R, Zenbook Pro UX550VD-BN094T, Zenbook Pro UX550VD-BN102T, Zenbook Pro UX550VD-BN120T, Zenbook Pro UX550VD-BN152T, Zenbook Pro UX550VD-BN157T, Zenbook Pro UX550VD-BN169R, Zenbook Pro UX550VD-BN205T, Zenbook Pro UX550VD-BN246T, Zenbook Pro UX550VD-BN247T, Zenbook Pro UX550VD-BO005R, Zenbook Pro UX550VD-BO023T, Zenbook Pro UX550VD-BO039T, Zenbook Pro UX550VD-BO098R, Zenbook Pro UX550VD-BO098T, Zenbook Pro UX550VD-BO116T, Zenbook Pro UX550VD-BO165T, Zenbook Pro UX550VD-BO701T, Zenbook Pro UX550VD-E2115T, Zenbook Pro UX550VD-E2147T, Zenbook Pro UX550VD-E2167T, Zenbook Pro UX550VD-E3109T, Zenbook Pro UX550VD-E3153T, Zenbook Pro UX550VD-E3156T, Zenbook Pro UX550VD-E3180T, Zenbook Pro UX550VD-E3208T, Zenbook Pro UX550VD-E3244T, Zenbook Pro UX550VD-E3248T, ZenBook Pro UX550VE, ASUS [ZenBook Pro UX550VE-bn007R](#) Laptop Battery, ZenBook Pro UX550VE-bn013T, ZenBook Pro UX550VE-bn014T, ZenBook Pro UX550VE-bn016R, ZenBook Pro UX550VE-bn016T, ZenBook Pro UX550VE-bn020T, ZenBook Pro UX550VE-bn022T, ZenBook Pro UX550VE-BN050T, ZenBook Pro UX550VE-bn070T, ZenBook Pro UX550VE-bn105R, ZenBook Pro UX550VE-bn106T, ASUS [ZenBook Pro UX550VE-bn109R](#) Laptop Battery, ZenBook Pro UX550VE-bn114T, ZenBook Pro UX550VE-bn121T, ZenBook Pro UX550VE-bn142T, ZenBook Pro UX550VE-bn148R, ZenBook Pro UX550VE-BO006T, ZenBook Pro UX550VE-BO026T, ASUS [ZenBook Pro UX550VE-BO030T](#) Laptop Battery, ASUS [ZenBook Pro UX550VE-BO031T](#) Laptop Battery, ZenBook Pro UX550VE-BO060T, ZenBook Pro UX550VE-BO099T, ZenBook Pro UX550VE-BO101R, ZenBook Pro UX550VE-BO104T, ZenBook Pro UX550VE-BO149R, ZenBook Pro UX550VE-BO150R, ZenBook Pro UX550VE-DB71T, ZenBook Pro UX550VE-E2064T, ZenBook Pro UX550VE-E3061T, ZenBook Pro UX550VE-E3079T, ZenBook Pro UX550VE-E3081T, ZenBook Pro UX550VE-E3094T, ZenBook Pro UX550VE-E3130T, ZenBook Pro UX550VE-E3159T, ZenBook Pro UX550VE-XH71, ZenBook Pro UX580, ZenBook Pro UX580G, ZenBook Pro UX580GD, ZenBook Pro UX580GE, ZenBook S UX391, ZenBook S UX391U, ZenBook S UX391UA, ZenBook S UX391UA-EG007T, ZenBook S UX391UA-EG019T, ZenBook S UX391UA-EG022T, ZenBook S UX391UA-EG023T, ZenBook S UX391UA-EG026T, ZenBook S UX391UA-EG031T, ASUS [ZenBook S UX391UA-EG047T](#) Laptop Battery, ZenBook S UX391UA-EG057T, ZenBook S UX391UA-EG060T, ZenBook S UX391UA-EG062T, ZenBook S UX391UA-EG064T, ZenBook S13 UX392, ZenBook S13 UX392FN, ZenBook S13 UX392FN-0032B8565U, ZenBook S13 UX392FN-0042B8265U, ZenBook S13 UX392FN-8565, ZenBook S13 UX392FN-AB003T, ASUS [ZenBook S13 UX392FN-AB003TS](#) Laptop Battery, ZenBook S13 UX392FN-AB006R, ZenBook S13 UX392FN-AB006T, ZenBook S13 UX392FN-AB009T, ZenBook S13 UX392FN-E7601T, ZenBook S13 UX392FN-SP8509T, ZenBook S13 UX392FN-XS71, ZenBook S13 UX392FN-XS77, ZenBook S13UX392FN-0042B8265U, ZENBOOK SERIES, Zenbook U303LA, Zenbook U303LN, ZenBook U305, ZenBook U305 Series, Zenbook U305CA6Y54, ZENBOOK U305FA, ZENBOOK U305FA5Y71, Zenbook U305UA, Zenbook U305UA6200, ASUS [Zenbook U433FN](#) Laptop Battery, Zenbook U500VZ,

ZENBOOK UX SERIES, Zenbook UX21, ZenBook UX21 Series, ZenBook UX21A Series, Zenbook UX21E, ASUS [ZenBook UX21E Series](#) Laptop Battery, Zenbook UX301, Zenbook UX301L, Zenbook UX301LA, Zenbook UX301LA4500, ZenBook UX302LA, ZenBook UX302LA-BHI5T08, ZenBook UX302LABHI5T08, Zenbook UX302LG, Zenbook UX303, ZenBook UX303L Series, Zenbook UX303LA, ZenBook UX303LA Series, Zenbook UX303LN, ZenBook UX303LN Series, ZenBook UX303UB, ASUS [Zenbook UX303UB-DH74T](#) Laptop Battery, Zenbook UX305, Zenbook UX305CA, Zenbook UX305CA (M-6Y30), ZenBook UX305CA M-6Y30, ZenBook UX305CA M3-6Y30, ASUS [Zenbook UX305CA-DHM4T](#) Laptop Battery, Zenbook UX305CA-EHM1, ZenBook UX305CA-FB006T, Zenbook UX305CA-FB031T, ZenBook UX305CA-FB052T, Zenbook UX305CA-FB055T, ASUS [ZenBook UX305CA-FB070T](#) Laptop Battery, Zenbook UX305CA-FB073T, ZenBook UX305CA-FB126T, ZenBook UX305CA-FB219T, Zenbook UX305CA-FC004T, Zenbook UX305CA-FC022T, ZenBook UX305CA-FC026T, Zenbook UX305CA-FC037T, Zenbook UX305CA-FC042T, Zenbook UX305CA-FC074R, Zenbook UX305CA-FC093T, ZenBook UX305CA-FC094T, ZenBook UX305CA-FC106T, ZenBook UX305CA-FC157T, Zenbook UX305CA-FC167T, ZenBook UX305CA-FC187T, ZenBook UX305CA-FC208T, ZenBook UX305CA-SHMQ1-CB, Zenbook UX305FA, ZenBook UX305FA-1A, ZenBook UX305FA-1B, ZenBook UX305FA-1C, ZenBook UX305FA-2A, Zenbook UX305FA-FB003H, Zenbook UX305FA-FB003T, Zenbook UX305FA-FB006H, Zenbook UX305FA-FB006T, Zenbook UX305FA-FB012H, Zenbook UX305FA-FB033H, Zenbook UX305FA-FB126H, ASUS [Zenbook UX305FA-FB128H](#) Laptop Battery, Zenbook UX305FA-FB128T, Zenbook UX305FA-FB142H, Zenbook UX305FA-FB186H, Zenbook UX305FA-FB191H, Zenbook UX305FA-FB192T, Zenbook UX305FA-FC002H, Zenbook UX305FA-FC004H, Zenbook UX305FA-FC004T, ZenBook UX305FA-FC005T, Zenbook UX305FA-FC008H, Zenbook UX305FA-FC014H, ZenBook UX305FA-FC066P, Zenbook UX305FA-FC158T, Zenbook UX305FA-FC159T, Zenbook UX305FA-FC190H, Zenbook UX305FA-FC225T, Zenbook UX305FA-FC284T, Zenbook UX305LA, Zenbook UX305LA-FB011T, Zenbook UX305LA-FC012H, Zenbook UX305LA-FC012T, Zenbook UX305LA-FC013T, Zenbook UX305LA-FC017T, Zenbook UX305LA-FC044T, Zenbook UX305LAFB011T, Zenbook UX305LAFB012H, Zenbook UX305LAFB012T, Zenbook UX305LAFB013T, Zenbook UX305LAFB017T, Zenbook UX305LAFB044T, Zenbook UX305UA, Zenbook UX305UA-FB004T, Zenbook UX305UA-FB011R, Zenbook UX305UA-FB019T, Zenbook UX305UA-FC001T, Zenbook UX305UA-FC002R, Zenbook UX305UA-FC002T, Zenbook UX305UA-FC006T, Zenbook UX305UA-FC010T, ASUS [Zenbook UX305UAFB004T](#) Laptop Battery, Zenbook UX305UAFB011R, Zenbook UX305UAFB019T, Zenbook UX305UAFB001T, Zenbook UX305UAFB002R, Zenbook UX305UAFB002T, Zenbook UX305UAFB006T, Zenbook UX305UAFB010T, ZENBOOK UX31, ZENBOOK UX31 Series, Zenbook UX310UA, Zenbook UX310UA-FB025T, ZenBook UX310UA-FB097T, Zenbook UX310UA-FB1103, Zenbook UX310UA-FB216R, Zenbook UX310UA-FB404T, Zenbook UX310UA-FB407T, Zenbook UX310UA-FB408T, Zenbook UX310UA-FB485, Zenbook UX310UA-FB485T, Zenbook UX310UA-FB763T, Zenbook UX310UA-FB818T, Zenbook UX310UA-FB828T, Zenbook UX310UA-FB840T, ASUS [Zenbook UX310UA-FB859T](#) Laptop Battery, Zenbook UX310UA-FC039T, Zenbook UX310UA-FC042T, Zenbook UX310UA-FC044T, Zenbook UX310UA-FC051T, ZenBook UX310UA-FC062T, Zenbook UX310UA-FC063T, Zenbook UX310UA-FC073T, ZenBook UX310UA-FC075T, Zenbook UX310UA-FC087T, Zenbook UX310UA-FC088T, Zenbook UX310UA-FC089T, Zenbook UX310UA-FC093T, Zenbook UX310UA-FC1008T, Zenbook UX310UA-FC1021T, Zenbook UX310UA-FC1023T, Zenbook UX310UA-FC1036T, ZenBook UX310UA-FC1040T, Zenbook UX310UA-FC114T, Zenbook UX310UA-FC137T, Zenbook UX310UA-FC138T, ZenBook UX310UA-FC144T, Zenbook UX310UA-FC208T, Zenbook UX310UA-FC211T, ASUS [Zenbook UX310UA-FC212T](#) Laptop Battery, Zenbook UX310UA-FC233T, Zenbook UX310UA-

FC255T, Zenbook UX310UA-FC289T, Zenbook UX310UA-FC330T, ZenBook UX310UA-FC331T, Zenbook UX310UA-FC336T, Zenbook UX310UA-FC337T, ZenBook UX310UA-FC338T, Zenbook UX310UA-FC339T, Zenbook UX310UA-FC341T, Zenbook UX310UA-FC344T, Zenbook UX310UA-FC347T, Zenbook UX310UA-FC348T, Zenbook UX310UA-FC435T, Zenbook UX310UA-FC468T, Zenbook UX310UA-FC488T, Zenbook UX310UA-FC555T, Zenbook UX310UA-FC589T, Zenbook UX310UA-FC593T, Zenbook UX310UA-FC598T, Zenbook UX310UA-FC605T, Zenbook UX310UA-FC630T, Zenbook UX310UA-FC647T, Zenbook UX310UA-FC662T, Zenbook UX310UA-FC684T, ASUS [Zenbook UX310UA-FC694T](#) Laptop Battery, Zenbook UX310UA-FC755T, Zenbook UX310UA-FC756T, ZenBook UX310UA-FC757T, ZenBook UX310UA-FC758T, Zenbook UX310UA-FC780T, Zenbook UX310UA-FC784T, Zenbook UX310UA-FC786T, Zenbook UX310UA-FC844T, Zenbook UX310UA-FC850T, ZenBook UX310UA-FC851T, Zenbook UX310UA-FC862T, Zenbook UX310UA-FC883T, Zenbook UX310UA-FC891T, Zenbook UX310UA-FC892T, Zenbook UX310UA-FC944T, Zenbook UX310UA-FC963, ZenBook UX310UA-FC973T, Zenbook UX310UA-FC976T, ZenBook UX310UA-FC977T, Zenbook UX310UA-FC990, Zenbook UX310UA-FC999R, Zenbook UX310UA-GL123T, Zenbook UX310UA-GL151T, Zenbook UX310UA-Q52S, ZenBook UX310UAFB097T, ZenBook UX310UAF062T, Zenbook UX310UAF073T, ZenBook UX310UAF075T, Zenbook UX310UAF087T, Zenbook UX310UAF088T, Zenbook UX310UAF089T, Zenbook UX310UAF114T, ASUS [Zenbook UX310UAF137T](#) Laptop Battery, Zenbook UX310UAF138T, Zenbook UX310UAF255T, ZenBook UX310UAF331T, Zenbook UX310UAF336T, Zenbook UX310UAF337T, Zenbook UX310UAF339T, Zenbook UX310UAF341T, Zenbook UX310UAF344T, Zenbook UX310UAF347T, Zenbook UX310UAF348T, Zenbook UX310UAF662T, Zenbook UX310UAF694T, Zenbook UX310UAF755T, Zenbook UX310UAF756T, Zenbook UX310UAF844T, Zenbook UX310UAF850T, Zenbook UX310UAF976T, Zenbook UX310UAGL123T, Zenbook UX310UAGL151T, ZenBook UX310UF, Zenbook UX310UF-FC004T, Zenbook UX310UF-FC005T, Zenbook UX310UF-FC007T, ASUS [Zenbook UX310UF-FC031T](#) Laptop Battery, Zenbook UX310UF-FC035R, Zenbook UX310UFFC004T, Zenbook UX310UFFC005T, Zenbook UX310UFFC007T, Zenbook UX310UFFC031T, Zenbook UX310UFFC035R, ZenBook UX310UQ, Zenbook UX310UQ-FB016T, Zenbook UX310UQ-FB047R, Zenbook UX310UQ-FB267T, Zenbook UX310UQ-FB276T, Zenbook UX310UQ-FB422T, Zenbook UX310UQ-FB451T, Zenbook UX310UQ-FB504T, Zenbook UX310UQ-FB532T, Zenbook UX310UQ-FB549T, Zenbook UX310UQ-FC133T, Zenbook UX310UQ-FC134T, Zenbook UX310UQ-FC146T, Zenbook UX310UQ-FC203T, Zenbook UX310UQ-FC286T, ASUS [Zenbook UX310UQ-FC337T](#) Laptop Battery, Zenbook UX310UQ-FC348T, Zenbook UX310UQ-FC368T, ZenBook UX310UQ-FC396T, Zenbook UX310UQ-FC421T, Zenbook UX310UQ-FC449T, Zenbook UX310UQ-FC475T, Zenbook UX310UQ-FC518T, Zenbook UX310UQ-FC531T, Zenbook UX310UQ-FC552T, Zenbook UX310UQ-FC559T, Zenbook UX310UQ-FC588T, ZenBook UX310UQ-GL011T, ZenBook UX310UQFC396T, ASUS [ZenBook UX310UQGL011T](#) Laptop Battery, ZenBook UX310UQK, Zenbook UX31A, Zenbook UX31A-C4027H, Zenbook UX31A-C4029H, Zenbook UX31A-C4032H, Zenbook UX31A-C4033H, Zenbook UX31A-R4002H, Zenbook UX31A-R4002V, Zenbook UX31A-R4003H, Zenbook UX31A-R4003P, Zenbook UX31A-R4003V, ASUS [Zenbook UX31A-R4003X](#) Laptop Battery, Zenbook UX31A-R4004H, Zenbook UX31A-R4004V, Zenbook UX31A-R4005H, Zenbook UX31A-R4005V, ZENBOOK UX31E, ZENBOOK UX31E Series, Zenbook UX31E-1A, Zenbook UX31E-1C, Zenbook UX31E-RY008V, Zenbook UX31E-RY009V, Zenbook UX31E-RY010V, Zenbook UX31E-RY012V, Zenbook UX31E-RY029V, ZENBOOK UX31LA, ZENBOOK UX31LA-US51T UX3Po, Zenbook UX32LA, Zenbook UX32LA-R3025H, Zenbook UX32LA-R3028H, Zenbook UX32LA-R3048H, Zenbook UX32LA-R3073P, Zenbook UX32LAR3025H, Zenbook UX32LAR3028H, Zenbook UX32LAR3048H,

Zenbook UX32LAR3073P, Zenbook UX32LN, Zenbook UX32LN-R4029H, ASUS [Zenbook UX32LN-R4029P](#) Laptop Battery, Zenbook UX32LN-R4052H, Zenbook UX32LN-R4053H, Zenbook UX32LN-R4086H, Zenbook UX32LNR4029H, Zenbook UX32LNR4029P, Zenbook UX32LNR4052H, Zenbook UX32LNR4053H, Zenbook UX32LNR4086H, Zenbook UX32VD, ZenBook UX330CA, ZenBook UX330CA-FC009T, ZenBook UX330CA-FC020T, ZenBook UX330CA-FC030T, ZenBook UX330CA-FC031T, ASUS [ZenBook UX330CA-FC055D](#) Laptop Battery, ZenBook UX330CAFC009T, ZenBook UX330CAFC020T, ZenBook UX330CAFC030T, ZenBook UX330CAFC031T, ZenBook UX330CAFC055D, Zenbook UX330UA, Zenbook UX330UA-FB018R, Zenbook UX330UA-FB161T, Zenbook UX330UA-FC004T, Zenbook UX330UA-FC006T, Zenbook UX330UA-FC031T, Zenbook UX330UA-FC034T, Zenbook UX330UA-FC059T, Zenbook UX330UA-FC078T, Zenbook UX330UA-FC079T, ASUS [Zenbook UX330UA-FC080T](#) Laptop Battery, Zenbook UX330UA-FC115T, Zenbook UX330UA-FC118T, Zenbook UX330UAFB018R, Zenbook UX330UAFB161T, Zenbook UX330U AFC004T, Zenbook UX330U AFC006T, Zenbook UX330U AFC031T, Zenbook UX330U AFC034T, Zenbook UX330U AFC059T, Zenbook UX330U AFC078T, Zenbook UX330U AFC079T, Zenbook UX330U AFC080T, Zenbook UX330U AFC115T, Zenbook UX330U AFC118T, Zenbook UX331FAL-BH71, Zenbook UX331FAL-BS8202T, Zenbook UX331FAL-EG002T, Zenbook UX331FAL-EG006T, Zenbook UX331FAL-EG009T, Zenbook UX331FAL-EG013R, Zenbook UX331FAL-EG013T, Zenbook UX331FAL-EG017R, ASUS [Zenbook UX331FAL-EG027R](#) Laptop Battery, Zenbook UX331FAL-EG028T, ZenBook UX331UA-AS51, ZenBook UX331UA-DS71, ZenBook UX331UA-EG003T, ZenBook UX331UA-EG005T, ZenBook UX331UA-EG010T, ZenBook UX331UA-EG012T, ZenBook UX331UA-EG013T, ZenBook UX331UA-EG018T, ZenBook UX331UA-EG028T, ZenBook UX331UA-EG029T, ZenBook UX331UA-EG039T, ZenBook UX331UA-EG061R, ZenBook UX331UA-EG071T, ZenBook UX331UA-EG101T, ZenBook UX331UA-EG131T, ZenBook UX331UA-EG156T, ZenBook UX331UA-EG158T, ZenBook UX331UA-EG160T, ZenBook UX331UA-QB51-CB, ZenBook UX331UAAS51, ZenBook UX331UADS71, ASUS [ZenBook UX331UAEG003T](#) Laptop Battery, ZenBook UX331UAEG005T, ZenBook UX331UAEG010T, ZenBook UX331UAEG012T, ZenBook UX331UAEG013T, ZenBook UX331UAEG018T, ZenBook UX331UAEG028T, ZenBook UX331UAEG029T, ZenBook UX331UAEG039T, ZenBook UX331UAEG061R, ZenBook UX331UAEG071T, ZenBook UX331UAEG101T, ZenBook UX331UAEG131T, ZenBook UX331UAEG156T, ZenBook UX331UAEG158T, ZenBook UX331UAEG160T, ZenBook UX331UAL, ZenBook UX331UAQB51CB, Zenbook UX331UN-C4032R, Zenbook UX331UN-C4043T, Zenbook UX331UN-C4088T, Zenbook UX331UN-C4136R, Zenbook UX331UN-C4136T, Zenbook UX331UN-C4137R, Zenbook UX331UN-EG004T, Zenbook UX331UN-EG008T, Zenbook UX331UN-EG009T, Zenbook UX331UN-EG010T, Zenbook UX331UN-EG011T, Zenbook UX331UN-EG012T, Zenbook UX331UN-EG015T, Zenbook UX331UN-EG016T, Zenbook UX331UN-EG017T, Zenbook UX331UN-EG062T, Zenbook UX331UN-EG080T, Zenbook UX331UN-EG103T, Zenbook UX331UN-EG105T, Zenbook UX331UN-EG106T, Zenbook UX331UN-EG113T, Zenbook UX331UN-EG129T, Zenbook UX331UN-EG134T, Zenbook UX331UN-EG151T, Zenbook UX331UN-WS51T, Zenbook UX331UNC4032R, Zenbook UX331UNC4043T, ASUS [Zenbook UX331UNC4088T](#) Laptop Battery, Zenbook UX331UNC4136R, Zenbook UX331UNC4136T, Zenbook UX331UNC4137R, Zenbook UX331UNEG004T, Zenbook UX331UNEG008T, Zenbook UX331UNEG009T, Zenbook UX331UNEG010T, Zenbook UX331UNEG011T, Zenbook UX331UNEG012T, Zenbook UX331UNEG015T, Zenbook UX331UNEG016T, Zenbook UX331UNEG017T, Zenbook UX331UNEG062T, ASUS [Zenbook UX331UNEG080T](#) Laptop Battery, Zenbook UX331UNEG103T, Zenbook UX331UNEG105T, Zenbook UX331UNEG106T, Zenbook UX331UNEG113T, Zenbook UX331UNEG129T, Zenbook UX331UNEG134T, ASUS [Zenbook](#)

[UX331UNEG151T](#) Laptop Battery, Zenbook UX331UNWS51T, ZenBook UX333, ZenBook UX333FA, Zenbook UX333FN, ZenBook UX334FL, Zenbook UX3410UA, Zenbook UX3410UA-GV028T, Zenbook UX3410UA-GV078T, Zenbook UX3410UA-GV079T, Zenbook UX3410UA-GV080T, Zenbook UX3410UA-GV081T, Zenbook UX3410UA-GV128T, Zenbook UX3410UA-GV129T, Zenbook UX3410UA-GV138T, Zenbook UX3410UA-GV149T, Zenbook UX3410UA-GV215T, Zenbook UX3410UA-GV265T, Zenbook UX3410UA-GV375T, Zenbook UX3410UA-GV424T, Zenbook UX3410UA-GV465T, Zenbook UX3410UA-GV470T, Zenbook UX3410UA-GV474T, ASUS [Zenbook UX3410UA-GV475T](#) Laptop Battery, Zenbook UX3410UA-GV579T, Zenbook UX3410UA-GV629T, Zenbook UX3410UA-GV638T, Zenbook UX3410UA-GV639T, Zenbook UX3410UA-GV643T, Zenbook UX3410UA-GV939T, Zenbook UX3410UAGV028T, Zenbook UX3410UAGV078T, Zenbook UX3410UAGV079T, ASUS [Zenbook UX3410UAGV080T](#) Laptop Battery, Zenbook UX3410UAGV149T, Zenbook UX3410UAGV265T, Zenbook UX3430UA, Zenbook UX3430UA-GV009T, Zenbook UX3430UA-GV010T, Zenbook UX3430UA-GV012T, Zenbook UX3430UA-GV068T, Zenbook UX3430UA-GV140T, Zenbook UX3430UA-GV301T, Zenbook UX3430UA-GV348T, ASUS [Zenbook UX3430UA-GV375T](#) Laptop Battery, Zenbook UX3430UA-GV376T, Zenbook UX3430UAGV009T, Zenbook UX3430UAGV010T, Zenbook UX3430UAGV012T, Zenbook UX3430UAGV068T, Zenbook UX3430UAGV140T, Zenbook UX3430UAGV301T, Zenbook UX3430UAGV348T, Zenbook UX3430UAGV375T, Zenbook UX3430UAGV376T, Zenbook UX360CA, Zenbook UX360CA-UBM1T, Zenbook UX362, Zenbook UX362FA, Zenbook UX370UA, ZENBOOK UX390UA, ZenBook UX390UA-GS031T, ZenBook UX390UA-GS032T, ZenBook UX390UA-GS034T, ZenBook UX390UA-GS039T, ZenBook UX390UA-GS041T, ZenBook UX390UA-GS046T, ZenBook UX390UA-GS063T, ZenBook UX390UAGS031T, ZenBook UX390UAGS032T, ZenBook UX390UAGS034T, ZenBook UX390UAGS039T, ZenBook UX390UAGS041T, ZenBook UX390UAGS046T, ZenBook UX390UAGS063T, ASUS [ZenBook UX390UAK](#) Laptop Battery, Zenbook UX391UA, ZenBook UX392, ZenBook UX392FA, ZenBook UX392FA-AB001R, ZenBook UX392FA-AB002R, ZenBook UX392FA-AB004T, ASUS [Zenbook UX392FA-AB007T](#) Laptop Battery, ZenBook UX392FA-AB015T, ZenBook UX392FA-AB016T, ZenBook UX392FA-AB017T, ZenBook UX392FA-AB019T, ZenBook UX392FA-AB021T, ZenBook UX392FA-AB030T, Zenbook UX392FA-AB032R, ZenBook UX410UA, Zenbook UX410UA-AS74, Zenbook UX410UA-AX8201T, ZenBook UX410UA-GV010T, ASUS [Zenbook UX410UA-GV024T](#) Laptop Battery, Zenbook UX410UA-GV027T, Zenbook UX410UA-GV063T, Zenbook UX410UA-GV096T, Zenbook UX410UA-GV097T, Zenbook UX410UA-GV151T, Zenbook UX410UA-GV157T, Zenbook UX410UA-GV158T, Zenbook UX410UA-GV190T, Zenbook UX410UA-GV232T, Zenbook UX410UA-GV262T, Zenbook UX410UA-GV285T, Zenbook UX410UA-GV296, Zenbook UX410UA-GV296T, Zenbook UX410UA-GV334T, Zenbook UX410UA-GV348T, Zenbook UX410UA-GV349T, Zenbook UX410UA-GV350T, Zenbook UX410UA-GV362T, Zenbook UX410UA-GV368T, ASUS [Zenbook UX410UA-GV415T](#) Laptop Battery, Zenbook UX410UA-GV423T, Zenbook UX410UA-GV428T, Zenbook UX410UA-GV445T, Zenbook UX410UA-GV454T, Zenbook UX410UA-GV503T, ASUS [Zenbook UX410UA-GV534T](#) Laptop Battery, Zenbook UX410UA-GV536T, Zenbook UX410UA-GV544T, Zenbook UX410UA-GV601T, ZenBook UX410UAGV010T, ZenBook UX410UF, Zenbook UX410UQ-0051A, Zenbook UX410UQ-GV015T, ZenBook UX410UQ-GV019R, ZenBook UX410UQ-GV039T, Zenbook UX410UQ-GV052T, Zenbook UX410UQ-GV066T, Zenbook UX410UQ-GV084T, Zenbook UX410UQ-GV090T, Zenbook UX410UQ-GV091T, Zenbook UX410UQ-GV103T, ASUS [Zenbook UX410UQ-GV110T](#) Laptop Battery, Zenbook UX410UQ-GV146T, Zenbook UX410UQ-GV152T, Zenbook UX410UQ-GV155T, ZENBOOK UX42, Zenbook UX42A, ASUS [Zenbook UX42VS](#) Laptop Battery, Zenbook UX42VS-W3007H, Zenbook UX42VS-W3007P, Zenbook UX42VS-W3015H, Zenbook

UX42VS-W3021H, Zenbook UX42VS-W3028H, ZenBook UX430, ZenBook UX430 Series, ZenBook UX430U Series, ZenBook UX430UA, ZenBook UX430UA Series, ZenBook UX430UA-GV001R, Zenbook UX430UA-GV001T, Zenbook UX430UA-GV002T, Zenbook UX430UA-GV007T, Zenbook UX430UA-GV023T, Zenbook UX430UA-GV027T, Zenbook UX430UA-GV028T, Zenbook UX430UA-GV029T, Zenbook UX430UA-GV046T, Zenbook UX430UA-GV065T, Zenbook UX430UA-GV092T, ZenBook UX430UA-GV096T, ZenBook UX430UA-GV100T, Zenbook UX430UA-GV102T, Zenbook UX430UA-GV103T, Zenbook UX430UA-GV114T, Zenbook UX430UA-GV117T, Zenbook UX430UA-GV126T, Zenbook UX430UA-GV128T, Zenbook UX430UA-GV138T, Zenbook UX430UA-GV168T, Zenbook UX430UA-GV183T, Zenbook UX430UA-GV223T, Zenbook UX430UA-GV224T, Zenbook UX430UA-GV232T, Zenbook UX430UA-GV259T, Zenbook UX430UA-GV261T, Zenbook UX430UA-GV264T, Zenbook UX430UA-GV265T, Zenbook UX430UA-GV272T, Zenbook UX430UA-GV273T, Zenbook UX430UA-GV303T, Zenbook UX430UA-GV307T, Zenbook UX430UA-GV334T, Zenbook UX430UA-GV338T, Zenbook UX430UA-GV340T, Zenbook UX430UA-GV356T, Zenbook UX430UA-GV372T, Zenbook UX430UA-GV407T, Zenbook UX430UA-GV408T, Zenbook UX430UA-GV412T, Zenbook UX430UA-GV414T, Zenbook UX430UA-GV415T, Zenbook UX430UA-GV423T, Zenbook UX430UA-GV424T, Zenbook UX430UA-GV502T, ASUS [Zenbook UX430UA-GV509T](#) Laptop Battery, Zenbook UX430UA-GV518T, ASUS [Zenbook UX430UA-GV534T](#) Laptop Battery, Zenbook UX430UA-GV535T, Zenbook UX430UA-GV595T, ZenBook UX430UN, Zenbook UX430UN-0071A7500U, Zenbook UX430UN-0101A8250U, Zenbook UX430UN-0132B8250U, Zenbook UX430UN-0182C8250U, Zenbook UX430UN-0191A8550U, Zenbook UX430UN-0211D8250U, Zenbook UX430UN-GS8204T, Zenbook UX430UN-GS8505T, Zenbook UX430UN-GV020T, Zenbook UX430UN-GV022T, Zenbook UX430UN-GV027T, Zenbook UX430UN-GV033T, ZenBook UX430UN-GV054T, ZenBook UX430UN-GV057R, Zenbook UX430UN-GV059T, ZenBook UX430UN-GV060R, Zenbook UX430UN-GV060T, ZenBook UX430UN-GV065T, Zenbook UX430UN-GV069T, ZenBook UX430UN-GV070R, ZenBook UX430UN-GV070T, Zenbook UX430UN-GV088T, ZenBook UX430UN-GV095T, ASUS [Zenbook UX430UN-GV098T](#) Laptop Battery, Zenbook UX430UN-GV109T, Zenbook UX430UN-GV115T, Zenbook UX430UN-GV122T, Zenbook UX430UN-GV135T, Zenbook UX430UN-GV165T, Zenbook UX430UN-GV171T, Zenbook UX430UN-GV172T, Zenbook UX430UN-GV190T, Zenbook UX430UN-GV203T, Zenbook UX430UN-GV207T, Zenbook UX430UN-GV216T, Zenbook UX430UN-GV266T, ZenBook UX430UQ, ZenBook UX430UQ Series, ZenBook UX430UQ-0021A7500U, ZenBook UX430UQ-0041A7200U, ZenBook UX430UQ-0052B7500U, ZenBook UX430UQ-0062B7200U, ZenBook UX430UQ-0081D7200U, ZenBook UX430UQ-0092C7200U, ZenBook UX430UQ-0132B7200U, ZenBook UX430UQ-0152C7200U, ZenBook UX430UQ-0201A7200U, ASUS [ZenBook UX430UQ-GV004T](#) Laptop Battery, ZenBook UX430UQ-GV012T, ZenBook UX430UQ-GV019T, ZenBook UX430UQ-GV022T, ZenBook UX430UQ-GV026T, ZenBook UX430UQ-GV044T, ZenBook UX430UQ-GV047T, ZenBook UX430UQ-GV048T, ZenBook UX430UQ-GV064T, ZenBook UX430UQ-GV069T, ZenBook UX430UQ-GV073T, ZenBook UX430UQ-GV080T, ZenBook UX430UQ-GV126T, ZenBook UX430UQ-GV145T, ZenBook UX430UQ-GV146T, ZenBook UX430UQ-GV147T, ZenBook UX430UQ-GV151T, ZenBook UX430UQ-GV154T, ZenBook UX430UQ-GV166T, ZenBook UX430UQ-GV171T, ZenBook UX430UQ-GV209T, ZenBook UX430UQ-GV212T, ZenBook UX430UQ-GV217T, ZenBook UX430UQ-GV218T, ZenBook UX430UQ-GV223T, ZenBook UX430UQ-GV226T, ZenBook UX430UQ-GV235T, ZenBook UX430UQ-GV243T, ZenBook UX430UQ-GV512T, ASUS [ZenBook UX431](#) Laptop Battery, ZenBook UX431FA, ZenBook UX431FL-AN012T, ZenBook UX431FN, ZenBook UX433, ZenBook UX433FA, ZenBook UX433FL, ZenBook UX433FN, ZenBook UX450, ZenBook UX450F, ZenBook UX450FD, ZenBook UX480, ZenBook

UX480F, ZenBook UX480FD, ZenBook UX490 Series, ZenBook UX490U Series, ZenBook UX490UA Series, Zenbook UX501JW, ZenBook UX501JW-CN245P, ZenBook UX501JW-CN245R, ZenBook UX501JW-CN245T, ZenBook UX501JW-DS71T, ZenBook UX501JW-FI177H, ZenBook UX501JW-FI177T, ZenBook UX501JW-FI218H, ASUS [ZenBook UX501JW-FI218T](#) Laptop Battery, ZenBook UX501LW, Zenbook UX51, ZenBook UX510UQ, Zenbook UX510UW, Zenbook UX510UW-CN044T, Zenbook UX510UWCN044T, ZenBook UX510UX, ZenBook UX510UX-CN014T, ZenBook UX510UX-CN020T, ZenBook UX510UX-CN044T, ASUS [ZenBook UX510UX-CN047T](#) Laptop Battery, ZenBook UX510UX-CN179T, ZenBook UX510UX-CN216T, ZenBook UX510UXCN014T, ZenBook UX510UXCN020T, ZenBook UX510UXCN044T, ZenBook UX510UXCN047T, ZenBook UX510UXCN179T, ZenBook UX510UXCN216T, Zenbook UX51VZ, ZenBook UX52, ASUS [ZenBook UX52A](#) Laptop Battery, ZenBook UX52V, ZenBook UX52VS, ZenBook UX52X3317VS, ZenBook UX52X3317VS-SL, ZenBook UX52X3317VSSL, ZenBook UX52X3517VS, ZenBook UX52X3517VS-SL, ZenBook UX52X3517VSSL, Zenbook UX530UQ, Zenbook UX530UQ-FY005T, Zenbook UX530UQ-FY019T, Zenbook UX530UQ-FY025T, Zenbook UX530UQFY005T, Zenbook UX530UQFY019T, Zenbook UX530UQFY025T, Zenbook UX530UX, Zenbook UX530UX-FY017T, Zenbook UX530UX-FY027T, Zenbook UX530UX-FY029R, Zenbook UX530UX-FY040T, Zenbook UX530UX-FY070T, Zenbook UX530UXFY017T, Zenbook UX530UXFY027T, Zenbook UX530UXFY029R, ASUS [Zenbook UX530UXFY040T](#) Laptop Battery, Zenbook UX530UXFY070T, ZenBook UX533FD, ZENBOOK UX533FD-A8067T, ZENBOOK UX534FT-BP8509T, Zenbook UX560UA, Zenbook UX560UQ, Zenbook UX560UQ-1C, Zenbook UX560UX, Zenbook UX561UD, ZenBook UX580, ZenBook UX580G, ZenBook UX580GD, ZenBook UX580GE, Zenbooks UX305LA-FB015T, ASUS [Zenbooks UX305LAFB015T](#) Laptop Battery, Zenbooks UX32LA-R3073H, Zenbooks UX32LAR3073H, Zenfone Flip UX560UX, Zenfone Flip UX560UX-FJ020R, Zenfone Flip UX560UX-FZ017T, Zenfone Flip UX560UX-FZ021T, Zenfone Flip UX560UX-FZ022T, Zenfone Flip UX560UX-FZ025T, ASUS [Zenfone Flip UX560UXFJ020R](#) Laptop Battery, Zenfone Flip UX560UXFZ017T, Zenfone Flip UX560UXFZ021T, Zenfone Flip UX560UXFZ022T, Zenfone Flip UX560UXFZ025T, ZenPad (Z8050CA), ZenPad 10 (Z300C), ZenPad 10 (Z300CG), ZenPad 10 (Z300CL), ZenPad 10 (Z300CT), ZenPad 10 (Z300CX), ZenPad 10 (Z300CXG), ZenPad 10 (ZD0310C), ZenPad 10 (ZD300C), ZenPad 10 (ZD300C-1A016A), ZenPad 10 (ZD300C-1A018A), ZenPad 10 (ZD300C-1A023A), ZenPad 10 (ZD300C-1A032A), ZenPad 10 (ZD300C-1L012A), ZenPad 10 (ZD300C-1L015A), ZenPad 10 (ZD300C1A016A), ZenPad 10 (ZD300C1A018A), ZenPad 10 (ZD300C1A023A), ZenPad 10 (ZD300C1A032A), ZenPad 10 (ZD300C1L012A), ZenPad 10 (ZD300C1L015A), ASUS [ZenPad 10 \(ZD300CG\)](#) Laptop Battery, ZenPad 10 3G (Z300CG), ZenPad 10 3G (Z300CG-1A020A), ZenPad 10 3G (Z300CG-1L009A), ZenPad 10 3G (Z300CG1A020A), ZenPad 10 3G (Z300CG1L009A), ASUS [ZenPad 10 3G \(ZD300CG\)](#) Laptop Battery, ZenPad 10 3G (ZD300CG-1A009A), ZenPad 10 3G (ZD300CG-1A011A), ZenPad 10 3G (ZD300CG-1A016A), ZenPad 10 3G (ZD300CG-1A020A), ZenPad 10 3G (ZD300CG-1L009A), ZenPad 10 3G (ZD300CG1A009A), ZenPad 10 3G (ZD300CG1A011A), ZenPad 10 3G (ZD300CG1A016A), ZenPad 10 3G (ZD300CG1A020A), ZenPad 10 3G (ZD300CG1L009A), ZenPad 10 LTE (Z300CL) Serie, ZenPad 10 LTE (Z300CL-1A012A), ZenPad 10 LTE (Z300CL-1L023A), ZenPad 10 LTE (Z300CL1A012A), ZenPad 10 LTE (Z300CL1L023A), ZenPad 10 LTE (ZD300CL), ZenPad 10 LTE (ZD300CL-1A001A), ZenPad 10 LTE (ZD300CL-1A020A), ZenPad 10 LTE (ZD300CL1A001A), ASUS [ZenPad 10 LTE \(ZD300CL1A020A\)](#) Laptop Battery, ZENPAD 10 Z300, ZenPad 3 8 Z581KL, ZenPad 3S 10, ZENPAD 3S 10 LTE Z500KL-BK32S4, ZENPAD 3S 10 Z500KL, ZENPAD 3S 10 Z500KL-1A, ZENPAD 3S 10 Z500KL-1A007A, ZENPAD 3S 10 Z500KL-1A008A, ZENPAD 3S 10 Z500KL-1A009A, ZENPAD 3S 10 Z500KL-1A012A, ASUS [ZENPAD 3S 10 Z500KL-1A014A](#) Laptop Battery, ZENPAD 3S 10

Z500KL-1A016A, ZENPAD 3S 10 Z500KL-1A019A, ZENPAD 3S 10 Z500KL-1A020A, ZENPAD 3S 10 Z500KL-1A023A, ZENPAD 3S 10 Z500KL-1A032A, ZENPAD 3S 10 Z500KL-1A042A, ZENPAD 3S 10 Z500KL-1A045A, ZenPad 7.0 (Z170CG), ZenPad 70 Z370C, ZenPad 70 Z370C-1A041A, ZenPad 70 Z370C-1B036A, ZenPad 70 Z370C1A041A, ZenPad 70 Z370C1B036A, ZENPAD 8 Z380KL, ZenPad 8.0 (Z380C), ZenPad 8.0 (Z380C-1A008A), ZenPad 8.0 (Z380C-1B038A), ZenPad 8.0 (Z380C-1B039A), ZenPad 8.0 (Z380C-1B062A), ZenPad 8.0 (Z380C1A008A), ZenPad 8.0 (Z380C1B038A), ZenPad 8.0 (Z380C1B039A), ZenPad 8.0 (Z380C1B062A), ZenPad 8.0 (Z380CX), ZenPad 8.0 (Z380CX-1B010A), ZenPad 8.0 (Z380CX1B010A), ZenPad 8.0 (Z380KL), ZenPad 8.0 (Z380KL-1A059A), ZenPad 8.0 (Z380KL-1B047A), ZenPad 8.0 (Z380KL-1B048A), ZenPad 8.0 (Z380KL-1L058A), ZenPad 8.0 (Z380KL1A059A), ZenPad 8.0 (Z380KL1B047A), ASUS [ZenPad 8.0 \(Z380KL1B048A\)](#) Laptop Battery, ZenPad 8.0 (Z380KL1L058A), ZenPad 8.0 (Z380M), ZenPad 8.0 Z380C, ASUS [ZenPad 8.0 Z380CX](#) Laptop Battery, ZenPad 8.0 Z380KL, ZenPad 80 Z380C, ZenPad 80 Z380C-1A008A, ZenPad 80 Z380C-1B038A, ZenPad 80 Z380C-1B039A, ZenPad 80 Z380C-1B062A, ZenPad 80 Z380C1A008A, ZenPad 80 Z380C1B038A, ZenPad 80 Z380C1B039A, ZenPad 80 Z380C1B062A, ZenPad 80 Z380CX, ZenPad 80 Z380CX-1B010A, ZenPad 80 Z380CX1B010A, ZenPad 80 Z380KL, ZenPad 80 Z380KL-1A059A, ZenPad 80 Z380KL-1B047A, ASUS [ZenPad 80 Z380KL-1B048A](#) Laptop Battery, ZenPad 80 Z380KL-1L058A, ZenPad 80 Z380KL1A059A, ZenPad 80 Z380KL1B047A, ZenPad 80 Z380KL1B048A, ZenPad 80 Z380KL1L058A, ZenPad 80 Z380M, ZenPad C 7.0 (Z170C), ZenPad C 7.0 (Z170CG), ZenPad CB81(Z380 Series), ZENPAD S 8 Z580CA-C1-BK, ZENPAD S 8 Z580CAC1BK, ZenPad S 8.0 (Z580C), ZenPad S 8.0 (Z580C-1A005A), ZenPad S 8.0 (Z580C-1B006A), ZenPad S 8.0 (Z580C1A005A), ZenPad S 8.0 (Z580C1B006A), ZenPad S 8.0 (Z580CA), ZenPad S 8.0 (Z580CA) Serie, ZenPad S 8.0 (Z580CA-1A027A), ASUS [ZenPad S 8.0 \(Z580CA1A027A\)](#) Laptop Battery, ZENPAD S 8.0 Z580C, ZenPad S 8.0 Z580C-1A005A, ZenPad S 8.0 Z580C-1B006A, ZenPad S 8.0 Z580C-B1-BK, ZENPAD S 8.0 Z580CA, ZenPad S 8.0 Z580CA-1A027A, ZenPad S 8.0 Z580CA-1B063A, ZenPad S 80 Z580C, ZenPad S 80 Z580C-1A005A, ZenPad S 80 Z580C-1B006A, ZenPad S 80 Z580C-B1-BK, ZenPad S 80 Z580C1A005A, ZenPad S 80 Z580C1B006A, ZenPad S 80 Z580CA, ASUS [ZenPad S 80 Z580CA Serie](#) Laptop Battery, ZenPad S 80 Z580CA-1A027A, ZenPad S 80 Z580CA-1B063A, ZenPad S 80 Z580CA1A027A, ASUS [Zenpad S8](#) Laptop Battery, ZenPad TZ902, ZenPad Z0310CX, ZENPAD Z10 ZT500KL, ZenPad Z580C, ZenPad Z580CA-C1-BK, ZenPad Z580CAC1BK, ZenPad Z7010C, ZenPad Z7010CG, ZenPad Z8 ZT581KL, ZenPad Z8050CA, ZenPad Z8s, ZenPad ZD0310C, ZenPad ZenPad 10 (ZD300CL), Zephyrus GX501, Zephyrus GX701, Zephyrus M GM501, Zephyrus S GX351, Zephyrus S GX531, Zephyrus S GX531GM, Zephyrus S GX531GS, ASUS [Zephyrus S GX531GV](#) Laptop Battery, Zephyrus S GX531GW, Zephyrus S GX531GX, ASUS [ZT582KL](#) Laptop Battery, ZX50, ZX50J, ZX50JX4200, ZX50JX4720, ZX50V, ZX50VW, ZX50VW6300, ZX50VW6700, ZX53VD, ZX53VE, ZX53VW-AH58, ZX553VD, ZX553VD-DM969T, ZX553VD-DM970T, ZX553VD-DM997T, ZX553VD-FY683T, ZX63V,